

disable_encoders()

 dexterindustries.com/GoPiGo/programming__trashed/python-programming-for-the-raspberry-pi-gopigo__trashed/disable_encoders/

Disable the GoPiGo encoders

Disable the encoder ISR on the GoPiGo. If the encoders are disabled, the GoPiGo firmware will not calculating the pulse count for the encoder rotations as the wheels move. This can be helpful if you want to run so other processor intensive task on the GoPiGo

Syntax

```
disable_encoders()
```

Parameter:

None

Return:

1 on success

-1 on error

Example

```
from gopigo import *  
disable_encoders()  
fwd()
```