


# set\_speed()

---

 [dexterindustries.com/GoPiGo/programming\\_\\_trashed/python-programming-for-the-raspberry-pi-gopigo\\_\\_trashed/set\\_speed/](https://dexterindustries.com/GoPiGo/programming__trashed/python-programming-for-the-raspberry-pi-gopigo__trashed/set_speed/)

## Set the speed of the GoPiGo

The speed of the GoPiGo can be between 0-255. The default speed is 200.

You can use `set_speed()` to set the speed of the GoPiGo between 0 and 255. Any speed above 255 will be made as 255 and any speed below 0 will be made 0.

## Syntax

```
set_speed(speed)
```

## Parameter:

speed: valid speed value between 0-255

## Return:

None

## Example

```
from gopigo import *  
set_speed(150)
```