



ABB INDUSTRIAL DRIVES

ACS880-07 drives (560 to 2800 kW)

Hardware manual

ACS880-07 drives (560 to 2800 kW)

Hardware manual

Table of contents

1. Safety instructions

4. Mechanical installation

6. Electrical installation

9. Start-up

Table of contents

1 Safety instructions

Contents of this chapter
Use of warnings and notes
General safety in installation, start-up and maintenance
Electrical safety in installation, start-up and maintenance
Electrical safety precautions
Additional instructions and notes
Printed circuit boards
Grounding
General safety in operation
Additional instructions for permanent magnet motor drives
Safety in installation, start-up, maintenance
Safety in operation

2 Introduction to the manual

Contents of this chapter
Target audience
Categorization by frame size and option code
Use of component designations
Quick installation, commissioning and operation flowchart
Terms and abbreviations
Related documents

3 Operation principle and hardware description

Contents of this chapter
Operation principle
Overview circuit diagram of the drive
12-pulse connection (option +A004)
Cabinet line-up and layout examples
Frame 1xD8T+2xR8i
Frame 2xD7T+2xR8i (12-pulse connection, option +A004)
Frame 2xD8T+3xR8i
Frame 3xD8T+4xR8i (with main breaker, option +F255)
Auxiliary control cubicle (ACU) layout
Overview of power and control connections (BCU-x2)
Overview of power and control connections (UCU-22)
Door devices
Main disconnecting device (Q1.1)
Auxiliary voltage switch [Q21]
Grounding (earthing) switch [Q9], optional
Other devices on the door

6 Table of contents

Descriptions of options	5
Degree of protection	5
Definitions	5
IP22 (UL Type 1)	5
IP42 (UL Type 1 Filtered) (option +B054)	5
IP54 (UL Type 12) (option +B055)	5
Marine construction (option +C121)	5
Cooling air inlet through bottom of cabinet (option +C128)	5
UL Listed (option +C129)	5
Channeled air outlet (option +C130)	5
CSA Approved (option +C134)	5
Plinth height (options +C164 and +C179)	5
Seismic design (option +C180)	5
Enclosures on left (options +C199	5
Resistor braking (options +D150 and +D151)	5
EMC filter (option +E202)	5
Sine filter (option +E206)	5
Cabinet heater with external supply (option +G300)	5
Cabinet lighting (option +G301)	5
Terminals for external control voltage (option +G307)	5
Output for motor space heater (option +G313)	5
Supply connection by busbars (option +G317)	5
Run/Fault lights (options +G327	5
Halogen-free wiring and materials (option +G330)	5
V-meter with selector switch (option +G334)	5
Wire markings	5
Standard wiring	5
Additional wire markings	5
Common mode filter temperature monitoring (option +G453)	5
Bottom cable entry/exit (options +H350 and +H352)	5
Top cable entry/exit (options +H351 and +H353)	5
Cable conduit entry (option +H358)	5
Common motor terminal cubicle (option +H359)	5
Common output terminals (option +H366)	5
Connectivity for wired remote monitoring (option +K496)	5
Connectivity for wireless remote monitoring (option +K497)	5
Additional terminal block X504 (option +L504)	5
Thermal protection with PTC relays (options +L505, +2L505, +L513, +2L513,	5
+L536, +L537)	5
+L505, +2L505, +L513, +2L513	5
+L536, +L537	5
Thermal protection with Pt100 relays (options +nL506, +nL514)	5
SM610 or auxiliary motor fan (options +M600	5
What the option contains	5
Description	5
Type designation label	6
Type designation key	6
Option codes	6

Necessary tools	
Examining the delivery	
Moving and unpacking the drive	
Moving the drive in its packaging	
Lifting the crate with a forklift	
Lifting the crate with a crane	
Moving the crate with a forklift	
Removing the transport package	
Moving the unpacked drive cabinet	
Lifting the cabinet with a crane	
Moving the cabinet on rollers	
Moving the cabinet on its back	
Moving the cabinet to its final position	
Attaching the cabinet to the floor and wall or roof	
General rules	
Attaching the cabinet (non-marine units)	
Alternative 1.- Clamping	
Alternative 2.- Using the holes inside the cabinet	
Alternative 3.- Cabinets with plinth options +C164 and +C179	
Attaching the cabinet (marine units)	
Joining cabinet sections together	
Miscellaneous	
Cable duct in the floor below the cabinet	
Arc welding	
Air inlet through the bottom of the cabinet (option +C128)	
Air outlet duct on the cabinet roof (option +C130)	
Calculating the required static pressure difference	
Lifting lugs and bars	
Certificate of conformity	
Declarations of conformity	

5 Guidelines for planning the electrical installation

Contents of this chapter	
Limitation of liability	
North America	
Selecting the supply transformer	
Basic guidelines	
Additional notes	
A drive with a 12-pulse diode supply unit	
Selecting the supply disconnecting device	
Selecting the main contactor or breaker	
Examining the compatibility of the motor and drive	
Protecting the motor insulation and bearings	
Requirements tables	

Requirements for ABB motors, P	< 100 kW (134 hp)
Requirements for ABB motors, P	> 100 kW (134 hp)
Requirements for non-ABB motors, P	< 100 kW (134 hp)

8 Table of contents

Additional requirements for ABB motors of types other than M3_, HX_, AM_ and AX	9
Additional requirements for braking applications	9
Additional requirements for ABB high-output and IP23 motors	9
Additional requirements for non-ABB high-output and IP23 motors	9
Additional data for calculating the rise time and the peak line-to-line voltage	9
Additional note for sine filters	9
Selecting the power cables	10
Power cable selection procedure and applicability check	10
General guidelines	10
Typical power cable sizes	10
Power cable types	10
Preferred power cable types	10
Alternate power cable types	10
Not allowed power cable types	10
Power cable shield	10
Grounding requirements	10
Additional grounding requirements - IEC	10
Additional grounding requirements - UL (NEC)	10
Selecting the control cables	10
Shielding	10
Signals in separate cables	10
Signals that can be run in the same cable	10
Relay cable	10
Control panel to drive cable	10
PC tool cable	10
Routing the cables	10
General guidelines - IEC	10
Continuous motor cable shield/conduit and metal enclosure for equipment on the motor cable	10
Separate control cable ducts	10
Protecting the drive, input power cable, motor and motor cable in short circuit situations and against thermal overload	10
Protecting the input cabling and the drive upon a short-circuit	10
Protecting the motor and motor cable in short-circuits	10
Protecting the drive and the power cables against thermal overload	10
Protecting the motor against thermal overload	10
Protecting the motor against overload without thermal model or temperature sensors	10
Protecting the drive against ground faults	10
Residual current device compatibility	10
Implementing the emergency stop function	10
Implementing the Safe torque off function	10
Implementing the Prevention of unexpected start-up function	10
Implementing an ATEX-certified motor thermal protection	10
Implementing the functions provided by the FSO safety functions module	11
Implementing the power loss ride-through function	11
Implementing a bypass connection	11

[Protecting the contacts of relay outputs](#)

[Implementing a motor temperature sensor connection](#)

[Connecting a motor temperature sensor to the drive through an option module](#)

6 Electrical installation

[Contents of this chapter](#)

[Warnings](#)

[Measuring the insulation](#)

[Measuring the insulation resistance of the drive](#)

[Measuring the insulation resistance of the motor and motor cable](#)

[Measuring the insulation resistance of the input power cable](#)

[Compatibility check : JT \(ungrounded\) earthing system](#)

[Attaching the device stickers to the cabinet door](#) .

[Checking the settings of transformers T21, T101 and T111](#)

[T21 and T101 tap settings \(400 V units\)](#)

[T21 and T101 tap settings \(690 V units\)](#)

[T111 tap settings](#)

[Connecting the control cables](#)

[Control cable connection procedure](#)

[Grounding the outer shields of the control cables 360° at the cabinet entry](#)

[Routing the control cables inside the cabinet](#) . . .

[Connecting control cabling](#)

[Connecting the motor cables \(units without common motor terminal cubicle or sine output filter\)](#)

[Motor connection diagram \(without option +H366\)](#)

[Motor connection diagram \(with option +H366\)](#) .

[Procedure](#)

[Removing an inverter module](#)

[Removing the fan carriage of an inverter module](#)

[Connecting the motor cables](#)

[Installing the fan carriage of an inverter module](#)

[Installing an inverter module](#)

[Connecting the motor cables \(units with common motor terminal cubicle or sine output filter\)](#)

[Output busbars](#)

[Connection diagram](#)

[Procedure](#)

[Connecting an external brake resistor assembly](#) . . .

[Connecting the input power cables](#)

[Connection diagram, 6-pulse units](#)

[Connection diagram, 12-pulse units](#)

[Layout of the input cable connection terminals and cable entries](#)

[Connection procedure](#)

[Use of fasteners in cable lug connections](#)

[Connecting a PC](#)

[Panel bus \(control of several units from one control panel\)](#)

10 Table of contents

7 Control units of the drive

Contents of this chapter	14
General	14
BCU layout	14
Default I/O diagram of the supply control unit (BCU-x2)	14
Default I/O diagram of the inverter control unit (BCU)	14
UCU layout	15
Default I/O diagram of the supply control unit (UCU-22)	15
Default I/O diagram of the inverter control unit (UCU-22)	15
Additional information on the connections	16
Power supply for the control unit (XPOW)	16
DIL input	16
The XD2D connector	16
Safe torque off (XSTO, XSTO OUT)	16
FSO safety functions module connection (X12, with BCU only)	16
SDHC memory card slot	16
MicroSDHC memory card slot	16
Connector data	16
BCU ground isolation diagram	16
UCU ground isolation diagram	16

8 Installation checklist

Contents of this chapter	17
Checklist	17

9 Start-up

Contents of this chapter	17
Start-up procedure	17
Switching off the drive	17

10 Fault tracing

Contents of this chapter	17
Control unit LEDs (BCU-x2)	17
Control unit LEDs (UCU-22)	17
Control panel and panel platform/holder LEDs	17
Warning and fault messages	17

11 Maintenance

Contents of this chapter	17
Handling fiber optic cables	17
Maintenance intervals	18
Description of symbols	18
Recommended maintenance intervals after start-up	18
Cabinet	18
Cleaning the interior of the cabinet	18
Cleaning the exterior of the drive	18

Fans	
Replacing a supply module (D7T) cooling fan	
Replacing a supply module (D8T) or inverter module (R8i) cooling fan	
Replacing the circuit board compartment fan	
Replacing the cooling fan in the auxiliary control cubicle	
Replacing the cooling fan in the incoming cubicle	
Replacing the roof fan (IP54/UL type 12)	
Replacing the common motor terminal cubicle fan	
Fan attached to the cabinet door	
Roof fan (with options +C128 and +H353)	
Floor fan (with options +C128 and +H353)	
Replacing the brake chopper and resistor cubicle fans (options +D150 and +D151)	
Supply and inverter modules	
Replacing a frame D7T supply module	
Replacing a frame D8T supply module	
Removing an inverter module	
Installing an inverter module	
Cleaning the heatsink	
Activating the reduced run of the supply unit	
Starting reduced run operation	
Resuming normal operation	
Activating the reduced run function of the inverter unit	
Returning the module	
Capacitors	
Reforming the capacitors	
Fuses	
Checking and replacing the DC fuses of a D7T supply module	
Checking and replacing the DC fuses of a D8T supply module	
Control panel	
Control units	
BCU control unit types	
Replacing the memory unit (BCU)	
Replacing the BCU control unit battery	
UCU control unit types	
Replacing the memory unit (UCU-22)	
Replacing the UCU control unit battery	
Replacing the microSDHC memory card (UCU-22)	
Functional safety components	

12 Technical data

Contents of this chapter	
Ratings	
Definitions	
Derating	
Surrounding air temperature derating	
Altitude derating	

12 Table of contents

DC fuses	23
Supply module internal DC fuses	23
Fuses on C/VAR varistor board	23
Brake chopper DC fuses	23
Dimensions and weights	23
Free space requirements	23
Losses, cooling data and noise	23
Sine output filter data	23
Typical power cable sizes	23
Terminal and cable entry data for the power cables	23
Terminal data for the motor cables	23
Terminal data for the supply and inverter control units	23
Terminal data for block X504	23
Electrical power network specification	23
Motor connection data	23
Efficiency	23
Energy efficiency data (ecodesign)	23
Protection classes	23
Ambient conditions	23
Transportation	24
Storage conditions	24
Colors	24
Materials	24
Drive	24
Packaging of drive	24
Packaging of options	24
Manuals	24
Disposal	24
Applicable standards	24
Markings	24
EMC compliance (IEC/EN 61800-3)	24
Definitions	24
Category C2	24
Category C3	24
Category C4	24
UL and CSA checklist	24
Tightening torques	24
Electrical connections	24
Mechanical connections	24
Insulation supports	24
Cable lugs	24
Disclaimers	24
Generic disclaimer	24
Cyber security disclaimer	24

13 Dimensions

Cabinet line-up dimensions	25
--	----

Frame 1×D8T + 2×R8i, IP54 (+B055)	
Frame 1×D8T + 2×R8i with common motor terminal cubicle (+H359)	1/2
Frame 1×D8T + 2×R8i with common motor terminal cubicle (+H359)	2/2
Frame 1×D8T + 2×R8i with brake choppers and resistors (+D150 +D151)	1/2
Frame 1×D8T + 2×R8i with brake choppers and resistors (+D150 +D151)	2/2
Frame 1×D8T + 2×R8i with sine output filter (+E206)	1/2
Frame 1×D8T + 2×R8i with sine output filter (+E206)	2/2
Frame 2×D8T + 2×R8i, 12-pulse (+A004) with grounding switch (+F259)	
Frame 2×D8T + 3×R8i	1/2
Frame 2×D8T + 3×R8i	2/2
Frame 2×D8T + 3×R8i with common motor terminal cubicle (+H359)	1/2
Frame 2×D8T + 3×R8i with common motor terminal cubicle (+H359)	2/2
Frame 2×D8T + 3×R8i with top entry / top exit (+H351/+H353)	1/2
Frame 2×D8T + 3×R8i with top entry/top exit .	2/2
Frame 3×D8T + 4×R8i	1/2
Frame 3×D8T + 4×R8i	2/2
Frame 3×D8T + 4×R8i with common motor terminal cubicle (+H359)	1/2
Frame 3×D8T + 4×R8i with common motor terminal cubicle (+H359)	2/2
Frame 3×D8T + 4×R8i with top entry / top exit (+H351/+H353)	1/2
Frame 3×D8T + 4×R8i with top entry / top exit (+H351/+H353)	2/2
Frame 4×D8T + 5×R8i (6-pulse) with top entry/exit, UL Listed (+C129)	1/2
Frame 4×D8T + 5×R8i (6-pulse) with top entry/exit, UL Listed (+C129)	2/2
Dimensions of empty cubicles (options +C199, +C200, +C201)	
IP22/IP42	
IP54	
Location and size of input terminals	
400 mm, bottom cable entry	
400 mm, top cable entry	
600 mm, without main breaker, bottom cable entry (including 12-pulse units with grounding switch)	
600 mm, without main breaker, top cable entry (including 12-pulse units with grounding switch)	
600 mm, 12-pulse units without grounding switch, bottom cable entry	
600 mm, 12-pulse units without grounding switch, top cable entry	
600 mm, with main breaker, bottom cable entry	
600 mm, with main breaker, top cable entry	
1000 mm (UL/CSA), top cable entry	
1000 mm (UL/CSA), bottom cable entry	
Location and size of output terminals	
Units without common motor terminal cubicle . . .	
Inverter module cubicle with two R8i modules, bottom cable exit	
Inverter module cubicle with two R8i modules, top cable exit	
Inverter module cubicle with three R8i modules, bottom cable exit	
Inverter module cubicle with three R8i modules, top cable exit	
Brake chopper cubicle	
Sine filter cubicle, 1000 mm, bottom cable exit	
Sine filter cubicle, 1000 mm, top cable exit	
Units with common motor terminal cubicle (+H359)	

14 Table of contents

Cubicle width 600 mm, bottom cable exit	30
Cubicle width 600 mm, top cable exit	30
14 The Safe torque off function	
Contents of this chapter	30
Description	30
Compliance with the European Machinery Directive and the UK Supply of Machinery (Safety) Regulations	
Wiring	30
Activation switch	30
Cable types and lengths	30
Grounding of protective shields	30
Dual-channel connection with internal power supply (BCU-x2)	31
Dual-channel connection with internal power supply (UCU-22)	31
Single-channel connection of activation switch (BCU-x2)	31
Single-channel connection of activation switch (UCU-22)	31
Multiple drives	31
Internal power supply (example, drives with ZCU-xx and BCU-x2)	31
Internal power supply (example, drives with UCU-22)	31
External power supply (example, drives with ZCU-xx and BCU-x2)	31
External power supply (example, drives with UCU-22)	31
Operation principle	31
Start-up including validation test	31
Competence	31
Validation test reports	31
Validation test procedure	31
Use	32
Maintenance	32
Competence	32
Perfect proof test procedure	32
Simplified proof test procedure	32
Fault tracing	32
Safety data	32
Terms and abbreviations	32
TUV certificate	32
Declarations of conformity	32

15 Resistor braking

Contents of this chapter	33
Operation principle	33
Factory-installed brake choppers and resistors	33
Technical data	33
Ratings of chopper/resistor combinations	33
Definitions	33
SAFUR resistor data	33
Terminals and cable lead-through data of factory-installed chopper/resistor cubicles	

Selecting and routing the cables of a custom resistor	
Minimizing electromagnetic interference	
Maximum cable length	
Selecting the installation location for the brake resistors	
Protecting the brake system against thermal overload	
Thermal protection of the resistors	
Protecting the resistor cable against short-circuits	
Mechanical installation of custom brake resistors .	
Electrical installation of custom brake resistors	
Connection diagram	
Connection procedure	
Brake system start-up	
Maintenance	
Replacing the brake resistor cabinet fan	

Further information

Safety instructions

Contents of this chapter

This chapter contains the safety instructions which you must obey when you ins start-up, operate and do maintenance work on the drive. If you ignore the safety instructions, injury, death or damage can occur.

Use of warnings and notes

Warnings tell you about conditions which can cause injury or death, or damage to the equipment. They also tell you how to prevent the danger. Notes draw attention to a particular condition or fact, or give information on a subject.

The manual uses these warning symbols:

WARNING!

Electricity warning tells about hazards from electricity which can cause injury or death, or damage to the equipment.

WARNING!

General warning tells about conditions other than those caused by electricity which can cause injury or death, or damage to the equipment.

WARNING!

Electrostatic sensitive devices warning tells you about the risk of electro

General safety in installation, start-up and maintenance

These instructions are for all personnel who do work on the drive.

WARNING!

Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur.

- Keep the drive in its package until you install it. After unpacking, protect the drive from dust, debris and moisture.
 - Use the required personal protective equipment: safety shoes with metal toe cap, safety glasses, protective gloves and long sleeves, etc. Some parts have sharp edges.
 - Lift a heavy drive with a lifting device. Use the designated lifting points. See the dimension drawings.
 - Obey the local laws and regulations applicable to lifting, such as requirements for planning the lifting, for capacity and condition of lifting equipment, and for training of personnel.
 - The lifting bars attached to large drive cabinets are heavy. Be careful when removing or reinstalling the bars. Whenever possible, use a lifting device attached to the designated lifting points.
 - Attach the drive cabinet to the floor to prevent it from falling over. The cabinet has a high center of gravity. When you pull out heavy components or power modules, there is a risk of overturning. Attach the cabinet also to the wall when necessary.
-
- Do not stand or walk on the cabinet roof. Make sure that nothing presses against the roof, side or back plates or door. Do not store anything on the roof while the drive is in operation.
 - Do not use the module extraction/installation ramp with plinth heights which exceeds the maximum allowed height.
 - Secure the module extraction/installation ramp carefully.
 - Push the module into the cabinet and pull it from the cabinet carefully preferably with help from another person. Keep a constant pressure with one foot on the

max.

- Do not move the module on its wheels for long distances. It can cause damage to the wheels. Also, there is a risk of the module falling over.
- Be careful when handling a tall module. The module overturns easily because it is heavy and has a high center of gravity. Whenever possible, secure the module with chains. Do not leave an unsupported module unattended especially on a slippery floor.

- Wear protective gloves and long sleeves! Some parts have sharp edges.
- Beware of hot surfaces. Some parts, such as heatsinks of power semiconductor modules and brake resistors, remain hot for a while after disconnection of the electrical supply.
- Vacuum clean the area around the drive before the start-up to prevent the drive's cooling fan from drawing dust inside the drive.
- Make sure that debris from drilling, cutting and grinding does not go into the drive during installation. Electrically conductive debris inside the drive can cause damage or malfunction.
- Make sure that there is sufficient cooling. See the technical data.

20 Safety instructions

- Before you adjust the drive operation limits, make sure that the motor and all driven equipment can operate throughout the set operation limits.
- Before you activate the automatic fault reset or automatic restart functions of the drive control program, make sure that no dangerous situations can occur. These functions reset the drive automatically and continue operation after a fault or supply break. If these functions are activated, the installation must be clearly marked as defined in IEC/EN/UL 61800-5-1, subclause 6.5.3, for example, "THIS MACHINE STARTS AUTOMATICALLY".
- The maximum number of drive power-ups is five in ten minutes. Too frequent power-ups can damage the charging circuit of the DC capacitors.
- If you have connected safety circuits to the drive (for example, Safe torque off or emergency stop), validate them at start-up. See separate instructions for the safety circuits.
- Beware of hot air exiting from the air outlets.
- Do not cover the air inlet or outlet when the drive is running.

Note:

- If you select an external source for the start command and it is on, the drive will start immediately after fault reset unless you configure the drive for pulse start. See the firmware manual.
- If the drive is in remote control mode, you cannot stop or start the drive with the control panel.
- Only authorized persons are allowed to repair a malfunctioning drive.

Electrical safety in installation, start-up and maintenance

■ Electrical safety precautions

These electrical safety precautions are for all personnel who do work on the drive, motor cable or motor.

WARNING!

Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur.

If you are not a qualified electrical professional, do not do installation or maintenance work.

Do these steps before you begin any installation or maintenance work.

1. Prepare for the work.
 - Make sure that you have a work order.
 - Do an on-site risk assessment or job hazard analysis.
 - Make sure that you have the correct tools available.
 - Make sure that the workers are qualified.
 - Select the correct personal protective equipment (PPE).
 - Stop the motor(s).
2. Clearly identify the work location and equipment.
3. Disconnect all possible voltage sources. Make sure that re-connection is not possible. Lock out and tag out.
 - Open the main disconnecting device of the drive.
 - Open the charging switch if present.
 - Open the disconnecter of the supply transformer. (The main disconnecting device in the drive cabinet does not disconnect the voltage from the AC input power busbars of the drive cabinet.)
 - Close the grounding switch or switches ([Q9], option +F259) if present. Do not use excessive force as the switch has electromagnetic interlocking.
 - Open the auxiliary voltage switch-disconnector (if present), and all other possible disconnecting devices that isolate the drive from dangerous voltage sources.
 - If you have a permanent magnet motor connected to the drive, disconnect the motor from the drive with a safety switch or by other means.
 - Open the main isolating device of the drive.
 - Disconnect all dangerous external voltages from the control circuits.
 - After you disconnect power from the drive, always wait 5 minutes to let the intermediate circuit capacitors discharge before you continue.
4. Protect other energized parts in the work location against contact and take special precautions when close to bare conductors.
5. Measure that the installation is de-energized. Use a quality voltage tester. If the measurement requires removal or disassembly of shrouding or other cabinet structures, obey the local laws and regulations applicable to live working (including

22 Safety instructions

- Make sure that the voltage between the drive output terminals (T1/U, T2/V, T3/W) and the grounding (PE) busbar is zero.
Important! Repeat the measurement also with the DC voltage setting of the tester. Measure between each phase and ground. There is a risk of dangerous DC voltage charging due to leakage capacitances of the motor circuit. This voltage can remain charged for a long time after the drive power-off. The measurement discharges the voltage.
- Make sure that the voltage between the drive DC busbars and the grounding (PE) busbar is zero.

6. Install temporary grounding as required by the local regulations.
7. Ask for a permit to work from the person in control of the electrical installation work.

■ Additional instructions and notes

WARNING!

Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur.

If you are not a qualified electrical professional, do not do installation or maintenance work.

- Keep the cabinet doors closed when the drive is powered. With the doors open, a risk of a potentially fatal electric shock, arc flash or high-energy arc blast exists.
- Make sure that the electrical power network, motor/generator, and environmental conditions agree with the drive data.
- Do not do insulation or voltage withstand tests on the drive.
- If you have a cardiac pacemaker or other electronic medical device, keep away from the area near motor, drive, and the drive power cabling when the drive is in operation. There are electromagnetic fields present which can interfere with the function of such devices. This can cause a health hazard.
- ABB does not recommend attaching the cabinet by arc welding. If you have to, obey the welding instructions in the drive manuals.

Note:

- When the drive is connected to the input power, the motor cable terminals and the DC bus are at a dangerous voltage.
The brake circuit, including the brake chopper (option +D150) and brake resistor (option +D151) are also at a dangerous voltage.
After disconnecting the drive from the input power, these remain at a dangerous voltage until the intermediate circuit capacitors have discharged.
- External wiring can supply dangerous voltages to the relay outputs of the control units of the drive.
- The Safe torque off function does not remove the voltage from the main and

Printed circuit boards

WARNING!

Use a grounding wristband when you handle printed circuit boards. Do not touch the boards unnecessarily. The boards contain components sensitive to electrostatic discharge.

■ Grounding

These instructions are for all personnel who are responsible for the grounding of the drive.

WARNING!

Obey these instructions. If you ignore them, injury or death, or equipment malfunction can occur, and electromagnetic interference can increase.

If you are not a qualified electrical professional, do not do grounding work.

- Always ground the drive, the motor and adjoining equipment. This is necessary for the personnel safety.
- Make sure that the conductivity of the protective earth (PE) conductors is sufficient and that other requirements are met. See the electrical planning instructions for the drive. Obey the applicable national and local regulations.
- When using shielded cables, make a 360° grounding of the cable shields at the cable entries to reduce electromagnetic emission and interference.
- In a multiple-drive installation, connect each drive separately to the protective earth (PE) busbar of the power supply.

General safety in operation

These instructions are for all personnel that operate the drive.

WARNING!

Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur.

- Keep the cabinet doors closed when the drive is powered. With the doors open, a risk of a potentially fatal electric shock, arc flash or high-energy arc blast exists.
- If you have a cardiac pacemaker or other electronic medical device, keep away from the area near motor, drive, and the drive power cabling when the drive is in operation. There are electromagnetic fields present which can interfere with the function of such devices. This can cause a health hazard.
- Give a stop command to the drive before you reset a fault. If you have an external source for the start command and the start is on, the drive will start immediately after the fault reset, unless you configure the drive for pulse start. See the firmware manual.
- Before you activate the automatic fault reset or automatic restart functions of the drive control program, make sure that no dangerous situations can occur. These functions reset the drive automatically and continue operation after a fault or supply break. If these functions are activated, the installation must be clearly marked as defined in IEC/EN/UL 61800-5-1, subclause 6.5.3, for example, "THIS MACHINE STARTS AUTOMATICALLY".

Note:

- The maximum number of drive power-ups is five in ten minutes. Too frequent power-ups can damage the charging circuit of the DC capacitors. If you need to start or stop the drive, use the control panel keys or commands through the I/O terminals of the drive.
- If the drive is in remote control mode, you cannot stop or start the drive with the control panel.

Additional instructions for permanent magnet motor drives

■ **Safety in installation, start-up, maintenance**

These are additional warnings concerning permanent magnet motor drives. The other safety instructions in this chapter are also valid.

WARNING!

Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur.

Before installation, start-up and maintenance work on the drive:

- Stop the drive.
- Disconnect the motor from the drive with a safety switch or by other means.
- If you cannot disconnect the motor, make sure that the motor cannot rotate during work. Make sure that no other system, like hydraulic crawling drives, can rotate the motor directly or through any mechanical connection like belt, nip, rope.
- Do the steps in section [Electrical safety precautions \(page 21\)](#).
- Install temporary grounding to the drive output terminals (T1/U, T2/V, T3/W). Connect the output terminals together as well as to the PE.

During the start-up:

- Make sure that the motor cannot run overspeed, for example, driven by the load. Motor overspeed causes overvoltage that can damage or destroy the capacitors in the intermediate circuit of the drive.

■ Safety in operation

WARNING!

Make sure that the motor cannot run overspeed, for example, driven by the load. Motor overspeed causes overvoltage that can damage or destroy capacitors in the intermediate circuit of the drive.

Introduction to the manual

Contents of this chapter

This chapter describes the manual. It contains a flowchart of steps in checking delivery, installing and starting up the drive. The flowchart refers to chapters/symbols in this manual and to other manuals.

Target audience

This manual is intended for people who plan the installation, install, commission, do maintenance work on the drive, or create instructions for the end user of the drive concerning the installation and maintenance of the drive.

Read the manual before you work on the drive. You are expected to know the fundamentals of electricity, wiring, electrical components and electrical symbols.

Categorization by frame size and option code

The frame size identifies information which concerns only a certain frame size drive. The frame size is shown on the type designation label. All frame sizes are listed in the technical data.

Use of component designations

Some device names in the manual include the component designation in brackets (for example, [Q20]). This will help you to identify the components in the circuit diagrams of the drive.

Quick installation, commissioning and operation flowchart

Task	See
Plan the electrical installation and acquire the accessories needed (cables, fuses, etc.). Check the ratings, required cooling air flow, input power connection, compatibility of the motor, motor connection, and other technical data.	Guidelines for planning the electrical installation (page 89) Technical data (page 223)
Check the installation site.	Ambient conditions (page 239)
Unpack and check the drive (only intact units may be started up). Make sure that all necessary optional modules and equipment are present and correct. Install the drive mechanically.	Mechanical installation (page 67)
Route the cables.	Routing the cables (page 105)
If the drive is about to be connected to an IT (ungrounded) system, check that the drive is not equipped with EMC filter +E202.	Compatibility check - IT (ungrounded earthing system (page 116)
Connect the power cables. Connect the control cables.	Electrical installation (page 115)
Check the installation.	Installation checklist (page 171) If the drive has been non-operational more than one year, reform the DC link capacitors. See Converter module capacitor reforming instructions (3BFE64059629 [English]) .

Terms and abbreviations

Term	Description
ATEX	Directives 2014/34/EU and 1999/92/EC are commonly referred to as directives (from "Atmosphères Explosibles")
BCU	Type of control unit
CMF	Common mode filtering
Drive	Frequency converter for controlling AC motors
EMC	Electromagnetic compatibility
EMI	Electromagnetic interference
FAIO-01	Analog I/O extension module
FEN-01	Optional TTL incremental encoder interface module
FEN-11	Optional absolute encoder interface module
FEN-21	Optional resolver interface module
FEN-31	Optional HTL incremental encoder interface module
FIO-11	Optional analog I/O extension module
FPTC-01	Optional thermistor protection module
FPTC-02	Optional ATEX-certified thermistor protection module for potentially explosive atmospheres
Frame, frame size	Physical size of the drive or power module
FSO-12, FSO-21	Optional functional safety modules
IGBT	Insulated gate bipolar transistor
Inverter unit	Inverter module(s) under control of one control unit, and related components. One inverter unit typically controls one motor.
Power module	Common term for drive module, inverter module, supply module, chopper module etc.
RFI	Radio-frequency interference
STO	Safe torque off (IEC/EN 61800-5-2)
Supply unit	Supply module(s) under control of one control unit, and related components.
UCU	Type of control unit
USCA-02	Adapter for installing F-series option modules onto the UCU connector

Related documents

You can find manuals on the Internet. See below for the relevant code/link. For further documentation, go to www.abb.com/drives/documents.

Operation principle and hardware description

Contents of this chapter

This chapter briefly describes the operation principle and construction of the drive.


Operation principle

The ACS880-07 is an air-cooled cabinet-installed drive for controlling asynchronous AC induction motors, permanent magnet synchronous motors, ABB synchronous reluctance (SynRM) motors and AC induction servomotors.

The drive consists of several cubicles that contain the supply and motor terminals, 2 to 4 diode supply module(s), 2 to 5 inverter modules, and optional equipment. The actual arrangement of the cubicles varies from type to type and the selected options.

32 Operation principle and hardware description

■ Overview circuit diagram of the drive



1 *Main switch-disconnector (Q1.1)

2 *AC fuses.

Frames 1×D8T + 2×R8i (6-pulse), 2×D7T + 2×R8i (12-pulse), 2×D8T + n×R8i(12-pulse) have AC fuses installed in the incoming cubicle (ICU) only. Frames 2×D8T + 2×R8i and above (6-pulse) and 4×D8T + n×R8i (12-pulse) have AC fuses installed for each supply module in the supply module cubicle(s). Additional common AC fuses are installed in the incoming cubicle (ICU) if optional main contactor (+F250) is present.

3 *Main contactor (Q2.1). Optional (+F250) with frames 2×D7T + 2×R8i, 2×D8T + 2×R8i and 2×D8T + 3×R8i. 12-pulse units have two contactors (Q2.1 and Q2.2).

*With larger units, an air circuit breaker is either optional (+F255) or standard, replacing items 1...3. Each supply module has dedicated AC fuses installed in the supply module cubicle(s).

4 Supply module. Converts alternating current and voltage to direct current and voltage. The module contains an AC input choke.

The ACS880-07 has 1...4 supply modules connected in parallel. 12-pulse units have either one or two supply modules per each 6-pulse supply line.

5 DC bus

6 Inverter DC fuses

7 Inverter module. Converts direct current and voltage to alternating current and voltage. The ACS880-07 has 2...5 inverter modules connected in parallel.

8 Motor

- 13 Auxiliary voltage transformers (T21, T101, T111). T21 is standard; T101 and T111 are whenever required by the options ordered.

12-pulse connection (option +A004)

The figure below illustrates the difference between 6-pulse and 12-pulse AC supply connections. 6-pulse connection is standard.

Some drive types are available as a 12-pulse version (option +A004).

The 12-pulse supply connection eliminates the fifth and seventh harmonics, which substantially reduces the harmonic distortion of the line current and the electromagnetic emissions.


The 12-pulse connection requires a three-winding transformer, or two separate transformers. There is a phase shift of 30-degrees between the two 6-pulse supply lines, which are connected to different supply modules through electrically isolated switching equipment.

A

B


Cabinet line-up and layout examples

■ Frame 1×D8T+2×R8i



Cabinet line-up example

- A Auxiliary control cubicle (ACU). Contains control electronics and customer I/O connections. See section [Auxiliary control cubicle \(ACU\) layout \(page 42\)](#).
- B Incoming cubicle (ICU). Contains the power input cable terminals and switchgear.
- C Supply module cubicle. Contains the D8T supply module.
- D Inverter module cubicle. Contains two R8i inverter modules. As standard, the motor cables are



Cabinet layout example

- A Auxiliary control cubicle (ACU). See section [Auxiliary control cubicle \(ACU\) layout](#)
- 1 Input cable lead-throughs, PE busbar
- 2 Input terminals
- 3 Main switch-disconnector (Q1.1)
- 4 Grounding (earthing) switch (Q9.1) (optional)
- 5 AC fuses
- 6 Main contactor (Q2.1) (optional)
- 7 Auxiliary voltage switch (Q21) with fuses
- 8 Incoming cubicle cooling fan


36 Operation principle and hardware description

■ **Frame 2×D7T+2×R8i (12-pulse connection, option +A004)**



Cabinet line-up example

- A Auxiliary control cubicle (ACU). Contains control electronics and customer I/O connections. See section [Auxiliary control cubicle \(ACU\) layout \(page 42\)](#).
- B Incoming cubicle (ICU). Contains the power input cable terminals and switchgear. With option +F259 (grounding switch), there are two incoming cubicles, one for each 6-pulse supply line.
- C Supply module cubicle. Contains two D7T supply modules, each connected to a different 6-pulse supply line.
- D Inverter module cubicle. Contains two R8i inverter modules. As standard, the motor cables are run from each inverter module to the motor unless the drive is equipped with option +H359 (common motor terminal cubicle), +H366 (common output terminals) or +E206 (sine filters).
- 1 Main switch-disconnector (Q1.1)




Cabinet layout example

- A Auxiliary control cubicle (ACU). See section [Auxiliary control cubicle \(ACU\) layout](#)
- 1 Input cable lead-throughs, PE busbar
- 2 Input terminals
- 3 Main switch-disconnector (Q1.1)
- 4 AC fuses
- 5 Main contactors (Q2.1 and Q2.2) (optional)
- 6 Auxiliary voltage switch (Q21) with fuses
- 7 Incoming cubicle cooling fans
- 8 Supply modules. Each module is connected to a different 6-pulse supply line.
- 9 Inverter DC fuses
- 10 Inverter modules. The output terminals are located behind each module. Each module can be individually connected to the motor using separate cables unless the drive is equipped with a common output cable.

38 Operation principle and hardware description


■ **Frame 2×D8T+3×R8i**



Cabinet line-up example

- A Auxiliary control cubicle (ACU). Contains control electronics and customer I/O connections. See section [Auxiliary control cubicle \(ACU\) layout \(page 42\)](#).
- B Incoming cubicle (ICU). Contains the power input cable terminals and switchgear.
- C Supply module cubicle. Contains two D8T supply modules.
- D Inverter module cubicle. Contains three R8i inverter modules. As standard, the motor cables are run from each inverter module to the motor unless the drive is equipped with option +H359 (common motor terminal cubicle) or +H366 (common output terminals).
- 1 Main switch-disconnector (Q1.1)
- 2 Auxiliary voltage switch (Q21)
- 3 Drive control panel. See section [Control panel \(page 50\)](#).
- 4 Door switches and lights. See section [Door devices \(page 48\)](#).

Operation principle and hardware




Cabinet layout example

A	Auxiliary control cubicle (ACU). See section Auxiliary control cubicle (ACU) layout
1	Input cable lead-throughs, PE busbar
2	Input terminals
3	Main switch-disconnector (Q1.1)
4	Grounding (earthing) switch (Q9.1) (optional)
5	Common AC fuses (installed with optional main contactor)
6	Main contactor (Q2.1) (optional)
7	Auxiliary voltage switch (Q21) with fuses
8	Incoming cubicle cooling fans
9	Supply module AC fuses
10	Supply modules
11	Inverter DC fuses
12	Inverter modules. The output terminals are located behind each module. Each module can be individually connected to the motor using separate cables unless the drive is equipped with option +H359 (common motor terminal cubicle) or +H366 (common output terminal cubicle)

40 Operation principle and hardware description


■ **Frame 3×D8T+4×R8i (with main breaker, option +F255)**



Cabinet line-up example

- A Auxiliary control cubicle (ACU). Contains control electronics and customer I/O connections. See section [Auxiliary control cubicle \(ACU\) layout \(page 42\)](#).
- B Incoming cubicle (ICU). Contains the power input cable terminals and switchgear.
- C Supply module cubicle. Contains three D8T supply modules.
- D, E Inverter module cubicles 1 and 2. Each cubicle contains two R8i inverter modules. As standard, the motor cables are run from each inverter module to the motor unless the drive is equipped with option +H359 (common motor terminal cubicle) or +H366 (common output terminals).
- 1 Main breaker (Q1) (option +F255)
- 2 Auxiliary voltage switch (Q21)
- 3 Drive control panel. See section [Control panel \(page 50\)](#).
- 4 Door switches and lights. See section [Door devices \(page 48\)](#).

A




Cabinet layout example

A	Auxiliary control cubicle (ACU). See section Auxiliary control cubicle (ACU) layout
1	Input cable lead-throughs, PE busbar
2	Input terminals
3	Incoming cubicle cooling fans
4	Main breaker (Q1) (option +F255)
5	Auxiliary voltage switch (Q21) with fuses
6	Grounding (earthing) switch (Q9.1) (optional)
7	Supply module AC fuses
8	Supply modules
9	Inverter DC fuses
10	Inverter modules. The output terminals are located behind each module. Each module can be individually connected to the motor using separate cables unless the drive is equipped with option +H359 (common motor terminal cubicle) or +H366 (common output terminal cubicle).

■ Auxiliary control cubicle (ACU) layout

A layout example of the auxiliary control cubicle (ACU) is shown below. On the left: Swing-out frame closed, detachable mounting plates in place. On the right: Swing-out frame open, without detachable mounting plates.



- 1

Fuse-disconnectors F101. On the primary of transformer T101 (item 27).
- 1

Fuse-disconnectors (F27) for motor cooling fan outputs (options +M602-610).
- 2

Supply control unit (A51). See chapter 40.
- 2

Fuse-disconnectors (F27) for motor cooling fan outputs (options +M602-610).
- 2

Fuse-disconnectors (F27) for motor cooling fan outputs (options +M602-610).
- 3

Supply control unit (A51). See chapter 40.
- 19

Lead-through for control cables
- 19

Lead-through for control cables
- 20

Terminal block (X68) for FSO-xx safety function module (option +Q972 or +Q973).
- 20

Terminal block (X68) for FSO-xx safety function module (option +Q972 or +Q973).
- 21

I/O terminal block (option +L504). The I/O of the input and control unit is connected to the I/O of the input and control unit.
- 21


I/O terminal block (option +L504). The I/O of the input and control unit is connected to the I/O of the input and control unit.

Operation principle and hardware

6	Switch (F90) for ground fault monitoring (item 12)	24	Motor fan starters and control (options +M602...610)
7	FSO-xx safety functions module (option +Q972 or +Q973 and other options requiring FSO-xx)	25	Terminal blocks (X601) for motor fan starters (options +M602...610)
8	Temperature monitoring relays (options +L505 and +L506). The terminals (X506) are located on the back of the detachable mounting plate.	26	24 V DC power supply for motor fan starters (option +G301)
9	Swing-out frame	27	Auxiliary voltage transformer for motor fan starters (located on the back of the cubicle, not visible). IP54, brake chopper and line reactor cooling fans (options +D150 and +D151).
10	Mounting rail for additional equipment	28	Auxiliary voltage transformer for control circuitry and the cooling fan (located on the back of the cubicle, not visible). Secondary for incoming unit (ICU) and the control unit (ACU).
11	Safety relays for safety options (emergency stop, safe torque off)	29	Auxiliary voltage transformer for safety options (emergency stop, safe torque off).
12	Ground fault monitoring equipment for ungrounded systems (option +Q954)	30	Auxiliary voltage circuit breaker (F102). On the secondary of transformer T101 (item 27) and T101 (item 27).
13	FEA-03 extension adapter (option +L515).	31	Input voltage setting for auxiliary voltage transformer T101 (item 27).
14	Switch and circuit breaker for externally-supplied motor space heater (option +G313). The terminals (X313) are located on the back of the detachable mounting plate.	32	Input voltage setting for auxiliary voltage transformer T21 (item 28).
15	Switch and circuit breaker for externally-supplied control voltage (option +G307), eg. UPS. The terminals (X307) are located on the back of the detachable mounting plate.	33	Input voltage setting for auxiliary voltage transformer T111 (item 29).
16	Switch and circuit breaker for externally-supplied cabinet lighting and heating (options +G300 and +G301). The terminals (X300) are located on the back of the detachable mounting plate.	34	Terminal blocks X250: indication of main switch and contactor status X951: connection of external emergency stop button X954: ground fault alarm indicator X957: for connection of Prospekt start-up switch. Mounted on the left-hand side of the cubicle.
17	Fuse-disconnectors F21. On the primary of transformer T21 (item 28). Mounted on a detachable plate.	35	Cubicle heater element (option +H301). Mounted on the right-hand side of the cubicle.

Overview of power and control connections (BCU-x2)

The diagram shows the power connections and control interfaces of the drive.



- A Drive
- B Supply control unit (A51)
- C Inverter control unit (A41)
- 1 Option modules can be inserted into slots 1, 2, 3 and 4 as follows:


2	Module type	Slots
	Analog and digital I/O extension modules	1, 2, 3

Operation principle and hardware

- 5 Control panel and PC connection
- 6 Terminal blocks on the inverter control unit. These terminals are optionally wired to block X504 in the auxiliary control cabinet of the drive.
- 7 Fiber optic link to each inverter module. Similarly, each supply module is connected to the supply control unit by fiber optic cables.
- 8 Terminal blocks for customer connections installed in the drive cabinet. For the layout, see section [Auxiliary control cubicle \(ACU\) layout \(page 42\)](#).
- 9 Supply unit (consisting of one or more supply modules)
- 10 DC intermediate link
- 11 Inverter unit (consisting of two or more inverter modules)
- 12 Optional brake chopper (+D150) and resistors (+D151)

Overview of power and control connections (UCU-22...24)

The diagram shows the power connections and control interfaces of the drive.



- A Drive
- B Supply control unit (A51)
- C Inverter control unit (A41)
- 1 Option modules can be inserted into slots 1, 2, 3 and 4 as follows:

2	Module type	Slots
	Analog and digital I/O extension modules	1, 2, 3

Operation principle and hardware

- 5 Control panel and PC connection
- 6 Ethernet ports for fieldbus communication (XETH 1...2) and tool communication
Not in use.
- 7 Terminal blocks on the inverter control unit. These terminals are optionally wired to block X504 in the auxiliary control cabinet of the drive.
- 8 Fiber optic link to each inverter module. Similarly, each supply module is connected to the supply control unit by fiber optic cables.
- 9 Terminal blocks for customer connections installed in the drive cabinet. For the layout see section [Auxiliary control cubicle \(ACU\) layout \(page 42\)](#).
- 10 Supply unit (consisting of one or more supply modules)
- 11 DC intermediate link
- 12 Inverter unit (consisting of two or more inverter modules)
- 13 Optional brake chopper (+D150) and resistors (+D151)

Door devices

	Label in English	Label in local language	Description
1	READY	-	Ready light (option +G327)
2	RUN	-	Run light (option +G328)
3	FAULT	-	Fault light (option +G329)
4	ENABLE / RUN 0-1	-	Run enable signal switch for the supply unit <div><div>0</div>Run enable signal off (starting the supply unit not allowed)</div> <div><div>1</div>Run enable signal on (starting the supply unit allowed). Close the main disconnecting device (if present).</div>
5	E-STOP RESET	-	Emergency stop reset push button (with emergency stop options only)
6	EARTH FAULT	-	Ground (earth) fault light and reset push button (option +Q954)
7			Reserved for order based engineered equipment

■ **Main disconnecting device (Q1.1)**

Depending on the configuration of the drive, the main disconnecting device of the drive is either a switch-disconnector or a main circuit breaker. Units with a switch-disconnector also have a main contactor.

The main disconnecting device switches the main supply to the drive on and disconnect the main supply, turn the switch-disconnector to the 0 (OFF) position or rack out the main breaker (whichever device is installed).

WARNING!

The main disconnecting device does not isolate the input power terminals, AC voltage meters, or the auxiliary voltage circuit from the power line. To disconnect the auxiliary voltage circuit, open the auxiliary voltage switch (Q21). To disconnect the input power terminals and AC voltage meters, open the main breaker or the supply transformer.

To close the main disconnecting device, auxiliary voltage must be switched on and the grounding switch (if present) must be open.

■ **Auxiliary voltage switch [Q21]**

The auxiliary voltage switch controls the supply to the internal auxiliary voltage transformers. The transformer feeds the control circuits inside the drive such as cooling fans, relays and measuring equipment.

■ **Grounding (earthing) switch [Q9], optional**

The grounding switch [Q9] (option +F259) connects the main AC power bus to the grounding busbar. Units with 12-pulse connection (option +A004), as well some of the larger 6-pulse types, have two switches, [Q9.1] and [Q9.2], one for each 6-pulse supply.

To close the grounding switch, auxiliary voltage must be switched on, and the main disconnecting device must be open.

WARNING!

The grounding switch does not ground the input power terminals of the drive or the auxiliary (control) voltage circuits.

■ **Other devices on the door**

- Voltmeter (option +G334); comes with a phase selector switch.

Note: The voltage is measured on the supply side of the main switch or breaker.

- AC current meter (option +G335) on one phase.

50 Operation principle and hardware description

■ Control panel

The ACS-AP-W is the user interface of the drive. It provides the essential controls such as Start/Stop/Direction/Reset/Reference, and the parameter settings for the inverter control program.

The control panel can be removed by pulling it forward by the top edge and reinstalled in reverse order. For the use of the control panel, see [ACS-AP-I, -S, -W and ACH-AP-W Assistant control panels user's manual \(3AUA0000085685 \[English\]\)](#) and the firmware manual.

Control by PC tools

There is a USB connector on the front of the panel that can be used to connect a PC to the drive. When a PC is connected to the control panel, the control panel keypad is disabled.

Descriptions of options

Note: All options are not available for all drive types, are not compatible with other options, or require additional engineering.

■ Degree of protection

Definitions

According to IEC/EN 60529, the degree of protection is indicated by an IP code. The first numeral means protection against ingress of solid foreign objects and the second numeral protection against ingress of water. The IP codes of the standard cabinet and options covered in this manual are defined below.

IP code	The equipment is protected ...	
	First numeral	Second numeral
IP22	against ingress of solid foreign objects > 12.5 mm diameter *	against dripping (15° tilting)
IP42	against ingress of solid foreign objects > 1 mm	against dripping (15° tilting)
IP54	dust-protected	against splashing water

* meaning for protection of persons: against access to hazardous parts with tools

IP22 (UL Type 1)

The degree of protection of the standard drive cabinet is IP22 (UL type 1). The air inlets at the top of the cabinet and the air inlet gratings are covered with metallic mesh gratings. With doors open, the degree of protection of the standard cabinet and cabinet options is IP20. The live parts inside the cabinet are protected against access with clear plastic shrouds or metallic gratings.

IP42 (UL Type 1 Filtered) (option +B054)

This option provides the degree of protection of IP42 (UL type 1). The air inlets are covered with a metallic mesh between the inner and outer metallic gratings.

IP54 (UL Type 12) (option +B055)

This option provides the degree of protection of IP54 (UL type 12). It provides cabinet air inlets with filter housings containing folded board air filter mats between the inner and outer metallic gratings. An additional fan and filtered outlets on cabinet roof are also included.

■ Marine construction (option +C121)

The option includes the following accessories and features by default:

52 Operation principle and hardware description

Marine product certifications may require additional wire markings. Refer to section [Wire markings \(page 54\)](#).

■ **Cooling air inlet through bottom of cabinet (option +C128)**

See section [Air inlet through the bottom of the cabinet \(option +C128\) \(page 8](#)

■ **UL Listed (option +C129)**

The cabinet contains the following accessories and features:

- top entry and exit with US cable conduit entries (plain plate without ready-made holes)
- all components UL/CSA Listed/Recognized
- maximum supply voltage 600 V
- US-type main switch and fuses.

■ **Channeled air outlet (option +C130)**

This option provides a collar for connection to an air outlet duct. The collar is located on the cabinet roof. Depending on the equipment installed in each cubicle, the channeled air outlet either replaces, or adds to, the standard roof arrangement.

With option +B055, this option also provides the cabinet air inlets with filter housings containing folded board air filter mats between the inner and outer metallic gratings.

See also section [Air outlet duct on the cabinet roof \(option +C130\) \(page 83\)](#).

■ **CSA Approved (option +C134)**

The option includes the following accessories and features:

- bottom entry and exit of cables with US cable conduit entry (plain plate without ready-made holes)
- all components UL/CSA listed/recognized
- maximum supply voltage 600 V
- main (air circuit) breaker when available for the particular drive type.

■ **Plinth height (options +C164 and +C179)**

The standard height of the cabinet plinth is 50 mm. These options specify a plinth height of 100 mm (+C164) or 200 mm (+C179).

■ **Seismic design (option +C180)**

The option involves seismic capability according to International building code 2012, test procedure ICC-ES AC-156. The installation level must not exceed 25% of the height

■ **Empty cubicles on left (options +C199...C201)**

The option adds an empty 400, 600 or 800 mm wide cubicle to the left end of the line-up. The cubicle is equipped with blank power cable entries both at the top and the bottom.

The cubicle is equipped with blank panel entries (full panel or two-half panels) on the back.

■ **Resistor braking (options +D150 and +D151)**

See chapter [Resistor braking \(page 333\)](#).

■ **EMC filter (option +E202)**

EMC filter for 1st Environment (category C2) for TN (grounded) system.

■ **Sine filter (option +E206)**

A sine filter provides true sinusoidal voltage waveform at the drive output by suppressing the high-frequency voltage components of the output. These high-frequency components cause stress to motor insulation as well as to transformer saturation (if present).

The sine filter option consists of three single-phase reactors and delta-connected capacitors at the output of the drive. The filter is fitted in a separate cubicle and has a dedicated cooling fan.

■ **Cabinet heater with external supply (option +G300)**

The option contains:

- heating elements in the cubicles or supply/inverter modules
- load switch for providing electrical isolation during service
- miniature circuit breaker for overcurrent protection
- terminal block for external power supply.

The heater prevents condensation inside the cabinet when the drive is not in operation. The power output of the heating elements increases when the surrounding air temperature is low and decreases when the surrounding air temperature is high. The customer must stop the heating when it is not needed by disconnecting the heater supply voltage.

The customer must supply the heater from an external 110...240 V AC power source.

For the actual wiring, see the circuit diagrams delivered with drive.

■ **Cabinet lighting (option +G301)**

54 Operation principle and hardware description

- [Supplying power for the auxiliary circuits \(page 111\)](#)
- circuit diagrams delivered with drive for the actual wiring.

■ **Output for motor space heater (option +G313)**

The option contains:

- load switch for providing electrical isolation during service
- miniature circuit breaker for overcurrent protection
- terminal block for heater and external heater supply connection.

When the drive is powered (and not faulted), the heater is switched off. Otherwise, the heater is controlled by the external supply voltage.

The power and voltage of the heater depend on the motor.

See also:

- [Supplying power for the auxiliary circuits \(page 111\)](#)
- circuit diagrams delivered with drive for the actual wiring.

■ **Supply connection by busbars (option +G317)**

This option provides input (supply) terminals and a busbar entry that enable direct connection to busbar trunking systems.

■ **Ready/Run/Fault lights (options +G327...G329)**

These options provide "ready" (+G327, white), "run" (+G328, green) and "fault" (+G329, yellow) lights installed on the cabinet door.

■ **Halogen-free wiring and materials (option +G330)**

The option provides halogen-free cable ducts, control wires and wire sleeves, thus reducing toxic fire gases.

■ **V-meter with selector switch (option +G334)**

The option contains a voltmeter and a selector switch on the cabinet door. The switch selects the two input phases across which the voltage is measured.

■ **Wire markings**

Standard wiring

Color

The standard color of the wiring is black, with the following exceptions:

- Main circuit terminals: Connector identifier (eg. "U1") marked on terminal block with insulating material close to the terminal. Input and output main circuit cables are not marked.
- Plug-in connectors of wire sets (except those that require special tools to disconnect) are labeled with connector designation (eg. "X1"). The marking is placed either directly on the connector, or near the connector on printed sleeving.
- Grounding busbars are marked with stickers.
- Fiber optic cable pairs and data cables have component designation and cable designations (eg. "A1:V1", "A1:X1") marked with rings or tape.
- Data cables are marked with tape.
- Ribbon cables are marked with either labels or tape.
- Customer-specific (engineered) wiring (option +P902) is not marked.

Additional wire markings

The following additional wire markings are available.

Option	Additional markings
+G340 (class A3)	Single wires not attached to plug-in connectors are marked with component pin numbers on snap-on or ring markers. Plug-in connectors are marked with an identification label placed on the wires near the connector (individual wires are not marked). Short, obvious connections are not marked. PE wires are not marked unless connected directly to components.

9.7 7

+G342 (class C1)	Single wires connected to components, between modules, or to terminal blocks are marked with component identification and pin numbers for both ends. The marking is printed on sleeving or, if necessary, snap-on markers. Plug-in connectors are marked with an identification label (or snap-on markers) placed on the wires near the connector (individual wires are not marked). Short, obvious connections are not marked. PE wires are not marked unless connected directly to components.
---------------------	--

K 1 2 4 T 2 3 T 2

K1 24 T2 3 T 2

■ Common mode filter temperature monitoring (option +G400)

This option contains thermal switches installed within the common mode filter.

56 Operation principle and hardware description

provide power and control cable entries at the floor of the cabinet. The entries are equipped with grommets and 360° grounding hardware.

For non-UL Listed units, bottom entry/exit is the default cabling arrangement.

■ **Top cable entry/exit (options +H351 and +H353)**

The top entry (+H351) and top exit (+H353) options provide power and control cable entries at the roof of the cabinet. The entries are equipped with grommets and 360° grounding hardware.

■ **Cable conduit entry (option +H358)**

The option provides US/UK conduit plates (plain 3 mm thick steel plates without any ready-made holes).

■ **Common motor terminal cubicle (option +H359)**

As standard, each inverter module must be individually cabled to the motor. This option provides an additional cubicle containing a single set of terminals for the motor cables.

The width of the cubicle and the size of the terminals within depend on the power rating of the drive.

Note that this option is not available with option +E206 (sine filters). In this case, the motor cables are connected to the sine filter cubicle.

■ **Common output terminals (option +H366)**

As standard, each inverter module must be individually cabled to the motor. This option adds bridging that connects the outputs of multiple (in practice, two or three) inverter modules mounted in the same cubicle. The bridging balances the motor current between the modules, which allows more cabling options. For example, it is possible to use a number of cables that could not otherwise be evenly distributed between the inverter modules.

WARNING!

The bridging can carry the nominal output of one inverter module. In case of three parallel modules, ensure that the load capacity of the bridging is not exceeded. For example, if the cabling connects to the output busbars at one module only, use the module in the middle.

Note: The +H366 option only interconnects the outputs of inverter modules within the same cubicle, not modules installed in different cubicles. Therefore, when the drive has more than three inverter modules, make sure that the load is distributed evenly between the modules:

■ **Connectivity for wired remote monitoring (option +K496)**

This option provides a gateway to connect the drive to ABB Ability™ via a local Ethernet network. Includes NETA-21 remote monitoring tool and FMBT-21 Modbus/TCP adapter module.

See the appropriate manual for more information.

Manual

NETA-21 remote monitoring tool user's manual

NETA-21 remote monitoring tool installation and start-up guide

FMBT-21 Modbus/TCP adapter module user's manual

FMBT-21 Modbus/TCP adapter module quick installation and start-up guide

■ **Connectivity for wireless remote monitoring (option +K499)**

This option provides a gateway to connect the drive to ABB Ability™ via a wireless network. Includes NETA-21 remote monitoring tool, FMBT-21 Modbus/TCP adapter module and modem.

See the appropriate manual for more information.

Manual

NETA-21 remote monitoring tool user's manual

NETA-21 remote monitoring tool installation and start-up guide

FMBT-21 Modbus/TCP adapter module user's manual

FMBT-21 Modbus/TCP adapter module quick installation and start-up guide

InRouter 615-S commissioning guide

■ **Additional terminal block X504 (option +L504)**

The standard terminal blocks of the drive control unit are wired to the additional terminal block at the factory for customer control wiring. The terminals are not preloaded.

Note: The optional modules inserted in the slots of the control unit are not wired to the additional terminal block. The customer must connect the optional module wires directly to the modules.

Cables accepted by the terminals of the additional I/O terminal block:

- solid wire 0.2 ... 2.5 mm² (24...12 AWG)
- stranded wire with ferrule 0.25 ... 2.5 mm² (24 ... 12 AWG)

58 Operation principle and hardware description

+L505, +2L505, +L513, +2L513

Option +L505 provides a thermistor relay and a terminal block. The terminal block has connections for the measuring circuit (one to three PTC sensors in series), an output indication of the relay, and an optional external reset button. The relay can be reset either locally or externally, or the reset circuit can be jumpered for automatic reset.

By default, the thermistor relay is wired internally to digital input DI6 of the drive control unit. The loss of the input is set to trigger an external fault.

The output indication on the terminal block can be wired by the customer, for example, to an external monitoring circuit. See the circuit diagrams delivered with the drive.

Option +L513 is an ATEX-certified thermal protection function that has the same external connectivity as +L505. In addition, +L513 comes with +Q971 (ATEX-certified safe disconnection function) as standard and is wired at the factory to activate the Safe torque off function of the drive in an overtemperature situation. A manual reset for the protection function is required by Ex/ATEX regulations. For more information, see [ATEX-certified motor thermal protection functions for cabinet-built ACS880 drives \(options +L513+Q971 and +L514+Q971\) user's manual \(3AXD50000014979](#) [Eng

Options +2L505 and +2L513 duplicate options +L505 and +L513 respectively, containing the relays and connections for two separate measurement circuits.

+L536, +L537

An alternative to a thermistor relay option is the FPTC-01 (option +L536) or FPTC-02 (option +L537, also requires option +Q971) thermistor protection module. The module mounts onto the inverter control unit, and has reinforced insulation to keep the control unit PELV-compatible. The connectivity of the FPTC-01 and the FPTC-02 is the same, but the FPTC-02 is Type Examined as a protective device within the scope of the European ATEX (and UKEX) Product Directive.

For protection purposes, the FPTC has a "fault" input for the PTC sensor. An overtemperature situation executes the SIL/PL-capable SMT (Safe motor temperature) safety function by activating the Safe torque off function of the drive.

The FPTC also has a "warning" input for the sensor. When the module detects overtemperature through this input, it sends a warning indication to the drive.

For more information and wiring examples, see the module manuals and the circuit diagrams delivered with the drive.

See also

- [firmware manual for parameter settings](#)
- [FPTC-01 thermistor protection module \(option +L536\) for ACS880 drives user's manual \(3AXD50000027750 \[English\]\)](#)
- [FPTC-02 ATEX-certified thermistor protection module, Ex II \(2\) GD \(option](#)

The standard Pt100 relay options include two (+2L506), three (+3L506), five or eight (+8L506) relays.

By default, the relays are wired internally to digital input DI6 of the drive controller. The loss of the input is set to trigger an external fault. The options include a terminal block for sensor connection. The output indication on the terminal block can be configured by the customer, for example, to an external monitoring circuit. See the circuit diagrams delivered with the drive.

Options +3L514 (3 relays), +5L514 (5 relays) and +8L514 (8 relays) are ATEX-certified thermal protection functions that have the same external connectivity as the standard relays. In addition, each monitoring relay has a 0/4...20 mA output that is available on the terminal block. Option +nL514 comes with +Q971 (ATEX-certified safe digital output function) as standard and is wired at the factory to activate the Safe torque off function of the drive in an overtemperature situation. As the monitoring relay does not have a reset functionality, the manual reset required by Ex/ATEX regulations must be implemented using drive parameters. For more information, see [ATEX-certified thermal protection functions for cabinet-built ACS880 drives \(options +L514 and +L514+Q971\) user's manual \(3AXD50000014979 \[English\]\)](#).

See also

- firmware manual for parameter settings
- [ATEX-certified motor thermal protection functions for cabinet-built ACS880 drives \(options +L513+Q971 and +L514+Q971\) user's manual \(3AXD50000014979 \[English\]\)](#)
- Pt100 relay alarm and trip limit setting instructions in the start-up instructions
- circuit diagrams delivered with the drive for the actual wiring.

■ Starter for auxiliary motor fan (options +M600...M610)

What the option contains

The option provides switched and protected connections for 3-phase auxiliary motor fans. Each fan connection is equipped with:

- fuses
- a manual motor starter switch with an adjustable current limit
- a contactor controlled by the drive, and
- terminal block X601 for customer connections.


Description

The output for the auxiliary fan is wired from the 3-phase supply voltage to terminal block X601 through a motor starter switch and a contactor. The contactor is controlled by the drive. The 230 V AC control circuit is wired through a jumper on the terminal

Type designation label

The type designation label includes ratings, appropriate markings, a type designation and a serial number, which allow the identification of each unit. A sample label is shown below.

Quote the complete type designation and serial number when contacting technical support.



- 1 Type designation (see section [Type designation](#) key)
- 2 Frame size
- 3 Short-time withstand current rating (see chapter [Technical data \(page 223\)](#)); degree of protection (see chapter [Technical data \(page 223\)](#))
- 4 Ratings. See also chapter [Technical data \(page 223\)](#).
- 5 Valid markings
- 6 Serial number. The first digit of the serial number refers to the manufacturing plant. The next four digits refer to the unit's manufacturing year and week, respectively. The remaining digits complete the serial number so that there are no two units with the same number.
- 7 Link to product information

Type designation key

The type designation contains information on the specifications and configuration of the drive. The first digits from left express the basic drive type. The optional selections are given thereafter, separated by plus signs, eg, +E202. Codes preceded by a zero (eg. +0J400) indicate the absence of the specified feature. The main selections are described below. Not all selections are available for all types. For more information refer to the ordering instructions available separately on request.

Code	Description
Basic code	
ACS880	Product series
ACS880-07	Default configuration: air-cooled cabinet-installed drive, IP22 (UL type 1), main circuit breaker (and contactor) or breaker, aR fuses, AC input choke, ACS-AP-W assist panel (with Bluetooth), EMC filter (category 3, 2nd Environment), du/dt filters, common mode filtering, standard wire markings, ACS880 primary control program, Safe torque off, coated circuit boards, bottom entry and exit of cables with lead-through-type enclosure, bilingual door device label sticker, USB memory stick containing circuit diagrams, drawings and manuals.
Size	
xxxxx	Refer to the rating tables
Voltage range	
3	380...415 V AC. This is indicated in the type designation label as typical input voltage range (3~ 400 V AC)
5	380...500 V AC. This is indicated in the type designation label as typical input voltage range (3~ 400/480/500 V AC)
7	525...690 V AC. This is indicated in the type designation label as typical input voltage range (3~ 525/600/690 V AC)

■ Option codes

Code	Description
A004	12-pulse supply connection
B054	IP42 (UL Type 1 Filtered)
B055	IP54 (UL Type 12)
C121	Marine construction. See section Marine construction (option +C121) (page 52).
C128	Air inlet through bottom of cabinet. See section Air inlet through the bottom (option +C128) (page 52).
C129	UL Listed (evaluated to both U.S. and Canadian safety requirements). See section UL Listed (option +C129) (page 52).
C130	Channeled air outlet. See section Channeled air outlet (option +C130) (page 52).

62 Operation principle and hardware description

Code	Description	
C200	Empty 600 mm wide cubicle on left. See section +C199...C201 (page 53).	Empty cubicles on left (options)
C201	Empty 800 mm wide cubicle on left. See section +C199...C201 (page 53).	Empty cubicles on left (options)
C205	Marine product certification issued by DNV GL	
C206	Marine product certification issued by the American Bureau of Shipping (ABS)	
C207	Marine product certification issued by Lloyd's Register (LR)	
C209	Marine product certification issued by Bureau Veritas	
C228	Marine product certification issued by China Classification Society (CCS)	
C229	Marine product certification issued by Russian Maritime Register of Shipping (RS)	
D150	Brake choppers	
D151	Brake resistors	
E202	EMC/RFI filter for 1st environment TN (grounded) system, category C2	
E206	Sine output filter	
F250	Main (line) contactor	
F255	Main circuit breaker	
F259	Grounding (earthing) switch	
G300	Cabinet and module heating elements (external supply). See section ternal supply (option +G300) (page 53).	Cabinet heater with
G301	Cabinet lighting. See section Cabinet lighting (option +G301) (page 53).	
G307	Terminals for connecting external control voltage (230 V AC or 115 V AC, eg. UPS). See section Terminals for external control voltage (option +G307) (page 53).	
G313	Output for motor space heater (external supply)	
G317	Supply connection by busbars	
G327	Ready light on door, white	
G328	Run light on door, green	
G329	Fault light on door, yellow	
G330	Halogen-free wiring and materials	
G334	V-meter with selector switch	
G335	A-meter in one phase	
G340	Wire marking class A3. See section Wire markings (page 54).	
G342	Wire marking class C1. See section Wire markings (page 54).	
G453	Common mode filter temperature monitoring. See section monitoring (option +G453) (page 55).	Common mode filter tempera
H350	Power cabling entry from bottom. See section +H352 (page 55).	Bottom cable entry/exit (options +H350 and

Code	Description
H366	Common output terminals (for inverter modules mounted in the same cubicle). Descriptions of options (page 51) .
J425	ACS-AP-I control panel (without Bluetooth)
K451	FDNA-01 DeviceNet™ adapter module
K454	FPBA-01 PROFIBUS DP® adapter module
K457	FCAN-01 CANopen® adapter module
K458	FSCA-01 RS-485 (Modbus/RTU) adapter module
K462	FCNA-01 ControlNet™ adapter module
K469	FECA-01 EtherCAT® adapter module
K470	FEPL-02 Ethernet POWERLINK adapter module
K475	FENA-21 Ethernet adapter module for EtherNet/IP™, Modbus TCP and PROFINET 2-port
K490	FEIP-21 Ethernet adapter module for EtherNet/IP™
K491	FMBT-21 Ethernet adapter module for Modbus TCP
K492	FPNO-21 Ethernet adapter module for PROFINET IO
K496	Connectivity for wired remote monitoring. Includes NETA-21 remote monitoring Ethernet connection, FMBT-21 Modbus/TCP adapter module (+K491). See section for wired remote monitoring (option +K496) (page 57) .
K497	Connectivity for wireless remote monitoring. Includes NETA-21 remote monitoring 21 Modbus/TCP adapter module (+K491) and 4G modem. See section remote monitoring (option +K497) (page 57) . Con
L500	FIO-11 analog I/O extension module
L501	FIO-01 digital I/O extension module
L502	FEN-31 HTL incremental encoder interface module
L503	FDCO-01 optical DDCS communication adapter module
L504	Additional I/O terminal block. See section Additional terminal block X504 (+L504) (page 57) .
L505	Thermal protection with PTC relays (1 or 2 pcs). See section Thermal protection (options +L505, +2L505, +L513, +2L513, +L536, +L537) (page 57) . Thermal protec
L506	Thermal protection with Pt100 relays (2, 3, 5 or 8 pcs). See section Pt100 relays (options +nL506, +nL514) (page 58) . Therm
L508	FDCO-02 optical DDCS communication adapter module
L513	ATEX-certified thermal protection with PTC relays (1 or 2 pcs)
L514	ATEX-certified thermal protection with Pt100 relays (3, 5 or 8 pcs)
L515	FEA-03 I/O extension adapter
L516	FEN-21 resolver interface module
L517	FEN-01 TTL incremental encoder interface module

64 Operation principle and hardware description

Code	Description
M604	Starter for auxiliary motor fan, trip limit 6.3 ... 10 A
M605	Starter for auxiliary motor fan, trip limit 10...16 A
M606	Starter for auxiliary motor fan, trip limit 16...20 A
M610	Starter for auxiliary motor fan, trip limit 20...25 A
N5000	Winder control program
N5050	Crane control program
N5100	Winch control program
N5200	PCP (Progressive Cavity Pump) control program
N5300	Test bench control program
N5350	Cooling tower control program
N5450	Override control program
N5600	ESP (Electrical Submersible Pump) control program
N5700	Position control program
N5800	Offshore winch control program
N6000	Spooling control program
N8010	IEC 61131-3 application programmability
N8200	High speed (> 598 Hz) license
P902	Customized
P904	Extended warranty (30 months from delivery or 24 months from commissioning)
P909	Extended warranty (42 months from delivery or 36 months from commissioning)
P911	Extended warranty (66 months from delivery or 60 months from commissioning)
P912	Seaworthy packaging
P913	Special color (RAL Classic)
P947	Safety data calculation and validation for tailored safety functions
P948	Customized extended warranty
P952	Country of origin: Finland
P966	Special color (other than RAL Classic)
Q950	Prevention of unexpected start-up with FSO safety functions module, by activating the Safe torque off function
Q951	Emergency stop (category 0) with safety relays, by opening the main breaker/contactors
Q952	Emergency stop (category 1) with safety relays, by opening the main breaker/contactors
Q954	Earth fault monitoring for IT (ungrounded) systems
Q957	Prevention of unexpected start-up with safety relays, by activating the Safe torque off function
Q963	Emergency stop (category 0) with safety relays, by activating the Safe torque off function

Code	Description
Q982	PROFIsafe with FSO safety functions module and FPNO-21 Ethernet adapter module
Q986	FSPS-21 PROFIsafe safety functions module
R700	Printed documents in English
R701	Printed documents in German ¹⁾
R702	Printed documents in Italian ¹⁾
R703	Printed documents in Dutch ¹⁾
R704	Printed documents in Danish ¹⁾
R705	Printed documents in Swedish ¹⁾
R706	Printed documents in Finnish ¹⁾
R707	Printed documents in French ¹⁾
R708	Printed documents in Spanish ¹⁾
R709	Printed documents in Portuguese ¹⁾
R711	Printed documents in Russian ¹⁾
R712	Printed documents in Chinese ¹⁾
R713	Printed documents in Polish ¹⁾
R714	Printed documents in Turkish ¹⁾
V112	Module auxiliary and fan power supply connector change
V998	UCU-22...24 control unit

1) The delivery can include documents in English if the requested language is not available.

Mechanical installation

Contents of this chapter

This chapter tells how to examine the installation site, unpack and examine the delivered drive and install the drive mechanically.

Examining the installation site

Examine the installation site. Make sure that:

- The installation site is sufficiently ventilated or cooled to remove heat from the drive. See the technical data.
- The ambient conditions of the drive meet the specifications. See the technical data.
- The material behind, above and below the drive is non-flammable.
- There is sufficient free space above the drive for cooling, maintenance, and operation of the pressure relief (if present).
- The floor that the drive cabinet is installed on is of non-flammable material, as smooth as possible, and strong enough to support the weight of the unit. Check the floor flatness with a spirit level. The maximum allowed deviation from the surface level is 5 mm (0.2 in) in every 3 meters (10 ft). Level the installation site, if necessary, as the cabinet is not equipped with adjustable feet.

Do not install the drive on an elevated platform or a recess. The module extraction/installation ramp included with the drive is only suitable for a height difference of 50 mm (2 in) maximum (ie. the standard plinth height of the drive).

Necessary tools

The tools required for moving the unit to its final position, fastening it to the floor and wall and tightening the connections are listed below:

- crane, fork-lift or pallet truck (check load capacity!), slate/spud bar, jack and rollers
- Pozidriv and Torx screwdrivers
- torque wrench
- set of wrenches or sockets.

- drive cabinet line-up
- optional modules (if ordered) installed onto the control unit(s) at the factory
- appropriate drive and optional module manuals
- delivery documents.

Make sure that there are no signs of damage. Before attempting installation and operation, see the information on the type designation labels of the drive to verify that the delivery is of the correct type.

Moving and unpacking the drive

Move the drive in its original packaging to the installation site as shown below to avoid damaging the cabinet surfaces and door devices. When you are using a pallet truck, check its load capacity before you move the drive.

The drive cabinet is to be moved in the upright position.

The center of gravity of the cabinet is high. Be therefore careful when moving the unit. Avoid tilting.

■ Moving the drive in its packaging

Lifting the crate with a forklift

WARNING!

Obey the local laws and regulations applicable to lifting, such as requirements for planning the lifting, for capacity and condition of lifting equipment, and for training of personnel.

70 Mechanical installation

Lifting the crate with a crane

WARNING!

Obey the local laws and regulations applicable to lifting, such as requirements for planning the lifting, for capacity and condition of lifting equipment, and for training of personnel.

b

a

a

Lifting point

b

Optimal position for the lifting sling: as close to the traverse board as possible

Moving the crate with a forklift
Moving the crate with a forklift

750 mm (29.5")

■ **Removing the transport package**

Remove the transport package as follows:

1. Undo the screws that attach the wooden parts of the transport crate to each other.
2. Remove the wooden parts.
3. Remove the clamps with which the drive cabinet is mounted onto the transport

Removing the transport package

72 Mechanical installation

Remove the transport package as follows:

1. Undo the screws that attach the wooden parts of the transport crate together.

Moving the unpacked drive cabinet

2. Remove the wooden parts.

~~Lifting the cabinet with a crane~~

3. Remove the clamps with which the drive cabinet is mounted onto the transport pallet by undoing the fastening screws.

WARNING!

4. Remove the plastic wrapping.

Obey the local laws and regulations applicable to lifting, such as requirements for planning the lifting, for capacity and condition of lifting equipment, and for training of personnel.

Moving the unpacked drive cabinet

Lifting the cabinet with a crane

Lift the drive cabinet by its designated lifting points. Depending on the size of the cabinet, it has either bolt-on lifting lugs, or lifting bars with lifting holes. Lift the drive cabinet using its lifting eyes. The lifting eyes can be removed after the cabinet is in its final position, but their mounting holes must be blocked to retain the degree of protection.

Note: The minimum allowed height of the lifting slings with IP54 units is 2 meters

(6'7").

Note: The minimum allowed height of the lifting slings with IP54 units is 2 meters (6'7").

Mechanical in

Lay the cabinet on the rollers and move it until close to its final location.
Remove the rollers by lifting the unit with a forklift, pallet truck or jack.

Moving the cabinet on its back

WARNING!

Do not transport a drive with a sine filter (option +E206) on its back. It will damage the filter.

Support the cabinet from below alongside the cubicle seams.

1 2

- 1 Cabinet back panel
- 2 Support


Moving the cabinet to its final position

Move the cabinet into its final position with the bar (spud bar). Put a piece of wood between the edge of the cabinet and the bar to protect the cabinet frame.

Attaching the cabinet to the floor and wall or roof

■ General rules

- The drive must be installed in an upright vertical position.
- Leave 400 mm (15.75") of free space above the basic roof level of the cabinet for cooling.
- The cabinet can be installed with its back against a wall (a), or back-to-back with another unit (b).
- Leave some space (w) at the side where the cabinet outmost hinges are to allow the doors to open sufficiently. The doors must open 120° to allow module replacement.



Note 1: Any height adjustment must be done before attaching the cabinet sections to the floor or to each other. Height adjustment can be done by using metal shims between the cabinet bottom and floor.

Note 2: Depending on the size of the cabinet, it has either bolt-on lifting eyes, or lifting bars with lifting holes. Bolt-on lifting eyes need not be removed unless the holes are used for attaching the cabinet. If the cabinet is delivered with lifting bars, remove them and store them for decommissioning. Plug any unused holes using the existing bolts and sealing rings included. Tighten to 70 N·m (52 lbf·ft).

WARNING!

Do not stand or walk on the cabinet roof. Make sure that nothing presses against the roof, side or back plates or door. Do not store anything on the roof while the drive is in operation.

■ **Attaching the cabinet (non-marine units)**

Alternative 1 – Clamping

1. Insert the clamps (included) into the twin slots along the front and rear edges of the cabinet frame body and fasten them to the floor with a bolt. The recommended maximum distance between the clamps in the front edge is 800 mm (31.5").
2. If floor mounting at the back is not possible, attach the top of the cabinet to the wall with L-brackets (not included in the delivery) bolted to the lifting eye/bottom holes, and suitable hardware.

Clamping bottom to floor

Attaching top to wall

M16

76 Mechanical installation

Alternative 2 – Using the holes inside the cabinet

1. Attach the cabinet to the floor through the bottom fastening holes with size M10...M12 (3/8"...1/2") bolts. The recommended maximum distance between the front edge fastening points is 800 mm (31.5").
2. If the back fastening holes are not accessible, attach the top of the cabinet to the wall with L-brackets (not included in the delivery) bolted to the lifting eye/bar holes.

Attaching bottom to floor

Attaching cabinet top to wall

M16

Alternative 3 – Cabinets with plinth options +C164 and +C179

Attach the plinth to the floor with the L-brackets with which the cabinet is attached to the transportation pallet.

■ **Attaching the cabinet (marine units)**

See the dimension drawing delivered with the drive for details of the fastening points.

Fasten the cabinet to the floor and roof (wall) as follows:

1. Bolt the unit to the floor through the flat bars at the base of the cabinet using M10 or M12 screws.
2. If there is not enough room behind the cabinet for installation, clamp (a) the rear edges of the flat bars (c) to the floor. See the figure below.
3. Attach corner brackets (d) to the lifting eye holes. Fasten the corner brackets to the rear wall and/or roof with suitable hardware such as U-brackets (e).

2

3

d

e

a

b

M16

c

- | | | | |
|---|------------------------------|---|---------------------------|
| a | Clamp | d | Corner bracket (included) |
| b | Back panel of cabinet | e | U-bracket (not included) |
| c | Flat bars at base of cabinet | - | - |

Dimension drawing for clamp (a)

Joining cabinet sections together

Wide cabinet line-ups are delivered in multiple sections. The sections must be joined together at the installation site. There is a joining cubicle at the end of a section for this purpose. The screws for joining the sections are in a plastic bag inside the cabinet.

1. Attach the first section to the floor.
2. Remove any plates covering the rear post of the joining cubicle.
3. Align the two sections. The illustration below shows the placement of the sections.

C

- a First section
- b Joining cubicle
- c Second section

4. Attach the front and rear posts of the joining cubicle to the posts of the other section with 16 screws (8 per post). Tighten the screws to 5 N·m (3.7 lbf·ft).

5. Attach the second section to the floor.

6. Connect the PE (ground) busbars using the M10 bolts included. Tighten to 35...40 N·m (25...30 lbf·ft). If necessary, adjust the connection between two busbars with the spacer plates (included in the delivery).



- a Bolt
- b Spring washer
- c Plain washer
- d Self-clinching nut
- e Spacer plate

7. Remove the shroud covering the DC busbars in the joining cubicle.

80 Mechanical installation

8. Connect the DC and AC busbars. Tighten the bolts to 55...70 N·m (40...50 lbf·ft).



Units with single DC busbars



Units with double DC busbars

Accessories kit identification:

Single DC busbars: 3AXD50000125876


Double DC busbars: 3AXD50000126361

Triple DC busbars (not shown): 3AXD50000126378

- a Joint piece
- b Plain washer with electroplated zinc coating and blue chromate passivation
- c Spring washer with mechanically sprayed zinc coating
- d Nut (M12)

Mechanical in

Units with single AC busbars



Units with double AC busba

Accessories kit identification:
Single AC busbars: 3AXD50000126392
Double AC busbars: 3AXD50000126408
Triple AC busbars (not shown): 3AXD50000126514

- a Bolt (M12)
- b Bolt (M12)
- c Joint piece
- d Plain washer with electroplated zinc coating and blue chromate passivation
- e Spring washer with mechanically sprayed zinc coating
- f Nut (M12)

WARNING!

Make sure that you install the washers in the correct order, as shown in the illustration. For example, placing an unpassivated zinc-coated spring washer directly against the joint piece will cause corrosion.

WARNING!

Do not use any joining parts other than those delivered with the unit. The parts are carefully selected to match the material of the busbars. Other parts or materials can form a galvanic couple and cause corrosion.

9. Reinstall any shrouding removed earlier.

10. Repeat procedure for any further sections

Miscellaneous

■ Cable duct in the floor below the cabinet

A cable duct can be constructed below the 500 mm wide middle part of the cabinet. The cabinet weight lies on the two 50 mm wide transverse sections which the floor must carry.

Prevent the cooling air flow from the cable duct to the cabinet by bottom plates. To ensure the degree of protection for the cabinet, use the original bottom plates delivered with the unit. With user-defined cable entries, take care of the degree of protection, fire protection and EMC compliance.

50 (1.97")

500 (19.68")

50 (1.97")

■ Arc welding

ABB does not recommend attaching the cabinet by arc welding. However, if arc welding is the only option, connect the return conductor of the welding equipment to the cabinet frame at the bottom within 0.5 meters (1'6") of the welding point.

Note: The cabinet frame is zinc-plated.

WARNING!

Make sure that the return wire is connected correctly. Welding current must not return via any component or cabling of the drive. If the welding return wire is connected incorrectly, the welding circuit can damage electronic circuits in the cabinet.

WARNING!

Do not inhale the welding fumes.

■ Air inlet through the bottom of the cabinet (option +C128)

Drives with air inlet through the bottom of the cabinet (option +C128) are intended for installation on an air duct in the floor. Each cubicle (except top entry adapter and joining cubicles) have an inlet through the bottom plate. The option also adds a 130 mm

Mechanical ins

1	1	1	1
1	1	1	1

1 Air inlet area

Support the plinth of the cabinet all round.

The air duct must be able to supply a sufficient volume of cooling air. See technical data for the minimum air flow values.

Top cable entry adapter and joining cubicles have no air inlet.

WARNING!

Make sure that the incoming air is sufficiently clean. If not, dust goes into the cabinet. The outlet filter on the cabinet roof prevents dust from going out. The collected dust can cause drive malfunction and danger of fire.

■ **Air outlet duct on the cabinet roof (option +C130)**

The option adds air outlet ducts to each cubicle of the cabinet line-up. The outlet diameter (and quantity) of the ducts depend on the cubicle width. The ducts used are from the Veloduct series by FläktGroup.

Cubicle width (mm)	Outlet duct				R i
	Veloduct type	Outer diameter (mm)	Inner diameter (mm)	Cross-sectional area (m ²)	
300	BDEA-6-020	200	194	0.030	2
400	BDEA-6-031	310	304	0.073	
500	BDEA-6-031	310	304	0.073	
600	BDEA-6-040	400	394	0.122	4
700	BDEA-6-040	400	394	0.122	4
800	2 × BDEA-6-031	310	304	0.145	

or moist air is able to flow backward to the drive in any case, even during off-time or while servicing the drive or the ventilation system.

Calculating the required static pressure difference

The required static pressure difference between the exit air duct and the drive installation room can be calculated as follows:

$$\Delta p_s = (1.5 \dots 2) \cdot p_d$$

where

$$p_d = 0.5 \cdot \rho \cdot v_m^2$$

$$v_m = q / A_c$$

p_d Dynamic pressure

ρ Air density (kg/m³)

v_m Average air velocity in the exit duct(s) (m/s)

q Rated air flow of the drive (m³/s)

A_c Cross-sectional area of the exit duct(s) (m²)

Example

The cabinet has 3 exit openings of 315 mm diameter. The rated air flow of the cabinet is 4650 m³/h = 1.3 m³/s.

$$A_c = 3 \cdot 0.315^2 \cdot \pi / 4 = 0.234 \text{ m}^2$$

$$v_m = 1.3 / 0.234 = 5.5 \text{ m/s}$$

$$p_d = 0.5 \cdot \rho \cdot v_m^2 = 0.5 \cdot 1.1 \cdot 5.5^2 = 17 \text{ Pa}$$

The required pressure in the exit air duct is then $1.5 \dots 2 \cdot 17 \text{ Pa} = 26 \dots 34 \text{ Pa}$ below the pressure in the room.

Lifting lugs and bars

■ Certificate of conformity

The certificate is available in ABB Library at (document number 3AXD10001061361).

www.abb.com/drives/documents

■ **Declarations of conformity**

86 Mechanical installation

Declaration of Conformity

Supply of Machinery (Safety) Regulations 2008

We
Manufacturer: ABB Oy
Address: Hiomotie 13, 00380 Helsinki, Finland.
Phone: +358 10 22 11

declare under our sole responsibility that the following products:

Lifting bars, identified with material codes			
64300971	64301284	64301411	64485342
64301047	64301306	64456695	64485351
64301063	64301314	64456725	64485369
64301080	64301322	64456822	64485377
64301101	64301331	64456881	64485458
64301136	64301349	64456890	68775558
64301152	64301357	64456920	68775540
64301187	64301365	64485296	3AUA5000013498
64301209	64301373	64485300	3AUA5000013504
64301250	64301381	64485318	3AUA0000055356
64301268	64301390	64485326	3AXD50000435524
64301276	64301403	64485334	3AXD50000435548

Lifting lugs, identified with material codes	
64302621	64327151

used for lifting the following frequency converters and frequency converter components

ACS800LC	types –x7LC, LC multidrives, -x07LC
ACS580, ACH580, ACQ580	types -07
ACS880	types –x7, multidrives, -x07, -xx07
ACS880LC	types –x7LC, LC multidrives, -x07LC, -xx07

identified with serial numbers beginning with 1 or 8

88 Mechanical installation

are in conformity with all the relevant lifting accessory requirements of the Supply of Machinery (Safety) Regulations 2008.

Authorized to compile the technical file: ABB Oy, Hiomotie 13, 00380 Helsinki, Finland

Helsinki, 28 May 2021

Signed for and on behalf of:

Peter Lindgren
Vice President, ABB Oy

Vesa Tiihonen
Manager, Reliability and Quality, ABB Oy

Guidelines for planning the electrical installation

Contents of this chapter

This chapter contains guidelines for planning the electrical installation of the drive.

Limitation of liability

The installation must always be designed and made according to applicable laws and regulations. ABB does not assume any liability whatsoever for any installation which breaches the local laws and/or other regulations. Furthermore, if the recommendations given by ABB are not followed, the drive may experience problems that the warranty does not cover.

■ North America

Installations must be compliant with NFPA 70 (NEC) ¹⁾ and/or Canadian Electrical Code (CE) along with state and local codes for your location and application.

¹⁾ National Fire Protection Association 70 (National Electric Code).

Selecting the supply transformer

■ Basic guidelines

1. Define the apparent power of the transformer. You can use this rule of thumb:
 $S_N \text{ (kVA)} = 1.32 \times \text{sum of the motor shaft power (kW)}$
2. Define the nominal voltage for the transformer secondary winding according to the nominal input voltage of the drive. See the supply unit hardware manual.
3. Make sure that the transformer complies with the electrical power network specification of the drive. See the appropriate drive or supply unit hardware manual for:
 - nominal input voltage, allowed voltage variation and imbalance
 - nominal frequency and allowed variation
 - short-circuit withstand strength and short-circuit current protection requirements
 - etc.
4. Consider the additional notes below.
5. Contact the transformer manufacturer for more information on the transformer selection.

■ Additional notes


A drive with a 12-pulse diode supply unit

A 12-pulse diode supply unit cannot control the load sharing between its diode bridges. The load sharing depends on factors such as the transformer selection, actual state of the transformer (voltages, harmonics), supply network and cables. Load unbalance reduces the load capacity of the drive. To avoid it, and to achieve the optimal drive system performance, obey the guidelines in this section on the transformer selection and on other factors.

Use a three-winding transformer, or two two-winding transformers:

- Connection groups: three-winding transformer: Dy11d0 (or Dd0y1). Two two-winding transformers: Dy11 and Yy0.
- Phase shift between secondaries: 30° electrical
- Voltage difference between secondaries: < 0.5%
- Short-circuit impedance of secondaries: > 5%
- Short-circuit impedance difference between secondaries: < 3%
- No grounding of the secondary windings.
- Static shield is recommended.

Guidelines for planning the electrical



- 1 Medium voltage network
- 2 Three-winding transformer
- 3 12-pulse drive
- 4 No grounding of transformer secondary windings is permitted
- 5 No load unbalance between transformer secondary windings is permitted
- 6 Large 6-pulse drives (possible sources of harmonics)
- 7 No (or only minimal) voltage distortion in medium voltage network is permitted.
 - a. Path of harmful effect (harmonics) to one leg of the 12-pulse supply unit through the delta-delta connections
 - b. Path of harmful effect (harmonics) to one leg of the 12-pulse supply unit through the delta-wye connections.

Use identical supply cables between the transformer secondary windings and the 12-pulse drive (type, size, length, quantity).

Make sure that there is no (or only minimal) voltage distortion in the medium voltage system. The distortion has a negative effect on the operation of the transformer and the 12-pulse drive. Especially 5th and 7th order harmonics are harmful. The

If the three-winding transformer supplies power to multiple 12-pulse drives, derate the drive power rating from the nominal value according to the table below.

Number of 12-pulse drives	Drive power rating (%)
1	100
2	90
3	85
4	82
5	80

Selecting the supply disconnecting device

The drive is equipped with a main disconnecting device as standard. Depending on the size of the drive, and the selected options, the type of disconnecting device may vary. Examples: switch-disconnector, withdrawable air circuit breaker, etc.

Selecting the main contactor or breaker

Depending on the drive type and size, it is fitted with a main contactor or a main breaker by default. With certain drive types, you can select either of the two.

Examining the compatibility of the motor and drive

Use asynchronous AC induction motors, permanent magnet synchronous motors, AC induction servomotors or ABB synchronous reluctance motors (SynRM motors) with the drive.

Select the motor size and drive type from the rating table on basis of the AC line voltage and motor load. You can find the rating table in the appropriate hardware manual. You can also use the DriveSize PC tool.

Make sure that the motor can be used with an AC drive. See [Requirements tables \(page 93\)](#). For basics of protecting the motor insulation and bearings in drive systems, see [Protecting the motor insulation and bearings \(page 92\)](#).

Note:

- Consult the motor manufacturer before using a motor with nominal voltage that differs from the AC line voltage connected to the drive input.
- The voltage peaks at the motor terminals are relative to the supply voltage of the drive, not to the drive output voltage.

Modern variable speed drives with their fast rising voltage pulses and high switching frequencies can generate current pulses that flow through the motor bearings and can gradually erode the bearing races and rolling elements.

dv/dt filters protect motor insulation system and reduce bearing currents. Common mode filters reduce bearing currents. Insulated N-end (non-drive end) bearing protects against bearing currents.

■ Requirements tables

These tables show how to select the motor insulation system and when a drive dv/dt filter and common mode filters and insulated N-end (non-drive end) motor bearing are required. Ignoring the requirements or improper installation may shorten motor life or damage the motor bearings and voids the warranty.

Requirements for ABB motors, $P_n < 100 \text{ kW}$ (134 hp)

See also [Abbreviations](#) (page 96).

Motor type	Nominal AC line voltage	Motor insulation system	Requirement for ABB d u /d t and common mode filters and insulated N-end motor bearing P _n < 100 kW and frame size 315-1000 P _n < 134 hp and frame size 315-1000
Random-wound M2_, M3_ and M4_	U _n ≤ 500 V	Standard	-
	500 V < U _n ≤ 600 V	Standard	+ d u /d t
		Reinforced	-
		Reinforced	+ d u /d t
	600 V < U _n ≤ 690 V (cable length ≤ 150 m)	Reinforced	+ d u /d t
	600 V < U _n ≤ 690 V (cable length > 150 m)	Reinforced	-
Form-wound HX_ and AM_	380 V < U _n ≤ 690 V	Standard	N/A
Old ¹⁾ form-wound HX_ and modular	380 V < U _n ≤ 690 V	Check with the motor manufacturer.	+ N + d u /d t with voltages over 600 V
Random-wound HX_ and AM_ ²⁾	0 V < U _n ≤ 500 V	Enamelled wire with fiber glass taping	+ N + CMF
	500 V < U _n ≤ 690 V		+ N + d u /d t + CMF
HDP	Consult the motor manufacturer.		

94 Guidelines for planning the electrical installation

Requirements for ABB motors, $P_n > 100 \text{ kW}$ (134 hp)

See also [Abbreviations](#) (page 96).

Motor type	Nominal AC line voltage	Motor insulation system	Requirement for	
			ABB d u /d t and common mode filters, insulated N-end motor bearings	
			100 kW ≤ P _n < 350 kW or IEC 315 ≤ frame size < IEC 400	P _n ≥ 350 kW or frame size ≥ IEC 400
			134 hp ≤ P _n < 469 hp or NEMA 500 ≤ frame size ≤ NEMA 580	P _n ≥ 469 hp or frame size > NEMA 580
Random-wound M2_, M3_ and M4_	U _n ≤ 500 V	Standard	+ N	+ N + CMF
	500 V < U _n ≤ 600 V	Standard	+ N + d u /d t	+ N + d u /d t + CMF
		Reinforced	+ N	+ N + CMF
	600 V < U _n ≤ 690 V (cable length ≤ 150 m)	Reinforced	+ N + d u /d t	+ N + d u /d t + CMF
	600 V < U _n ≤ 690 V (cable length > 150 m)	Reinforced	+ N	+ N + CMF
Form-wound HX_ and AM_	380 V < U _n ≤ 690 V	Standard	+ N + CMF	P _n < 500 kW: +N + P _n ≥ 500 kW: +N + d u /d t + CMF
Old ¹⁾ form-wound HX_ and modular	380 V < U _n ≤ 690 V	Check with the motor manufacturer.	+ N + d u /d t with voltages over 500 V + CMF	
Random-wound HX_ and AM_ ²⁾	0 V < U _n ≤ 500 V	Enamelled wire with fiber glass taping	+ N + CMF	
	500 V < U _n ≤ 690 V		+ N + d u /d t + CMF	
HDP	Consult the motor manufacturer.			

1) manufactured before 1.1.1998

2) For motors manufactured before 1.1.1998, check for additional instructions with the motor manufacturer.

Requirements for non-ABB motors, $P_n < 100 \text{ kW (134 hp)}$

See also [Abbreviations \(page 96\)](#).

Motor type	Nominal AC line voltage	Motor insulation system ¹⁾	Requirement for	
			ABB d u /d t and common mode	N-end motor b
			$P_n < 100 \text{ kW}$ and frame si	$P_n < 134 \text{ hp}$ and frame size
Random-wound and form-wound	$U_n \leq 420 \text{ V}$	$\hat{U}_{LL} = 1300 \text{ V}$, 0.2 μs rise time	-	-
	$420 \text{ V} < U_n \leq 500 \text{ V}$	$\hat{U}_{LL} = 1300 \text{ V}$	+ d u /d t	-
		$\hat{U}_{LL} = 1600 \text{ V}$, 0.2 μs rise time	-	-
	$500 \text{ V} < U_n \leq 600 \text{ V}$	$\hat{U}_{LL} = 1600 \text{ V}$	+ d u /d t	-
		$\hat{U}_{LL} = 1800 \text{ V}$, 0.2 μs rise time	-	-
	$600 \text{ V} < U_n \leq 690 \text{ V}$	$\hat{U}_{LL} = 1800 \text{ V}$	+ d u /d t	-
		$\hat{U}_{LL} = 2000 \text{ V}$, 0.3 μs rise time	-	-

1) These are typical values. The network topology and grounding, drive type, cable type, cable length, and other factors have an effect on the phase-to-phase and phase-to-ground voltages of the motor. For motor dimension selection, refer to IEC 60034-18-41, IEC 60034-18-42 and IEC/TC 60034-25. For more information, c

Requirements for non-ABB motors, $P_n > 100 \text{ kW}$ (134 hp)See also [Abbreviations](#) (page 96).

Motor type	Nominal AC line voltage	Motor insulation system ¹⁾	Requirement for	
			ABB d u /d t and common mode filters, insulated N-end motor bearings	
			100 kW ≤ P_n < 350 kW or IEC 315 ≤ frame size < IEC 400	P_n ≥ 350 kW or frame size ≥ IEC 400
			134 hp ≤ P_n < 469 hp or NEMA 500 ≤ frame size ≤ NEMA 580	P_n ≥ 469 hp or frame size > NEMA 580
Random-wound and form-wound	$U_n \leq 420 \text{ V}$	$\hat{U}_{LL} = 1300 \text{ V}$, 0.2 μs rise time	+ N or CMF	+ N + CMF
	$420 \text{ V} < U_n \leq 500 \text{ V}$	$\hat{U}_{LL} = 1300 \text{ V}$	+ d u /d t + (N or CMF)	+ N + d u /d t + CMF
		$\hat{U}_{LL} = 1600 \text{ V}$, 0.2 μs rise time	+ N or CMF	+ N + CMF
	$500 \text{ V} < U_n \leq 600 \text{ V}$	$\hat{U}_{LL} = 1600 \text{ V}$	+ d u /d t + (N or CMF)	+ N + d u /d t + CMF
		$\hat{U}_{LL} = 1800 \text{ V}$, 0.2 μs rise time	+ N or CMF	+ N + CMF
	$600 \text{ V} < U_n \leq 690 \text{ V}$	$\hat{U}_{LL} = 1800 \text{ V}$	+ d u /d t + N	+ N + d u /d t + CMF
		$\hat{U}_{LL} = 2000 \text{ V}$, 0.3 μs rise time	+ N + CMF	+ N + CMF

1) These are typical values. The network topology and grounding, drive type, cable type, cable length, and motor type have an effect on the phase-to-phase and phase-to-ground voltages of the motor. For motor dimensioning and selection, refer to IEC 60034-18-41, IEC 60034-18-42 and IEC/TC 60034-25. For more information, contact ABB.

Abbreviations

Abbr.	Definition
U_n	Nominal AC line voltage
\hat{U}_{LL}	Peak line-to-line voltage at motor terminals which the motor insulation must withstand
P_n	Motor nominal power
d u /d t	d u /d t filter at the output of the drive
CMF	Common mode filter of the drive

Additional requirements for explosion-safe (EX) motors

If you use an explosion-safe (EX) motor, obey the rules in the requirements table. In addition, consult the motor manufacturer for any further requirements.

Additional requirements for ABB motors of types other than M3_, HX_, AM_

Use the selection criteria given for non-ABB motors.

Additional requirements for braking applications

When the motor brakes the machinery, the intermediate circuit DC voltage of the drive increases, the effect being similar to the motor supply voltage increasing by up to 20 percent. Consider this voltage increase when specifying the motor insulation requirements if the motor will be braking a large part of its operation time.

Example: Motor insulation requirement for a 400 V AC line voltage application should be selected as if the drive were supplied with 480 V.

Additional requirements for ABB high-output and IP23 motors

The rated output power of high output motors is higher than what is stated for a particular frame size in EN 50347 (2001).

This table shows the requirements for protecting the motor insulation and bearings in drive systems for ABB random-wound motor series (for example, M3AA, M3AB, M3BP).

Nominal AC supply voltage	Motor insulation system	Requirement for ABB du/dt and common mode filters, insulated bearings	
		$P_n < 100 \text{ kW}$	$100 \text{ kW} \leq P_n < 200 \text{ kW}$
		$P_n < 140 \text{ hp}$	$140 \text{ hp} \leq P_n < 268 \text{ hp}$
$U_n \leq 500 \text{ V}$	Standard	-	+ N
$500 \text{ V} < U_n \leq 600 \text{ V}$	Standard	+ du/dt	+ du/dt + N
	Reinforced	-	+ N
$600 \text{ V} < U_n \leq 690 \text{ V}$	Reinforced	+ du/dt	+ du/dt + N

Additional requirements for non-ABB high-output and IP23 motors

The rated output power of high-output motors is higher than what is stated for a particular frame size in EN 50347 (2001).

If you plan to use a non-ABB high-output motor or an IP23 motor, consider the additional requirements for protecting the motor insulation and bearings in

98 Guidelines for planning the electrical installation

Nominal AC supply voltage	Motor insulation system ¹⁾	Requirement for	
		ABB d u /d t and common mode filters, insulated N end motor bearings	
		P_n < 100 kW or frame size < IEC 315	100 kW < P_n < 350 IEC 315 < frame size < 400
		P_n < 134 hp or frame size < NEMA 500	134 hp < P_n < 469 NEMA 500 < frame size < NEMA 580
U _n ≤ 420 V	Û _{LL} = 1300 V, 0.2 µs rise time	+ N or CMF	+ N or CMF
420 V < U _n < 500 V	Û _{LL} = 1300 V	+ d u /d t + (N or CMF)	+ N + d u /d t + CMF
	Û _{LL} = 1600 V, 0.2 µs rise time	+ N or CMF	+ N or CMF
500 V < U _n ≤ 600 V	Û _{LL} = 1600 V	+ d u /d t + (N or CMF)	+ N + d u /d t + CMF
	Û _{LL} = 1800 V, 0.2 µs rise time	+ N or CMF	+ N + CMF
600 V < U _n ≤ 690 V	Û _{LL} = 1800 V	+ N + d u /d t	+ N + d u /d t + CMF
	Û _{LL} = 2000 V, 0.3 µs rise time	+ N + CMF	+ N + CMF



1) These are typical values. The network topology and grounding, drive type, cable type, cable length, and motor type have an effect on the phase-to-phase and phase-to-ground voltages of the motor. For motor dimensioning and selection, refer to IEC 60034-18-41, IEC 60034-18-42 and IEC/TC 60034-25. For more information, contact ABB.

Additional data for calculating the rise time and the peak line-to-line voltage

The diagrams below show the relative peak line-to-line voltage and rate of change of voltage as a function of the motor cable length. If you need to estimate the peak voltage and voltage rise time considering the actual cable length, proceed as follows:

- Peak line-to line voltage: Read the relative \hat{U}_{LL} / U_n value from the diagram below and multiply it by the nominal supply voltage (U_n).
- Voltage rise time (t_r): Read the d u /d t value from the diagram below. Substitute the \hat{U}_{LL} (in kV) and d u /d t values into equation $t_r = 0.8 \cdot \hat{U}_{LL} / (d u /d t)$.

Guidelines for planning the electrical



- | | |
|----------------------|------------------------------------|
| A | Drive with d u / d t filter |
| B | Drive without d u / d t filter |
| l | Motor cable length |
| \hat{U}_{LL} / U_N | Relative peak line-to-line voltage |
| $(d u / d t) / U_N$ | Relative d u / d t value |

Additional note for sine filters

A sine filter also protects the motor insulation system. The peak phase-to-voltage with a sine filter is approximately $1.5 \cdot U_n$.

Selecting the power cables

■ Power cable selection procedure and applicability check

Select each power cable as follows. Obey the local regulations.

1. Select the cable type. Obey the general guidelines and recommendations for the drive power cabling.
2. Select the cable size. Refer to the listing of typical power cable sizes given in the technical data.
3. Make sure that the short-circuit rating of the cable is sufficient. Take into account the disconnection time of the protective device. If the rating is not sufficient, select a larger cable, increase the number of parallel cables or change the cable to a type with higher conductor temperature rating.
4. Select the cable lugs.
5. Make sure that the cable can enter the cabinet through the cable entry plate. Refer to the dimension drawings of the drive delivery or technical data in the drive hardware manual. For special cable entry solutions, consult ABB.
6. Make sure that there is sufficient space to install the cable(s) and cable lugs to the terminals. Refer to the terminal and cable entry data given in the technical data.

■ General guidelines

Select the input power and motor cables according to local regulations.

- **Current:** Select a cable capable of carrying the maximum load current and suitable for the prospective short-circuit current provided by the supply network. The method of installation and ambient temperature affect the cable current carrying capacity. Obey local regulations and laws.
- **Temperature:** For an IEC installation, select a cable rated for at least 70 °C (158 °F) maximum permissible temperature of conductor in continuous use. For North America, select a cable rated for at least 75 °C (167 °F). Important: For certain product types or option configurations higher temperature rating may be required. See the technical data for details.
- **Voltage:** 600 V AC cable is accepted for up to 500 V AC. 750 V AC cable is accepted for up to 600 V AC. 1000 V AC cable is accepted for up to 690 V AC.

To comply with the EMC requirements of the CE mark, use one of the preferred cable types. See [Preferred power cable types \(page 101\)](#).

Symmetrical shielded cable reduces electromagnetic emission of the whole drive system as well as the stress on motor insulation, bearing currents and wear.

■ Power cable types

Preferred power cable types

This section shows the preferred cable types. Make sure that the selected cable also complies with local/state/country electrical codes.


Cable type	Use as input power cabling	Use as motor cabling or brake resistor
PE	Yes	Yes
Symmetrical shielded (or armored) cable with three phase conductors and concentric PE conductor as shield (or armor)		
PE	Yes	Yes
Symmetrical shielded (or armored) cable with three phase conductors and symmetrically constructed PE conductor and a shield (or armor)		
	Yes	Yes
PE		
Symmetrical shielded (or armored) cable with three phase conductors and a shield (or armor), and separate PE conductor/cable ¹⁾		

1) A separate PE conductor is required if the conductivity of the shield (or armor) is not sufficient for the

Alternate power cable types

Cable type	Use as input power cabling	Use as motor cabling or brake resistor
	Yes	Yes with phase

102 Guidelines for planning the electrical installation

Cable type	Use as input power cabling	Use as motor cabling and as brake resistor cabling
	Yes	Yes with motors up to 100 kW (135 hp). A potential equalization between the frames of motor driven equipment is required.
Shielded (Al/Cu shield or armor) ¹⁾ four-conductor cable (three phase conductors and a PE)		
PE	Yes	No
A single-core cable system: three phase conductors and PE conductor on cable tray	WARNING! If you use unshielded single-core cables in an IT network, make sure that the non-conductive outer sheath (jacket) of the cables have good contact with a properly grounded conductive surface. For example, install the cables on a properly grounded cable tray. Otherwise voltage may become present on the non-conductive outer sheath of the cables, and there is even a risk of an electric shock.	
 Preferable cable arrangement to avoid voltage or current unbalance between the phases		

¹⁾ Armor may act as an EMC shield, as long as it provides the same performance as a concentric EMC shield of a shielded cable. To be effective at high frequencies, the shield conductivity must be at least 1/10 of the phase conductor conductivity. The effectiveness of the shield can be evaluated based on the shield inductance, which must be low and only slightly dependent on frequency. The requirements are easily met with a copper or aluminum shield/armor. The cross-section of a steel shield must be ample and the shield helix must have a low gradient. A galvanized steel shield has a better high-frequency conductivity than a non-galvanized steel shield.

Not allowed power cable types

Cable type	Use as input power cabling	Use as motor cabling and as brake resistor cabling
PE	No	No
Symmetrical shielded cable with individual shields for each phase conductor		

- ## Grounding requirements

The conductivity of the protective earth conductor(s) must be sufficient.

The table shows the minimum cross-sectional area of the protective earth related to the phase conductor size according to IEC/UL 61800-5-1 when the conductor(s) and the protective earth conductor are made of the same metal. If they are different metals, the cross-sectional area of the protective earth conductor can be determined in a manner which produces a conductance equivalent to that which results from the application of this table.

1) For the minimum conductor size in IEC installations, refer to [Additional grounding requirements](#)

■ Additional grounding requirements – IEC

This section gives grounding requirements according to standard IEC/EN 61800-5-1.

Because the normal touch current of the drive is more than 3.5 mA AC or 10 mA DC:

- the minimum size of the protective earth conductor must comply with the local safety regulations for high protective earth conductor current equipment, and
- you must use one of these connection methods:
 1. a fixed connection and:
 - a protective earth conductor with a minimum cross-sectional area of 10 mm^2 Cu or 16 mm^2 Al (as an alternative when aluminum cables are permitted),
 - or
 - a second protective earth conductor of the same cross-sectional area as the original protective earth conductor,
 - or
 - a device that automatically disconnects the supply if the protective earth conductor is damaged.
 2. a connection with an industrial connector according to IEC 60309 and a minimum protective earth conductor cross-section of 2.5 mm^2 as part of a multi-conductor power cable. Sufficient strain relief must be provided.

If the protective earth conductor is routed through a plug and socket, or similar means of disconnection, it must not be possible to disconnect it unless power is simultaneously removed.

Note: You can use power cable shields as grounding conductors only when their conductivity is sufficient.

■ Additional grounding requirements – UL (NEC)

This section gives grounding requirements according to standard UL 61800-5-1.

The protective earth conductor must be sized as specified in Article 250.122 and table 250.122 of the National Electric Code, ANSI/NFPA 70.

For cord-connected equipment, it must not be possible to disconnect the protective earth conductor before power is removed.

Selecting the control cables

■ Shielding

Only use shielded control cables.

A double-shielded cable (a) is the best alternative for low-voltage digital signals. A single-shielded (b) twisted pair cable is also acceptable.

a

b

■ **Signals in separate cables**

Run analog and digital signals in separate, shielded cables. Do not mix 24 V or 115/230 V AC signals in the same cable.

■ **Signals that can be run in the same cable**

If their voltage does not exceed 48 V, relay-controlled signals can be run in the same cables as digital input signals. The relay-controlled signals should be run as twisted pairs.

■ **Relay cable**

The cable type with braided metallic shield (for example ÖLFLEX by LAPPKABEL, Germany) has been tested and approved by ABB.

■ **Control panel to drive cable**

Use EIA-485, Cat 5e (or better) cable with male RJ-45 connectors. The maximum length of the cable is 100 m (328 ft).

■ **PC tool cable**

Connect the Drive Composer PC tool to the drive through the USB port of the control panel. Use a USB Type A (PC) - Type Mini-B (control panel) cable. The maximum length of the cable is 3 m (9.8 ft).


Routing the cables

■ **General guidelines – IEC**

- Route the motor cable away from other cables. Motor cables of several cables can be run in parallel installed next to each other.
- Install the motor cable, input power cable and control cables on separate cable trays.
- Avoid long parallel runs of motor cables with other cables.

106 Guidelines for planning the electrical installation

The following figure illustrates the cable routing guidelines with an example drive.



- 1 Motor cable
- 2 Input power cable
- 3 Control cable
- 4 Brake resistor or chopper cable (if any)

■ Continuous motor cable shield/conduit and metal enclosure for equipment on the motor cable

To minimize the emission level when safety switches, contactors, connection boxes or similar equipment are installed on the motor cable between the drive and the motor:

- Install the equipment in a metal enclosure.
- Use either a symmetrical shielded cable, or install the cabling in a metal conduit.
- Make sure that there is a good and continuous galvanic connection in the shield/conduit between drive and motor.
- Connect the shield/conduit to the protective ground terminal of the drive and the motor.

■ Separate control cable ducts

Put 24 V DC and 230 V AC (120 V AC) control cables in separate ducts, unless the 24 V DC cable is insulated for 230 V AC (120 V AC) or insulated with an insulation sleeving for 230 V AC (120 V AC).

Protecting the drive, input power cable, motor and motor cable in short circuit situations and against thermal overload

■ Protecting the input cabling and the drive upon a short-circuit

To protect the input cable in short-circuit situations, install fuses or a suitable circuit breaker at the supply side of the cabling.

The drive is equipped with fuses as standard. In case of a short-circuit inside the drive, the fuses protect the drive, restrict drive damage, and prevent damage to other equipment.

■ Protecting the motor and motor cable in short-circuits

The drive protects the motor cable and motor in a short-circuit situation with the following conditions:

- the motor cable is sized correctly
- the motor cable type complies with the motor cable selection guidelines
- the cable length does not exceed the allowed maximum length specified in the drive manual
- the setting of parameter 99.10 Motor nominal power in the drive is equal to or greater than the value given on the motor rating plate.

The electronic power output short-circuit protection circuitry meets the requirements of IEC 60364-4-41 2005/AMD1.

■ Protecting the drive and the power cables against thermal overload

The drive protects itself and the input and motor cables against thermal overload when the cables are sized according to the nominal current of the drive. No additional thermal protection devices are needed.

WARNING!

If the drive is connected to multiple motors, use a separate circuit breaker and fuses for protecting each motor cable and motor against overload. The drive's overload protection is tuned for the total motor load. It may not trip due to an overload in one motor circuit only.

■ Protecting the motor against thermal overload

According to regulations, the motor must be protected against thermal overload. The drive's current must be switched off when overload is detected. The drive includes a motor thermal protection function that protects the motor and switches off the drive.

■ **Protecting the motor against overload without thermal model or temperature sensors**

Motor overload protection protects the motor against overload without using motor thermal model or temperature sensors.

Motor overload protection is required and specified by multiple standards including the US National Electric Code (NEC) and the common UL/IEC 61800-5-1 standard in conjunction with UL/IEC 60947-4-1. The standards allow for motor overload protection without external temperature sensors.

The protection feature of the drive allows the user to specify the class of operation in the same manner as the overload relays are specified in standards UL/IEC 60947-4-1 and NEMA ICS 2.

The motor overload protection supports thermal memory retention and speed sensitivity.

For more information, see drive firmware manual.

Protecting the drive against ground faults

The drive is equipped with an internal ground fault protective function to protect the unit against ground faults in the motor and motor cable. This function is not a personnel safety or a fire protection feature. See the firmware manual for more information.

An optional ground fault monitoring device (+Q954) is available for IT (ungrounded) systems. The option includes a ground fault indicator on the drive cabinet door.

■ **Residual current device compatibility**

The drive is suitable for use with residual current devices of Type B.

Note: As standard, the drive contains capacitors connected between the main circuit and the frame. These capacitors and long motor cables increase the ground leakage current and may cause nuisance faults in residual current devices.

Implementing the emergency stop function

You can order the drive with an emergency stop function (option).

See the appropriate option manual for more information.

Note: The UCU control unit does not support options +Q978 and +Q979.

Implementing the Safe torque off function

See chapter [The Safe torque off function](#) (page 307).

Implementing the Prevention of unexpected start-up function

You can order the drive with a Prevention of unexpected start-up (POUS) function. The POUS function disables the control voltage of the power semiconductors of the drive (inverter) output stage. This prevents the drive from generating the torque required to rotate the motor. POUS enables a short-time maintenance work (e.g. cleaning) on the non-electrical parts of the machinery without switching off or disconnecting the drive.

See the appropriate option manual for more information.

Note: The UCU control unit does not support option +Q950.

Option code	User's manual
+Q950	Prevention of unexpected start-up, with FSO-xx safety functions module
+Q957	Prevention of unexpected start-up, with safety relay

Implementing an ATEX-certified motor thermal protection

With option +Q971, the drive provides ATEX-certified safe motor disconnection using the drive Safe torque off function. To implement the thermal protection of a motor in explosive atmosphere (Ex motor), you must also:

- use an ATEX-certified Ex motor
- order an ATEX-certified thermistor protection module for the drive (option +Q971) or acquire and install an ATEX-compliant protection relay
- do the necessary connections.

For cabinet-built drives, an ATEX-certified motor thermal protection function is available (option +L513+Q971, or +L514+Q971). The drive is equipped with an ATEX-certified Safe motor disconnection function and with ATEX-compliant relays for PTC or Pt100 temperature sensors.

For more information, see:

User's manual

Implementing the functions provided by the FSO safety functions module

You can order the drive with an FSO-12 safety functions module (option +Q973) or FSO-21 safety functions module (option +Q972). An FSO module enables the implementation of functions such as Safe brake control (SBC), Safe stop 1 (SS1), Safe stop emergency (SSE), Safely limited speed (SLS) and Safe maximum speed (SMS).

The settings of the FSO module have default values when delivered from the factory. The wiring of the external safety circuit and configuration of the FSO module are the responsibility of the user.

The FSO module reserves the standard Safe torque off (STO) connection of the drive control unit. STO can still be utilized by other safety circuits through the FSO module.

See the appropriate manual for more information.

Note: The UCU control unit does not support options +Q973 and +Q972.

Name	Code
FSO-12 safety functions module user's manual	3AXD500000
FSO-21 safety functions module user's manual	3AXD500000

Implementing the power loss ride-through function

If the incoming supply voltage is cut off, the drive will continue to operate by utilizing the kinetic energy of the rotating motor. The drive will be fully operational as long as the motor rotates and generates energy to the drive.

If the drive is equipped with a main contactor or breaker, it restores the drive input power after a short break. The contactor re-connects after the break automatically. If the drive is equipped an external uninterruptible auxiliary power supply (option +G307), it keeps the main contactor closed in power-loss situations

Note: If the power loss lasts so long that the drive trips on undervoltage, a fault reset and a fresh start command is required to continue operation.

Implement the power-loss ride-through function as follows:

1. Enable the power-loss ride-through function of the drive (parameter 30.31).
2. Enable the automatic restart of the motor after a short power supply break:
 - Set the start mode to automatic (parameter 21.01 or 21.19, depending on the motor control mode being used).
 - Define the automatic restart time (parameter 21.18).

installation must be clearly marked as defined in IEC/EN/UL 61800-5-1, subclause 6.5.3, for example, "THIS MACHINE STARTS AUTOMATICALLY".

Bypass connection is available as a factory-installed option for some cabinet-drive types. Consult ABB for more information.

WARNING!

Never connect the drive output to the electrical power network. The output may damage the drive.

Supplying power for the auxiliary circuits

The user must supply these options from external power sources:

- +G300/+G301: Cabinet heaters and/or lighting
- +G307: Connection for an external uninterruptible power supply
- +G313: Power supply connection for a motor space heater output

For the voltages and fuse sizes, refer to the circuit diagrams delivered with the drive.

Using power factor compensation capacitors with the drive

Power factor compensation is not needed with AC drives. However, if a drive is connected in a system with compensation capacitors installed, note the following restrictions.

WARNING!

Do not connect power factor compensation capacitors or harmonic filters to the motor cables (between the drive and the motor). They are not meant to be used with AC drives and can cause permanent damage to the drive or themselves.

If there are power factor compensation capacitors in parallel with the input to the drive:

1. Do not connect a high-power capacitor to the power line while the drive is connected. The connection will cause voltage transients that may trip or damage the drive.
2. If capacitor load is increased/decreased step by step when the AC drive is connected to the power line, make sure that the connection steps are low enough not to cause voltage transients that would trip the drive.

Implementing the control of a contactor between drive and motor

Implementing the control of the output contactor depends on the motor control mode and stopping method selected.

When you select the DTC motor control mode and the motor ramp stop mode, use this operation sequence to open the contactor:

1. Give a stop command to the drive.
2. Wait until the drive decelerates the motor to zero speed.
3. Open the contactor.

WARNING!

If DTC motor control mode is in use, do not open the output contactor while the drive controls the motor. The motor control operates faster than the contactor, and tries to maintain the load current. This can cause damage to the contactor.

When you select the DTC motor control mode and the motor coast stop mode, you can open the contactor immediately after the drive has received the stop command. This is the case also if you use the scalar motor control mode.


Protecting the contacts of relay outputs

Inductive loads (relays, contactors, motors) cause voltage transients when switched off.

The relay contacts on the drive control unit are protected with varistors (250 V) against overvoltage peaks. In spite of this, it is highly recommended that inductive loads are equipped with noise attenuating circuits (varistors, RC filters [AC] or diodes [DC]) to minimize the EMC emission at switch-off. If not suppressed, the disturbances may connect capacitively or inductively to other conductors in the control cable and form a risk of malfunction in other parts of the system.

Install the protective component as close to the inductive load as possible. Do not install protective components at the relay outputs.

Guidelines for planning the electrical



Implementing a motor temperature sensor connection

WARNING!

IEC 61800-5-1 requires double or reinforced insulation between live parts and accessible parts when:

- the accessible parts are not conductive, or
- the accessible parts are conductive, but not connected to the earth.

Obey this requirement when you plan the connection of the motor temperature sensor to the drive.

You have these implementation alternatives:

1. If there is double or reinforced insulation between the sensor and the live parts of the motor: You can connect the sensor directly to the analog/digital input module of the drive. See the control cable connection instructions. Make sure that the voltage is not more than the maximum allowed voltage over the sensor.
2. If there is basic insulation between the sensor and the live parts of the motor or if the insulation type is not known: You can connect the sensor to the drive through an option module. The sensor and the module must form a double or reinforced insulation.

■ **Connecting a motor temperature sensor to the drive through an option module**

This table shows:

- option module types that you can use for the motor temperature sensor connection
- insulation or isolation level that each option module forms between its temperature sensor connector and other connectors
- temperature sensor types that you can connect to each option module
- temperature sensor insulation requirement in order to form, together with the insulation of the option module, a reinforced insulation between the motor live parts and the drive control unit.

Type	Option module	Temperature sensor type			Temperature sensor insulation requirement
	Insulation/Isolation	PTC	KTY	Pt100, Pt1000	
FIO-11	Galvanic isolation between sensor connector and drive control unit connector. No isolation between sensor connector and other I/O connectors.	x	x	x	Reinforced insulation
FEN-01	Galvanic isolation between sensor connector and drive control unit connector. No isolation between sensor connector and TTL encoder emulation output.	x	-	-	Reinforced insulation
FEN-11	Galvanic isolation between sensor connector and drive control unit connector. No isolation between sensor connector and TTL encoder emulation output.	x	x	-	Reinforced insulation
FEN-21	Galvanic isolation between sensor connector and drive control unit connector. No isolation between sensor connector and TTL encoder emulation output.	x	x	-	Reinforced insulation
FEN-31	Galvanic isolation between sensor connector and drive control unit connector. No isolation between sensor connector and other connectors.	x	x	-	Reinforced insulation
FAIO-01	Basic insulation between sensor connector and drive control unit	x	x	x	Reinforced or basic insulation. With basic insulation

Electrical installation

Contents of this chapter

This chapter contains instructions on the wiring of the drive.

Warnings

WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur. If you are not a qualified electrical professional, do not do installation, commissioning or maintenance work.

Measuring the insulation

■ Measuring the insulation resistance of the drive

WARNING!

Do not do voltage withstand or insulation resistance tests on the drive. These tests can cause damage to the drive. Every drive is tested for insulation between the main circuit and the chassis at the factory. Also, there are voltage-limiting circuits inside the drive which cut down the testing voltage automatically.


■ Measuring the insulation resistance of the motor and motor cable

WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur. If you are not a qualified electrical professional, do not do installation, commissioning or maintenance work.

1. Do the steps in section [Electrical safety precautions \(page 21\)](#) before you start the work.
2. Make sure that the motor cable is disconnected from the drive output terminals.
3. Measure the insulation resistance between each phase conductor and the protective earth conductor. Use a measuring voltage of 1000 V DC. The insulation resistance of an ABB motor must be more than 100 Mohm (reference value at 25 °C [77 °F]). For the insulation resistance of other motors, refer to the manufacturer's instructions.

Note: Moisture inside the motor reduces the insulation resistance. If you think that there is moisture in the motor, dry the motor and do the measurement again.



■ Measuring the insulation resistance of the input power cable

Before you connect the input power cable to the drive, measure its insulation resistance according to local regulations.

Compatibility check - IT (ungrounded) earthing system

Drives with a category 2, 1st environment EMC filter (option +E202) are not suitable for use in an IT (ungrounded) supply network system. If the drive is equipped with option +E202, disconnect the filter before connecting the drive to the IT supply network. Contact ABB for instructions.

WARNING!

Do not install a drive equipped with EMC filter +E202 on an IT system (an ungrounded power system or a high-resistance-grounded [over 30 ohms] power system). The system will be connected to ground potential through the EMC filter capacitors of the drive. This can cause danger, or damage the drive.

Checking the settings of transformers T21, T101 and T

Check the tap settings of all auxiliary voltage transformers. Transformer T21 is stand equipment; T101 and T111 are present depending on drive configuration.

The voltage settings of transformers T21 and T101 are made at terminal blocks T21_X1/X2 and T101_X1/X2 respectively. The settings of transformer T111 are made on the transformer itself. The locations of the transformers and the terminal block are shown in section [Operation principle and hardware description \(page](#)

■ T21 and T101 tap settings (400...500 V units)

T21_X1			
T101_X1			
500 V	1		1
480 V	2		
460 V	3		
440 V	4		
415 V	5		2
400 V	6		3
380 V	7		
			4
U1	8		5
TP1	9		
TP2	10		

118 Electrical installation

■ T21 and T101 tap settings (690 V units)

T21_X1 T101_X1		T21_X2 T101_X2	
690 V	1	1	230 V
660 V	2		
600 V	3		
575 V	4		
540 V	5	2	
525 V	6	3	
	7		
		4	N
U1	8	5	
TP1	9		
TP2	10		

Electrical ins

■ T111 tap settings

3~ input

3~ output

Supply voltage	Terminals	Tap settings			400 V (50 Hz)
		A1–	B1–	C1–	
690 V	A1, B1, C1	C2	A2	B2	a1, b1, c1
660 V	A1, B1, C1	C2	A2	B2	a1, b1, c1
600 V	A1, B1, C1	C3	A3	B3	a1, b1, c1
575 V	A1, B1, C1	C3	A3	B3	a1, b1, c1
540 V	A1, B1, C1	C4	A4	B4	a1, b1, c1
525 V	A1, B1, C1	C4	A4	B4	a1, b1, c1
500 V	A1, B1, C1	C4	A4	B4	a1, b1, c1
480 V	A1, B1, C1	C5	A5	B5	a1, b1, c1

Connecting the control cables

See chapter [Control units of the drive \(page 143\)](#) for the default I/O connections of the inverter unit (with the ACS880 primary control program). The default I/O connections can be different with some hardware options. See the circuit diagrams delivered with the drive for the actual wiring. For other control programs, see their firmware manuals.

■ Control cable connection procedure

WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

1. Do the steps in section [Electrical safety precautions \(page 21\)](#) before you start the work.
2. Run the control cables into the cabinet as described in section [Grounding the outer shields of the control cables 360° at the cabinet entry \(page 120\)](#).
3. Route the control cables as described in section [Routing the control cables inside the cabinet \(page 122\)](#).
4. Connect the control cables as described in section [Connecting control cabling \(page 122\)](#).

Grounding the outer shields of the control cables 360° at the cabinet entry

Ground the outer shields of all control cables 360° with the EMI conductive cushions at the cabinet entry. The grounding principle is the same for top and bottom entry cables. The figures show the bottom entry. The actual design details can vary.

1. If necessary, remove the shrouding in front of the cable entry.
2. Put the cables in sequence from the smallest to the largest. This will help to achieve a good contact with the cushions.
3. Loosen the tightening bolts of the EMI conductive cushions and pull them apart.
4. Cut holes in the grommets and put the cables through the grommets.
5. Peel the insulation from the part of the cable that will be in contact with the EMI conductive cushion.
6. Put the cables between the cushions and attach them with cable ties for strain relief.
7. Move the cushions back together.
8. Tighten the bolts to make sure that the EMI conductive cushions press tightly around the peeled part of the cables.

If the outer surface of the shield is non-conductive:

- Cut the shield at the midpoint of the peeled part. Be careful not to cut the conductors or the grounding wire.
- Turn the conductive side of the shield inside out over the insulation.
- Cover the exposed shield and the peeled cable with copper foil to keep the shield continuous.

A	B	C	A	
			B	Stripped cable
			C	Conductive surface of the shield exposed
				Stripped part covered with copper foil
1	2	3	1	Cable shield
		4	2	Copper foil
			3	Shielded twisted pair
			4	Grounding wire

Routing the control cables inside the cabinet

Use the existing trunking in the cabinet where possible. Use sleeving if cables are laid against sharp edges. When running cables to or from a swing-out frame, leave enough slack at the hinge to allow the frame to open fully.

Connecting control cabling

Connect the conductors to the appropriate terminals. Refer to the wiring diagrams delivered with the drive.

With option +L504, the terminals of the inverter control unit are available on terminal block X504.

Obey these instructions:

- Connect the inner twisted pair shields and all separate grounding wires to the grounding clamps near the terminals.
- Ground the outer shield of the cable at the cable entry, not at the grounding clamps near the terminals.
- Keep any signal wire pairs twisted as close to the terminals as possible. Twisting the wire with its return wire reduces disturbances caused by inductive coupling.
- At the other end of the cable, leave the shields unconnected or ground them indirectly via a high-frequency capacitor with a few nanofarads, eg. 3.3 nF / 630 V. The shield can also be grounded directly at both ends if they are in the same ground line with no significant voltage drop between the end points.

Electrical ins


The drawing below represents the grounding of the control cabling when connected to a terminal block inside the cabinet. The grounding is done in the same way when connecting directly to a component such as the control unit.

Connecting the motor cables (units without common motor terminal cubicle or sine output filter)

On units without a common motor terminal cubicle or a sine output filter, the motor cables connect to busbars located behind the inverter module(s). The location and dimensions of the busbars are shown in the dimension drawings delivered with the drive and in the example drawings in this manual.

■ Motor connection diagram (without option +H366)

All parallel-connected inverter modules are to be cabled separately to the motor. 360° grounding must be used at the cable entries.



Inverter unit cubicle(s)

The recommended cable types are given in the technical data.

WARNING!


The cabling from all inverter modules to the motor must be physically identical considering cable type, cross-sectional area, and length.



Inverter unit cubicle(s)

■ Motor connection diagram (with option +H366)

With option +H366, the output busbars of the inverter modules within the same cubicle are connected by bridging busbars. The bridging balances the motor current between the modules, which allows more cabling options. For example, it is possible to use a number of cables that could not otherwise be evenly distributed between the inverter modules.



The recommended cable types are given in the technical data.

WARNING!

The bridging can carry the nominal output of one inverter module. In case of three parallel modules, make sure that the load capacity of the bridging is not exceeded. For example, if the cabling connects to the output busbars at one module only, use the module in the middle.

Note: The +H366 option only interconnects the outputs of inverter modules within the same cubicle, not modules installed in different cubicles. Therefore, when the drive has multiple inverter cubicles (ie. two cubicles of two modules each), make sure that the motor cabling is identical for both cubicles.

■ **Procedure**

To get more space for cabling work, you can remove the inverter modules or the fan carriages of each module. Especially in the case of multiple inverter modules in the same cubicle, you can consider only removing the fan carriages. This is faster than removing the entire module, but gives less free space for the work than removing the module.

Removing an inverter module

Refer to section [Removing an inverter module \(page 202\)](#).

Removing the fan carriage of an inverter module

Refer to the drawings below.

WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

126 Electrical installation

3. Remove the screws holding the front cover plate. Lift the cover plate somewhat to release it.
4. Disconnect the wiring at the top of the fan carriage.
5. Remove the two screws at the bottom of the fan carriage.

WARNING!

Before you proceed, make sure the two screws holding the top of the inverter module are in place.

6. Remove the two screws at the top of the fan carriage. (During reassembly, tighten these screws to 22 N·m [16 lbf·ft].)

Note: Units with marine or seismic design have an additional transverse bracket that is attached to the module with these screws. At this point, loosen the retaining screws of the bracket at the left and the right ends and remove it. (During reassembly, tighten the bracket retaining screws to 9 N·m [6.6 lbf·ft].)

7. Pull the fan carriage out.
8. Repeat the procedure for other fan carriages in the same cubicle.

Electrical ins

Electrical ins

4

5

6

Connecting the motor cables

Refer to the drawings below.

WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

1. Do the steps in section [Electrical safety precautions \(page 21\)](#) before you start the work.
2. Remove the shroud in front of the output busbars.
3. For 360° grounding of the shield at the cable entry, remove the outer jacket of each cable where they pass through the cable entry (a).
4. Cut the cable to suitable length and strip the ends of the individual conductors. Twist the shield strands together to form a separate conductor and wrap it with tape.
5. Crimp suitable lug terminals onto the phase conductors and the ground conductor. The dimensions of the output busbars are shown in chapter Technical data.
6. Connect the phase conductors of the motor cable to the U2, V2 and W2 terminals. You can temporarily remove the plastic insulators (b) between the busbars to make the connecting work easier. See [Use of fasteners in cable lug connections \(page 135\)](#).

WARNING!

The plastic insulators (b) between the busbars must be in place when the inverter is powered.

7. Connect the shield (and any grounding conductors) of the cable to the PE busbar close to the cable entries.
8. Secure the cable mechanically.
9. Repeat the procedure for other modules (if any).
10. Refit the shroud removed earlier.
11. At the motor, connect the cables according to instructions from the motor manufacturer. Pay special attention to the phase order. For minimum radio-frequency interference, ground the cable shield 360° at the cable entry of the motor terminal box, or ground the cable by twisting the shield so that the flattened shield is wider than 1/5 of its length.

Electrical ins

360° groundin

5 6

b 7

PE

2 10

Installing the fan carriage of an inverter module

(If the inverter module was removed completely instead of only the fan carriage, proceed to section [Installing an inverter module \(page 207\)](#)).

The installation of the fan carriage is the removal procedure in reverse. See section [Removing the fan carriage of an inverter module \(page 125\)](#).

Installing an inverter module

Refer to section [Installing an inverter module \(page 207\)](#).


Connecting the motor cables (units with common motor terminal cubicle or sine output filter)

■ Output busbars

If the drive is equipped with option +H359, the motor cables connect to a common motor terminal cubicle. Similarly, if the drive is equipped with option +E206 (sine output filter), the motor cables connect to the output busbars in the sine filter cubicle.

The location and dimensions of the busbars are visible in the dimensional drawings delivered with the drive.

■ Connection diagram



The recommended cable types are given in the technical data.

■ Procedure

WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

1. Do the steps in section [Electrical safety precautions \(page 21\)](#) before you start

Grommet

4. Cut the cables to suitable length. Strip the cables and conductors.
5. Twist the cable screens into bundles and connect the bundles to the PE busbar in the cubicle.
6. Connect any separate ground conductors/cables to the PE busbar in the cubicle. Refer to section [Use of fasteners in cable lug connections](#) (page 135).
7. Connect the phase conductors to the output terminals. Use the tightening torque specified in section [Tightening torques](#) (page 248).
8. Refit any shrouding removed earlier and close the cubicle doors.
9. At the motor, connect the cables according to instructions from the motor manufacturer. Pay special attention to the phase order. For minimum radio-frequency interference, ground the cable shield 360° at the cable entrance to the motor terminal box, or ground the cable by twisting the shield so that the flattened shield is wider than 1/5 of its length.

Connecting an external brake resistor assembly

See chapter [Resistor braking](#) (page 333).

For the location of the terminals, refer to the dimension drawings delivered with the unit or the dimension drawing examples in this manual.

Connecting the input power cables

■ Connection diagram, 6-pulse units

1

L1

L2

L3

PE

2

1 Fuses or other protection means for short-circuit protection of the cable.

2 Grounding of the cable shield at the cable entry (360-degree grounding).

Additional information:

- See the technical data for the dimensions of the cable entries, and the dimensions and tightening torques of the terminals.
- Use a separate PE conductor in addition if the conductivity of the shields does not meet the requirement for the PE conductor.

■ Connection diagram, 12-pulse units

1

1L1

1L2

1L3

PE

2L1

2L2

2L3

PE

2

1 Fuses or other protection means for short-circuit protection of the cable.

2 Grounding of the cable shield at the cable entry (360-degree grounding).

Additional information:

- See the technical data for the dimensions of the cable entries, and the dimensions and tightening torques of the terminals.

■ Layout of the input cable connection terminals and cable entries

The location and dimensions of the busbars are visible in the dimensional drawings delivered with the drive. Alternatively, see the example dimension drawings in the manual.

■ Connection procedure

WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

1. Do the steps in section [Electrical safety precautions \(page 21\)](#) before the work.
2. Open the door of the incoming cubicle.
3. Remove the shrouding covering the input terminals.
4. Peel off 3...5 cm (1.2 ... 2 inches) of the outer insulation of the cables above the cable entry plate for 360° high-frequency grounding.
5. Prepare the ends of the cables.

WARNING!

Apply grease to stripped aluminum conductors before you attach the non-coated aluminum cable lugs. Obey the grease manufacturer's instructions. Aluminum-aluminum contact can cause oxidation in the contact surfaces.

PE

PE

6. Remove rubber grommets from the cable entries for the cables to be connected. Cut adequate holes into the rubber grommets. Slide the grommets onto the cables. Slide the cables into the cubicle through the conductive sleeves and attach the grommets to the holes.

134 Electrical installation

7. Attach the conductive sleeves to the cable shields with cable ties. Tie up the unused conductive sleeves with cable ties.

8. Connect the twisted shields of the cables to the PE busbar of the cabinet.
9. Connect the phase conductors of the input cable to the L1, L2 and L3 terminals. (With 12-pulse connection, the terminals are 1L1, 1L2 and 1L3 for one 6-pulse supply line, 2L1, 2L2 and 2L3 for the other.) See [Use of fasteners in cable lug connections \(page 135\)](#). Tighten the screws to the torque given under [Tightening](#)

Use of fasteners in cable lug connections

Use the bolts, nuts and washers delivered with the drive. Install all the fasteners in the correct order. See the figure below. Tighten the cable lug to the torque specified for the connection.

Cable lug on one side of the busbar

1 2 3 4 2 5 6

Cable lugs on both sides of the busbar

1 5 2 4 3 4 2 5 6

- | | | | |
|---|--------------|---|---------------|
| 1 | Bolt | 4 | Cable lug |
| 2 | Plain washer | 5 | Spring washer |
| 3 | Busbar | 6 | Nut |

Connecting a PC

WARNING!

Do not connect the PC directly to the control panel connector of the control unit. It can cause damage.

A PC (with, for example, the Drive composer PC tool) can be connected as follows:

- To connect a control panel to the unit, either
 - insert the control panel into the panel holder or platform, or
 - use an Ethernet (eg, Cat 5e) networking cable.
- Remove the USB connector cover on the front of the control panel.
- Connect an USB cable (Type A to Type Mini-B) between the USB connector on



Panel bus (control of several units from one control panel)

One control panel (or PC) can be used to control several drives (or inverter units, supply units etc.) by constructing a panel bus. This is done by daisy-chaining the panel connections of the drives. Some drives have the necessary (twin) panel connectors in the control panel holder; those that do not require the installation of an FDPI-02 module (available separately). For further information, see the hardware description and [FDPI-02 diagnostics and panel interface user's manual \(3AUA0000113618 \[English\]\)](#).

The maximum allowed length of the cable chain is 100 m (328 ft).

- Connect the panel to one drive using an Ethernet (for example Cat 5e) cable.
 - Use Menu - Settings - Edit texts - Drive to give a descriptive name to the drive
 - Use parameter 49.01* to assign the drive with a unique node ID number
 - Set other parameters in group 49* if necessary
 - Use parameter 49.06* to validate any changes.

*The parameter group is 149 with supply (line-side), brake or DC/DC converter units.
Repeat the above for each drive.
- With the panel connected to one unit, link the units using Ethernet cables.
- Switch on the bus termination on the drive that is farthest from the control panel in the chain.
 - With drives that have the panel mounted on the front cover, move the terminating switch into the outer position.
 - With the FDPI-02 module and BCU-02 control unit: move termination switch S1 on the FDPI-02 module into the TERMINATED position.
 - With the FDPI-02 module and UCU-22...24 control unit: move termination switch S1 on the FDPI-02 module into the OPEN position. Move control panel connection termination switch XPAN TERM on the UCU-22...24 control unit to ON position.

Make sure that bus termination is off on all other drives.

- On the control panel, switch on the panel bus functionality (Options - Select drive - Panel bus). The drive to be controlled can now be selected from the list under Options - Select drive

Electrical ins

With twin connectors in the control panel holder:

1

2

3

1

138 Electrical installation

With FDPI-02 modules and BCU control unit:

1

1

2

2

3

Installing option modules

■ Mechanical installation of I/O extension, fieldbus adapter and pulse encoder interface modules

See hardware description for the available slots for each module. Install the option modules as follows:

WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

1. Stop the drive and do the steps in section [Electrical safety precautions](#) before you start the work.
2. Open the door of the auxiliary control cubicle (ACU).
3. Remove the shrouding at the top of the cubicle.
4. Locate the inverter control unit (A41).
5. Insert the module carefully into its position on the control unit.
6. Fasten the mounting screw.

Note: The screw secures and grounds the module. It is essential for fulfilling the EMC requirements and for proper operation of the module.

■ Installation of an FSO safety functions module onto BCU

WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

This procedure describes the installation of an FSO safety functions module onto the BCU control unit. As an alternative, the FSO module can be installed adjacent to the inverter control unit, which is the standard method for factory-installed FSO modules. For more instructions, refer to the applicable FSO module user's manual.

1. Stop the drive and do the steps in section [Electrical safety precautions](#) before you start the work.
2. The FSO module comes with alternative bottom plates for installation onto different control units. For installation onto a BCU control unit, the mounting points should be located at the long edges of the module as shown in the illustration below. If necessary, replace the bottom plate of the FSO module

140 Electrical installation

3. Attach the FSO module onto slot 3 of the BCU control unit [A41] with four screws.

4. Torque the FSO module electronics grounding screw to 0.8 N·m (7.1 lbf·in).

Note: The screw tightens the connections and grounds the module. It is essential for fulfilling the EMC requirements and for proper operation of the module.

5. Connect the FSO module data cable between FSO connector X110 and BCU connector X12.
6. To complete the installation, refer to the instructions in the applicable FSO module user's manual.

- **Wiring of option modules**

See the applicable optional module manual for specific installation and wiring instructions.

Control units of the drive

Contents of this chapter

This chapter

- describes the connections of the control unit(s) used in the drive,
- contains the specifications of the inputs and outputs of the control unit.

General

The drive utilizes either BCU-x2 control units or UCU-22...24 control units.

The supply and inverter units of the drive are each controlled by a dedicated control unit. The designation of the supply control unit is A51; the inverter control unit is A52. Both are connected to the power modules (ie. supply and inverter modules respectively) by fiber optic cables.

In this manual:

- the name "BCU-x2" represents the control unit types BCU-02 and BCU-07. They have a different number of power module connections (2 and 7 respectively) but are otherwise similar.
- the name "UCU-22...24" represents the control unit types UCU-22 and UCU-24.

BCU layout

	Description
I/O	I/O terminals (see following diagram)
SLOT 1	I/O extension, encoder interface or fieldbus adapter module connection. (This is the sole location for an FDPI-02 diagnostics and panel interface.)
SLOT 2	I/O extension, encoder interface or fieldbus adapter module connection
SLOT 3	I/O extension, encoder interface, fieldbus adapter or FSO safety functions module connection
SLOT 4	RDCO-0x DDCS communication optional module connection
X205	Memory unit connection
BATTERY	Holder for real-time clock battery (BR2032)
AI1	Mode selector for analog input AI1 (I = current, U = voltage)
AI2	Mode selector for analog input AI2 (I = current, U = voltage)
D2D TERM	Termination switch for drive-to-drive (D2D)
DICOM= DIOGND	Ground selection. Determines whether DICOM is separated from DIOGND (ie. the common reference for the digital inputs floats). See the ground isolation diagram.

7-segment display

Multicharacter indications are displayed as repeated sequences of characters

("U" is indicated briefly before "o".)

Control program running

Control program startup in progress

(Flashing) Firmware cannot be started
Memory unit missing or corrupted

Firmware download from PC to control unit in progress

Control unit

			Description
XRO3	XD24	XPOW	XAI Analog inputs
			XAO Analog outputs
			XDI Digital inputs, Digital inputs
XRO2	XDIO	XAO	XDIO Digital input/outputs
			XD2D Drive-to-drive link
			XD24 +24 V output (for digital inputs)
XRO1	XDIO	XAO	XETH Ethernet port – Not in use
			XPOW External power input
			XRO1 Relay output RO1
X485	XDI	XAI	XRO2 Relay output RO2
			XRO3 Relay output RO3
			XSTO Safe torque off connection
XD2D	XSTO	XSTO OUT	XSTO OUT Safe torque off connection (for digital modules)
			X12 (On the opposite side) Connection to safety functions module
			X13 Control panel / PC connection
			X485 Not in use
			V1T/V1R, V2T/V2R Fiber optic connection to BCU-12/22 (VxT = transmitter, VxR = receiver)
			V3T/V3R Fiber optic connection to BCU-12/22 (VxT = transmitter, VxR = receiver)
			... (BCU-12/22 only)
			V7T/V7R Fiber optic connection to BCU-22 (VxT = transmitter, VxR = receiver)
			V8T/V8R Fiber optic connection to BCU-22 (VxT = transmitter, VxR = receiver)
			... (BCU-22 only)
			V12T/V12R Fiber optic connection to BCU-22 (VxT = transmitter, VxR = receiver)
			SD CARD Data logger memory card for module communication
			BATT OK Real-time clock battery voltage > 2.8 V. If the LED is on, the control unit is powered, replace the battery.
			FAULT The control program has detected a fault. See the firmware manual for the inverter unit.
			PWR OK Internal voltage supply is OK
			WRITE Writing to memory card. Do not remove the memory card.

Default I/O diagram of the supply control unit (BCU-x2)

The diagram below shows the default I/O connections on the supply control unit (A51), and describes the use of the connections in the supply unit. Under normal circumstances, the factory-made wiring should not be changed.

The wire size accepted by all screw terminals (for both stranded and solid wire) is 0.5 ... 2.5 mm² (22...12 AWG). The tightening torque is 0.45 N·m (4 lbf·in).

Terminal			Description	
XD2D			Drive-to-drive link	
1	1	B		
2	2	A		
3	3	BGND	Not in use by default	
4	4	Shield		
	D2D.TERM		Drive-to-drive link termination switch	1)
X485			RS485 connection	
5	5	B		
6	6	A		
7	7	BGND	Not in use by default	
8	8	Shield		
XRO1, XRO2, XRO3			Relay outputs	
	11	NC	Norm. closed	
11	12	COM	Common	XRO1: Running 2) (Energized = running) 250 V AC / 30 V DC, 2 A
12	13	NO	Norm. open	
13	21	NC	Norm. closed	
21	22	COM	Common	XRO2: Fault (-1) 2) (Energized = no fault) 250 V AC / 30 V DC, 2 A
22	23	NO	Norm. open	
23	31	NC	Norm. closed	
31	32	COM	Common	XRO3: MCB ctrl 3) (Energized = closed) main contactor/breaker) 250 V AC / 30 V DC, 2 A
32	33	NO	Norm. open	
	33	NO	Norm. open	
XSTO, XSTO OUT			Safe torque off	4)
	1	OUT		
1	2	SGND	XSTO: Factory connection. Both circuits must be closed for the drive to start (IN1 and IN2 must be connected to OUT).	
2	3	IN1		
3	4	IN2		
4	5	IN1		
5	5	IN1		

Terminal			Description
1	1	DI1	Temp fault ²⁾ (0 = overtemperature)
2	2	DI2	Run enable ²⁾ (1 = run enable)
3	3	DI3	MCB feedback ³⁾ (0 = main contactor/breaker open)
4	4	DI4	Auxiliary circuit breaker fault ²⁾
5	5	DI5	Not in use by default. Can be used for eg. earth fault monitoring
6	6	DI6	Reset ²⁾ (0 -> 1 = fault reset)
7	7	DIIL	Not in use by default. Can be used for eg. emergency stop.
XDIO			Digital input/outputs
1	1	DIO1	Not in use by default
2	2	DIO2	Not in use by default
3	3	DIOGND	Digital input/output ground
4	4	DIOGND	Digital input/output ground
XD24			Auxiliary voltage output
5	5	+24VD	+24 V DC 200 mA ⁵⁾
6	6	DICOM	Digital input ground
7	7	+24VD	+24 V DC 200 mA ⁵⁾
8	8	DIOGND	Digital input/output ground
		DICOM=DIOGND	Ground selection switch ⁶⁾
XAI			Analog inputs, reference voltage output
1	1	+VREF	10 V DC, $R_L \geq 1...10 \text{ kohm}$
2	2	-VREF	-10 V DC, $R_L \geq 1...10 \text{ kohm}$
3	3	AGND	Ground
4	4	AI1+	Not in use by default. 0(2)...10 V, $R_{in} > 200 \text{ kohm}$ ⁷⁾
5	5	AI1-	
6	6	AI2+	Not in use by default. 0(4)...20 mA, $R_{in} = 100 \text{ ohm}$ ⁸⁾
7	7	AI2-	
		AI1	AI1 current/voltage selection switch
		AI2	AI2 current/voltage selection switch
XAO			Analog outputs
1	1	AO1	Zero (no signal indicated) ²⁾ 0...20 mA, $R_L < 500 \text{ ohm}$
2	2	AGND	
3	3	AO2	Zero (not signal indicated) ²⁾ 0...20 mA, $R_L < 500 \text{ ohm}$
4	4	AGND	

148 Control units of the drive

Terminal	Description
X205	Memory unit connection
<p>1) Must be set to ON when the supply unit is the first or last unit on the drive-to-drive (D2D) link. On intermediate units, set termination to OFF.</p> <p>2) Default use of the signal in the control program. The use can be changed by a parameter. See also the delivery-specific circuit diagrams.</p> <p>3) Use of the signal in the control program (fixed). See also the delivery-specific circuit diagrams.</p> <p>4) This input only acts as a true Safe torque off input in inverter units. In other applications (such as a supply or brake unit), de-energizing the IN1 and/or IN2 terminal will stop the unit but not constitute a true safety function.</p> <p>5) Total load capacity of these outputs is 4.8 W (200 mA at 24 V) minus the power taken by DIO1 and DIO2.</p> <p>6) Determines whether DICOM is separated from DIOGND (ie, common reference for digital inputs floats). ON: DICOM connected to DIOGND. OFF: DICOM and DIOGND separate.</p> <p>7) Current [0(4)...20 mA, $R_{in} = 100 \text{ ohm}$] or voltage [0(2)...10 V, $R_{in} > 200 \text{ kohm}$] input selected by switch AI1. Change of setting requires reboot of control unit.</p> <p>8) Current [0(4)...20 mA, $R_{in} = 100 \text{ ohm}$] or voltage [0(2)...10 V, $R_{in} > 200 \text{ kohm}$] input selected by switch AI2. Change of setting requires reboot of control unit.</p>	

Default I/O diagram of the inverter control unit (BC)

The table below describes the use of the connections in the inverter unit. Under different circumstances, the factory-made wiring should not be changed.

The wire size accepted by all screw terminals (for both stranded and solid wire) is 0.5 ... 2.5 mm² (22...12 AWG). The tightening torque is 0.45 N·m (4 lbf·in).

Terminal			Description	
XD2D			Drive-to-drive link	
1	1	B	Drive-to-drive link. Refer to section The XD2D connection	
2	2	A		
3	3	BGND		
4	4	Shield		
D2D.TERM			Drive-to-drive link termination switch. Must be set to ON when unit is the first or last unit in the drive-to-drive (D2D) link. On intermediate units, set termination to OFF.	
X485			RS485 connection	
5	5	B	Not in use by default	
6	6	A		
7	7	BGND		
8	8	Shield		
XRO1, XRO2, XRO3			Relay outputs	
	11	NC	Norm. closed	XRO1: Ready (Energized) 250 V AC / 30 V DC, 2 A
11	12	COM	Common	
12	13	NO	Norm. open	
13	21	NC	Norm. closed	XRO2: Running (Energized) 250 V AC / 30 V DC, 2 A
21	22	COM	Common	
22	23	NO	Norm. open	
23	31	NC	Norm. closed	XRO3: Fault (-1) (Energized) 250 V AC / 30 V DC, 2 A
31	32	COM	Common	
32	33	NO	Norm. open	
XSTO, XSTO OUT			Safe torque off	
	1	OUT	XSTO: Factory connection. Both circuits must be closed for start (IN1 and IN2 must be connected to OUT). Refer to chapter torque off function.	
1	2	SGND		
2	3	IN1		
3	4	IN2		
4	5	IN1		

150 Control units of the drive

Terminal			Description
1 2 3 4 5 6 7	1	DI1	Stop (0) / Start (1)
	2	DI2	Forward (0) / Reverse (1)
	3	DI3	Reset
	4	DI4	Acceleration & deceleration select ¹⁾
	5	DI5	Constant speed 1 select (1 = on) ²⁾
	6	DI6	Not in use by default.
	7	DIIL	Run enable ³⁾
XDIO			Digital input/outputs
1	1	DIO1	Output: Ready
2	2	DIO2	Output: Running
3	3	DIOGND	Digital input/output ground
4	4	DIOGND	Digital input/output ground
XD24			Auxiliary voltage output
5	5	+24VD	+24 V DC 200 mA ⁴⁾
6	6	DICOM	Digital input ground
7	7	+24VD	+24 V DC 200 mA ⁴⁾
8	8	DIOGND	Digital input/output ground
			Ground selection switch. Determines whether DICOM is separated from DIOGND (ie, common reference for digital inputs floats). ON: DICOM connected to DIOGND. OFF: DICOM and DIOGND separate.
DICOM=DIOGND			
XAI			Analog inputs, reference voltage output
1	1	+VREF	10 V DC, $R_L \geq 1 \dots 10 \text{ kohm}$
2	2	-VREF	-10 V DC, $R_L \geq 1 \dots 10 \text{ kohm}$
3	3	AGND	Ground
4	4	AI1+	Speed reference. 0(2)...10 V, $R_{in} > 200 \text{ kohm}$ ⁵⁾
5	5	AI1-	
6	6	AI2+	Not in use by default. 0(4)...20 mA, $R_{in} = 100 \text{ ohm}$ ⁶⁾
7	7	AI2-	
AI1			AI1 current/voltage selection switch
AI2			AI2 current/voltage selection switch
XAO			Analog outputs
1	1	AO1	Motor speed rpm 0 ... 20 mA, $R_L < 500 \text{ ohm}$
2	2	AGND	
3	3	AO2	

Terminal	Description
X205	Memory unit connection
<p>1) 0 = Acceleration/deceleration ramps defined by parameters 23.12/23.13 in use. 1 = Acceleration/deceleration ramps defined by parameters 23.14/23.15 in use.</p> <p>2) Constant speed 1 is defined by parameter 22.26.</p> <p>3) The DIIL input is configured to stop the unit when the input signal is removed. This input does not have a SIL classification.</p> <p>4) Total load capacity of these outputs is 4.8 W (200 mA at 24 V) minus the power taken by DIO1 and DIO2.</p> <p>5) Current [0(4)...20 mA, $R_{in} = 100\text{ ohm}$] or voltage [0(2)...10 V, $R_{in} > 200\text{ kohm}$] input selected by of setting requires reboot of control unit.</p> <p>6) Current [0(4)...20 mA, $R_{in} = 100\text{ ohm}$] or voltage [0(2)...10 V, $R_{in} > 200\text{ kohm}$] input selected by of setting requires reboot of control unit.</p>	

152 Control units of the drive

The diagram below shows the default I/O connections on the inverter control unit (A41).

XRO1...XRO3		
NC	11	
COM	12	
NO	13	
NC	21	
COM	22	
NO	23	
NC	31	1)
COM	32	
NO	33	
XSTO		
OUT	1	
SGND	2	2)
IN1	3	
IN2	4	
XDI		
D ^{1I}	1	
D ^{2I}	2	
D ^{3I}	3	
DI4	4	
DI5	5	
D ^{6I}	6	
DIIL	7	
XD24		
+24VD	5	
D ^{CI} OM	6	
+24VD	7	
I ^D OGND	8	
XAI		
+VREF	1	
V-REF	2	
AGND	3	
AI1+	4	
AI1-	5	
AI2+	6	
AI2-	7	
XAO		
AO1	1	
AGND	2	

UCU-22...24 layout

	Description
I/O	I/O terminals
SLOT 1	I/O extension, encoder in adapter module connection modules with USCA-02 a
SLOT 2	I/O extension, encoder in adapter module connection modules with USCA-02 a
SLOT 3	I/O extension, encoder in adapter module connection modules with USCA-02 a
SLOT 4	RDCO-0x DDCCS commu module connection
MEM	UMU-01 memory unit co microSDHC memory car communication is inside
BAT	Holder for real-time clock
XD2D TERM	Termination switches for (XD2D)
X485 TERM	RS-485 link termination s
X485 BIAS	RS-485 link bias switch.
DICOM= DIOGND	Ground selection. Determ is separated from DIOGN reference for the digital in to the ground isolation di
LED	Description
PWR	When the PWR LED is on, is sufficient.
BAT	When the BAT LED is on, battery voltage is higher th is off, replace the battery
WRITE	When the WRITE LED is o microSDHC memory car not remove the microSD
FAULT	The control program has Refer to the firmware ma
FS COMM	Reserved.
FS STATUS	Reserved.

154 Control units of the drive

			Description
XRO4	XD24	XPOW	XAI Analog input
			XAO Analog output
XRO3	XDIO	XAO	XCAN Not in use
			XCAN TERM CAN bus termination switch
XRO2			XDI Digital input
	XDI	XAI	XDIO Digital input/output
XRO1			XD2D Drive-to-drive link
			XD24 +24 V output (for digital input)
X485	XSTO	XSTO OUT	XETH1 Ethernet ports for fieldbus, internal switch
			XETH2
			XETH3 Ethernet ports for tool communication, internal switch
			XETH4
XD2D	XCAN		XPAN Control panel connection
			XPAN TERM Panel bus termination switch
			XPOW External power input
			XRO1 Relay output RO1
			XRO2 Relay output RO2
			XRO3 Relay output RO3
			XRO4 Relay output RO4, reserved.
			XSTO Safe torque off connection (input signals)
			XSTO OUT Safe torque off connection (to inverter module)
			X485 RS-485 link
			V1T/V1R Fiber optic connections to converter modules
			... (VxT = transmitter, VxR = receiver)
			V14T/V14R

Control unit

1

Description

XFSO	Not in use
Environmental sensors (1)	Humidity and temperature m

XFSO

Default I/O diagram of the supply control unit (UCU-22...24)

The diagram below shows the default I/O connections on the supply control unit (A51), and describes the use of the connections in the supply unit. Under normal circumstances, the factory-made wiring should not be changed.

The wire size accepted by all screw terminals (for both stranded and solid wire) is 0.5 ... 2.5 mm² (22...12 AWG). The tightening torque is 0.45 N·m (4 lbf·in).

Terminal			Description
XD2D			Drive-to-drive link
1	1	B	Not in use by default
2	2	A	
3	3	BGND	
4	4	SHIELD	
XD2D TERM			Drive-to-drive link termination switch.
X485			RS485 connection
5	5	B	Not in use by default
6	6	A	
7	7	BGND	
8	8	SHIELD	
X485 BIAS			X485 bias selection switch
X485 TERM			X485 termination switch
XCAN			CAN bus
9	9	CANH	Not supported
10	10	CANL	
11	11	CGND	
12	12	SHIELD	Control cable shield
XCAN TERM			CANopen termination switch
XRO1			Relay output 1
11	11	NC1	Norm. closed
12	12	NO1	Norm. open

Terminal			Description	
31	31	NC3	Norm. closed	XRO3: MCB ctrl ²⁾ (E main contactor/breaker) 250 V AC / 30 V DC, 2 A
32	32	COM3	Common	
33	33	NO3	Norm. open	
XRO4			Relay output 4	XRO4: Not supported 250 V AC / 30 V DC, 2 A
41	41	NC4	Norm. closed	
42	42	COM4	Common	
43	43	NO4	Norm. open	
XSTO			Safe torque off ³⁾	
1	1	OUT		
2	2	SGND	XSTO: Factory connection. Both circuits must be closed for the unit to start (STO1 and STO2 must be connected to OUT).	
3	3	STO1		
4	4	STO2		
XSTO OUT			Safe torque off connection	
5	5	OUT1		
6	6	SGND	XSTO OUT: Not in use.	
7	7	OUT2		
8	8	SGND		
XDI			Digital inputs	
	1	DI1	Temp fault ¹⁾ (0 = overtemperature)	
1	2	DI2	Run / enable ¹⁾ (1 = run / enable)	
2	3	DI3	MCB feedback ²⁾ (0 = main contactor/breaker open)	
3	4	DI4	Auxiliary circuit breaker fault ¹⁾	
4	5	DI5	Not in use by default. Can be used for eg, earth fault monitoring	
5	6	DI6	Reset ¹⁾	
6	7	DI6	(0 -> = fault reset)	
	7	DIIL	Not in use by default. Can be used for eg, emergency stop.	
XDIO			Digital input/outputs	
1	1	DIO1	Not in use by default	
2	2	DIO2	Not in use by default	
3	3	DIOGND	Digital input/output ground	
4	4	DIOGND	Digital input/output ground	
XD24			Auxiliary voltage output	
5	5	+24VD	+24 V DC 200 mA ⁴⁾	
6	6	DICOM	Digital input ground	

158 Control units of the drive

Terminal			Description
XAI			Analog inputs, reference voltage output
1	1	+VREF	10 V DC, R_L 1...10 kohm
2	2	-VREF	-10 V DC, R_L 1...10 kohm
3	3	AGND	Ground
4	4	AI1+	Not in use by default. 0(2)...10 V, $R_{in} > 200$ kohm 5)
5	5	AI1-	
6	6	AI2+	Not in use by default. 0(4)...20 mA, $R_{in} = 100$ ohm 6)
7	7	AI2-	
XAO			Analog outputs
1	1	AO1	Zero (no signal indicated) 1) 0...20 mA, $R_L < 500$ ohm
2	2	AGND	
3	3	AO2	Zero (not signal indicated) 1) 0...20 mA, $R_L < 500$ ohm
4	4	AGND	
XPOW			External power input
	1	+24V	24 V DC, 2.05 A
	2	GND	
	3	+24V	
	4	GND	
XFSO			Safety functions module connection. Not in use by default.
XETH1			Ethernet ports for fieldbus. Not in use by default.
XETH2			
XETH3			
XETH4			Ethernet ports for tool communication. Not in use by default.
XPAN			Control panel connection
	XPAN TERM		Control panel connection termination switch
MEM			Memory unit connection

1) Default use of the signal in the control program. The use can be changed by a parameter. For the delivery-specific use, see the delivery-specific circuit diagrams.

2) Use of the signal in the control program. The use is fixed and it cannot be changed by a parameter.

3) This input only acts as a true Safe torque off input in inverter units. In other applications (such as a supply or brake unit), de-energizing the STO1 and/or STO2 terminal will stop the unit but not constitute a SIL/PL classified safety function.

4) Total load capacity of these outputs is 4.8 W (200 mA at 24 V) minus the power taken by DIO1 and DIO2.

5) Current [0(4)...20 mA, $R_{in} = 100$ ohm] or voltage [0(2)...10 V, $R_{in} > 200$ kohm]. Change of setting requires reboot control unit.

6) Current [0(4)...20 mA, $R_{in} = 100$ ohm] or voltage [0(2)...10 V, $R_{in} > 200$ kohm]. Change of setting requires reboot control unit.

Default I/O diagram of the inverter control unit (UCU-22...24)

The table below describes the use of the connections in the inverter unit. Under certain circumstances, the factory-made wiring should not be changed.

The wire size accepted by all screw terminals (for both stranded and solid wire) is 0.5 ... 2.5 mm² (22...12 AWG). The tightening torque is 0.45 N·m (4 lbf·in).

Terminal			Description
XD2D			Drive-to-drive link
1	1	B	Drive-to-drive link. Refer to section The XD2D connection
2	2	A	
3	3	BGND	
4	4	SHIELD	
XD2D.TERM			Drive-to-drive link termination switch.
X485			RS485 connection
5	5	B	Not in use by default
6	6	A	
7	7	BGND	
8	8	SHIELD	
X485 BIAS			X485 bias selection switch
X485 TERM			X485 termination switch
XCAN			CAN bus
9	9	CANH	Not supported
10	10	CANL	
11	11	CGND	
12	12	SHIELD	Control cable shield
XCAN TERM			CANopen termination switch
XRO1			Relay output 1
11	11	NC1	Norm. closed
12	12	COM1	Common
13	13	NO1	Normally open

XRO1: Ready (Energiz
250 V AC / 30 V DC, 2 A

160 Control units of the drive

Terminal			Description	
31	31	NC3	Norm. closed	XRO3: Fault (-1) (Energized = No fault) 250 V AC / 30 V DC, 2 A
32	32	COM3	Common	
33	33	NO3	Norm. open	
XRO4			Relay output 4	XRO4: Not supported 250 V AC / 30 V DC, 2 A
41	41	NC4	Norm. closed	
42	42	COM4	Common	
43	43	NO4	Norm. open	
XSTO			Safe torque off	XSTO: Factory connection. Both circuits (power module, control unit) must be closed for the drive to start (STO1 and STO2 must be connected to OUT). Refer to chapter The Safe torque off function (page 307).
1	1	OUT		
2	2	SGND		
3	3	STO1		
4	4	STO2		
XSTO OUT			Safe torque off connection (to inverter modules)	XSTO OUT: Safe torque off output to inverter modules
5	5	OUT1		
6	6	SGND		
7	7	OUT2		
8	8	SGND		
XDI			Digital inputs	
	1	DI1	Stop (0) / Start (1)	
1	2	DI2	Forward (0) / Reverse (1)	
2	3	DI3	Reset	
3	4	DI4	Acceleration & deceleration select ¹⁾	
4	5	DI5	Constant speed 1 select (1 = on) ²⁾	
5	6	DI6	Not in use by default.	
6	7	DIIL	Run enable ³⁾	
XDIO			Digital input/outputs	
1	1	DIO1	Output: Ready	
2	2	DIO2	Output: Running	
3	3	DIOGND	Digital input/output ground	
4	4	DIOGND	Digital input/output ground	
XD24			Auxiliary voltage output	
5	5	+24VD	+24 V DC 200 mA ⁴⁾	
6	6	DICOM	Digital input ground	

Terminal			Description
XAI			Analog inputs, reference voltage output
1	1	+VREF	10 V DC, $R_L \geq 1 \dots 10 \text{ kohm}$
2	2	-VREF	-10 V DC, $R_L \geq 1 \dots 10 \text{ kohm}$
3	3	AGND	Ground
4	4	AI1+	Speed reference. 0(2)...10 V, $R_{in} > 200 \text{ kohm}$ ⁵⁾
5	5	AI1-	
6	6	AI2+	Not in use by default. 0(4)...20 mA, $R_{in} = 100 \text{ ohm}$ ⁶⁾
7	7	AI2-	
XAO			Analog outputs
1	1	AO1	Motor speed rpm 0 ... 20 mA, $R_L < 500 \text{ ohm}$
2	2	AGND	
3	3	AO2	Motor current 0 ... 20 mA, $R_L < 500 \text{ ohm}$
4	4	AGND	
XPOW			External power input
	1	+24V	24 V DC, 2.05 A Two supplies can be connected for redundancy.
	2	GND	
	3	+24V	
	4	GND	
XFSO			Safety functions module connection. Not in use by default.
XETH1			Ethernet ports for fieldbus. Not in use by default.
XETH2			
XETH3			Ethernet ports for tool communication. Not in use by default.
XETH4			
XPAN			Control panel connection
	XPAN TERM		Control panel connection termination switch
MEM			Memory unit connection

1) 0 = Acceleration/deceleration ramps defined by parameters 23.12/23.13 in use.

1 = Acceleration/deceleration ramps defined by parameters 23.14/23.15 in use.

2) Constant speed 1 is defined by parameter 22.26.

3) The DIIL input is configured to stop the unit when the input signal is removed. This input does not have a SIL classification.

4) Total load capacity of these outputs is 4.8 W (200 mA at 24 V) minus the power taken by DIO1 and DIO2.

5) Current [0(4)...20 mA, $R_{in} = 100 \text{ ohm}$] or voltage [0(2)...10 V, $R_{in} > 200 \text{ kohm}$]. Change of setting in control unit.6) Current [0(4)...20 mA, $R_{in} = 100 \text{ ohm}$] or voltage [0(2)...10 V, $R_{in} > 200 \text{ kohm}$]. Change of setting in control unit.

162 Control units of the drive

The diagram below shows the default I/O connections on the inverter control unit (A41).

XRO1...XRO4		
NC1	11	
COM1	12	
NO1	13	
NC2	21	
COM2	22	
NO2	23	
NC3	31	1)
COM3	32	
NO3	33	
NC4	41	
COM4	42	
NO4	43	
XSTO		
OUT	1	
SGND	2	2)
STO1	3	
STO2	4	
XDI		
D ^{1 I}	1	
D ^{2 I}	2	
D ^{3 I}	3	
DI4	4	
DI5	5	
D ^{6 I}	6	
DIIL	7	
XD24		
+24VD	5	
D ^{C I} OM	6	
+24VD	7	
I ^D OGND	8	
XAI		
+VREF	1	
V-REF	2	
AGND	3	
AI1+	4	
AI1-	5	
AI2+	6	
AI2-	7	

Additional information on the connections

■ Power supply for the control unit (XPOW)

The control unit is powered from a 24 V DC, 2 A supply (ZCU, BCU) or a 24 V DC, 2.9 A supply (UCU) through terminal block XPOW. With a type BCU/UCU control unit, a second supply can be connected to the same terminal block for redundancy.

Using a second supply is recommended, if:

- the control unit needs to be kept operational during input power break (for example, because of continuous fieldbus communication)
- immediate restart is needed after a power break (that is, no control unit power delay is allowed).

■ DIIL input

The DIIL input is used for the connection of safety circuits. The input is parameterized to stop the unit when the input signal is lost.

A jumper wire set installed at the factory connects the DIIL input to +24 V, which enables the drive to start. If this function is used as a part of safety function implementation, the jumper wire set must be removed.

Note: This input is not SIL or PL classified.

■ The XD2D connector

The XD2D connector provides an RS-485 connection that can be used for

- basic master/follower communication with one master drive and multiple followers,
- fieldbus control through the embedded fieldbus interface (EFB), or
- drive-to-drive (D2D) communication implemented by application programs.

See the firmware manual of the drive for the related parameter settings.

Terminate the bus on the units at the ends of the drive-to-drive link. Disable bus termination on the intermediate units.

Use a shielded twisted-pair cable for data, and another pair or a wire for signaling (nominal impedance 100...165 ohm, for example Belden 9842). For the best results, ABB recommends high quality cable. Keep the cable as short as possible. Avoid unnecessary loops and parallel runs near power cables such as motor cables.

164 Control units of the drive

The diagram that follows shows the wiring of the drive-to-drive link. The diagram is applicable to these control units:

- BCU-02/12/22
- UCU-22...24

Termination ON

Termination OFF

Termination ON

■ Safe torque off (XSTO, XSTO OUT)

See chapter [The Safe torque off function](#) (page 307).

Note: The XSTO input only acts as a true Safe torque off input on the inverter control unit. De-energizing the STO input terminals of other units (supply, DC/DC converter, or brake unit) will stop the unit but not constitute a SIL/PL classified safety function.

■ FSO safety functions module connection (X12, with BCU only)

Refer to the applicable FSO module user's manual.

Note: Control units that have a sticker with the text "No FSO support" are not compatible with the FSO safety functions module.

■ SDHC memory card slot

The BCU control unit has an on-board data logger that collects real-time data from the power modules to help fault tracing and analysis. The data is stored onto the SDHC memory card inserted into the SD CARD slot and can be analyzed by ABB service personnel.

■ MicroSDHC memory card slot

The UCU-22...24 has an on-board data logger that collects real-time data from the power modules to help fault tracing and analysis. The data is stored onto the microSDHC memory card inserted into the UMIH memory slot and can be analyzed by

Connector data

Power supply (XPOW)

Connector pitch 5 mm, wire size 0.5 ... 2.5 mm
 Maximum tightening torque 0.45 N·m (4 lbf·in)
 24 V ($\pm 10\%$) DC, 2 A (BCU)
 19...32 V DC, 2.9 A (UCU-22...24)
 External power input.
 Two supplies can be connected to the BCU and UCU control units for redundancy.

Relay outputs RO1...RO3 (XRO1...XRO3 [BCU])

Connector pitch 5 mm, wire size 0.5 ... 2.5 mm
 Maximum tightening torque 0.45 N·m (4 lbf·in)

Relay outputs RO1...RO4 (XRO1...XRO4 [UCU-22...24])

250 V AC / 30 V DC, 2 A

Protected by varistors

+24 V output (XD24:2 and XD24:4)

Connector pitch 5 mm, wire size 0.5 ... 2.5 mm
 Maximum tightening torque 0.45 N·m (4 lbf·in)
 Total load capacity of these outputs is 4.8 W (200 mA) minus the power taken by DIO1 and DIO2.

Digital inputs DI1...DI6 (XDI:1...XDI:6)

Connector pitch 5 mm, wire size 0.5 ... 2.5 mm
 Maximum tightening torque 0.45 N·m (4 lbf·in)
 24 V logic levels: "0" < 5 V, "1" > 15 V
 R_{in} : 2.0 kohm
 Input type: NPN/PNP (DI1...DI5), PNP (DI6)
 Hardware filtering: 0.04 ms, digital filtering up to 10 kHz
 I_{max} : 15 mA (DI1...DI5), 5 mA (DI6)

Start interlock input DIIL (XDI:7)

Connector pitch 5 mm, wire size 0.5 ... 2.5 mm
 Maximum tightening torque 0.45 N·m (4 lbf·in)
 24 V logic levels: "0" < 5 V, "1" > 15 V
 R_{in} : 2.0 kohm
 Input type: NPN/PNP
 Hardware filtering: 0.04 ms, digital filtering up to 10 kHz

Digital inputs/outputs DIO1 and DIO2 (XDIO:1 and XDIO:2)

Connector pitch 5 mm, wire size 0.5 ... 2.5 mm
 Maximum tightening torque 0.45 N·m (4 lbf·in)
 As inputs: 24 V logic levels: "0" < 5 V, "1" > 15 V. R
 Filtering: 1 ms.

Input/output mode selection by parameters.

DIO1 can be configured as a frequency input (0...16 kHz with hardware filtering of 4 microseconds) for 24 V level square wave signal (sinusoidal or other wave form cannot be used). (BCU)

As outputs: Total output current from +24VD is 100 mA
 +24VD

DIO1 can be configured as a frequency input (0...100 kHz with hardware filtering of 4 microseconds) for 24 V

DIOx

166 Control units of the drive

Reference voltage for analog inputs +VREF and -VREF (XAI:1 and XAI:2)	Connector pitch 5 mm, wire size 0.5 ... 2.5 mm Maximum tightening torque 0.45 N·m (4 lbf·in) 10 V ±1% and -10 V ±1%, $R_{load} > 100 \text{ kohm}$ Maximum output current: 10 mA	² (22...12 A)
Analog inputs AI1 and AI2 (XAI:4 ... XAI:7). Current/voltage input mode selection by switches (BCU) Current/voltage input mode selection by parameters 12.15 AI1 unit selection and 12.25 AI2 unit selection (UCU)	Connector pitch 5 mm, wire size 0.5 ... 2.5 mm Maximum tightening torque 0.45 N·m (4 lbf·in) Current input: -20...20 mA, $R_{in} = 100 \text{ ohm}$ Voltage input: -10...10 V, $R_{in} > 200 \text{ kohm}$ Differential inputs, common mode range ±30 V Sampling interval per channel: 0.25 ms Hardware filtering: 0.25 ms Resolution: 11 bit + sign bit Inaccuracy: 1% of full scale range	² (22...12 A)
Analog outputs AO1 and AO2 (XAO)	Connector pitch 5 mm, wire size 0.5 ... 2.5 mm Maximum tightening torque 0.45 N·m (4 lbf·in) 0...20 mA, $R_{load} < 500 \text{ ohm}$ Frequency range: 0...500 Hz Resolution: 11 bit + sign bit Inaccuracy: 2% of full scale range	² (22...12 A)
XD2D connector	Connector pitch 5 mm, wire size 0.5 ... 2.5 mm Maximum tightening torque 0.45 N·m (4 lbf·in) Physical layer: RS-485 Transmission rate: 8 Mbit/s Cable type: Shielded twisted-pair cable with a twisted pair for data and a wire or another pair for signal ground (nominal impedance 100 ... 165 ohm, for example Belden 9842) Maximum length of link: 50 m (164 ft) Termination by switch	² (22...12 A)
RS-485 connection (X485)	Connector pitch 5 mm, wire size 0.5 ... 2.5 mm Maximum tightening torque 0.45 N·m (4 lbf·in) Physical layer: RS-485 Cable type: Shielded twisted-pair cable with a twisted pair for data and a wire or another pair for signal ground (nominal impedance 100 ... 165 ohm, for example Belden 9842) Maximum length of link: 50 m (164 ft) Termination and bias by switch (X485 TERM and X485 BIAS) (UCU-22...24)	² (22...12 A)
CAN connection (XCAN [UCU-22...24])	Connector pitch 5 mm, wire size 0.5 ... 2.5 mm Maximum tightening torque 0.45 N·m (4 lbf·in) Termination by switch (XCAN TERM) This connection is not supported by the firmware.	² (22...12 A)


Safe torque off connection (XSTO)	<p>Connector pitch 5 mm, wire size 0.5 ... 2.5 mm</p> <p>Maximum tightening torque 0.45 N·m (4 lbf·in)</p> <p>Input voltage range: -3...30 V DC</p> <p>Logic levels: "0" < 5 V, "1" > 17 V.</p> <p>Note: For the unit to start, both connections must</p> <p>applies to all control units (including drive, inverter, DC/DC converter etc. control units), but SIL/PL torque off functionality is only achieved through connector of the drive/inverter control unit.</p> <p>Current consumption: 10 mA (continuous) per S (UCU-22...24). The number of parallel drive/inverter does not have an effect on the current consumption.</p> <p>Current consumption: 66 mA (continuous) per S drive/inverter module (BCU)</p> <p>EMC (immunity) according to IEC 61326-3-1 and IEC 61326-3-2</p> <p>See also chapter The Safe torque off function</p>
Safe torque off output (XSTO OUT)	<p>Connector pitch 5 mm, wire size 0.5 ... 2.5 mm</p> <p>Maximum tightening torque 0.45 N·m (4 lbf·in)</p> <p>To STO connector of inverter module.</p>
Control panel connection (X13 [BCU])	Connector: RJ-45
Control panel connection (XPAN [UCU-22...24])	<p>Cable length < 100 m (328 ft) (BCU)</p> <p>Cable length < 50 m (164 ft) (UCU-22...24)</p> <p>Termination by switch (XPAN TERM) (UCU-22...24)</p>
Ethernet connection (XETH [BCU])	Connector: RJ-45
Fieldbus Ethernet connection with internal switch (XETH1 and XETH2 [UCU-22...24])	This connection is not supported by the firmware
Tool Ethernet connection with internal switch (XETH3 and XETH4 [UCU-22...24])	Cable type: minimum requirement CAT5e (UCU-22...24)
SDHC memory card slot (SD CARD [BCU])	<p>Memory card type: SDHC</p> <p>Maximum memory size: 4 GB</p>
microSDHC memory card slot (microSDHC CARD [UCU-22...24])	<p>Memory card type: microSDHC (minimum of class 10)</p> <p>Supported memory size: 4 GB...32 GB</p>
Battery	Real-time clock battery type: BR2032
<p>The terminals of the control unit fulfill the Protective Extra Low Voltage (PELV) requirements. The requirements of a relay output are not fulfilled if a voltage higher than 48 V is connected to the relay output.</p>	

168 Control units of the drive

■ BCU ground isolation diagram

	XPOW	
+24VI	1	
GND	2	
+24VI	3	
GND	4	
	XAI	
+VREF	1	
-VREF	2	
AGND	3	
AI1+	4	
AI1-	5	**
AI2+	6	
AI2-	7	
	XAO	
AO1	1	
AGND	2	
AO2	3	
AGND	4	
	XD2D	
B	1	
A	2	
BGND	3	
SHIELD	4	
XRO1, XRO2, XRO3		
NC	11	
COM	12	
NO	13	
NC	21	
COM	22	
NO	23	
NC	31	
COM	32	
NO	33	
	XD24	
+24VD	5	
DICOM	6	
+24VD	7	
DIOGND	8	
	XDIO	
DIO1	1	
DIO2	2	
DIOGND	3	
DIOGND	4	
	XDI	*
DI1	1	
DI2	2	
DI3	3	
DI4	4	
DI5	5	
DI6	6	
DIIL	7	
	XSTO	
OUT	1	
SGND	2	
IN1	3	
IN2	4	
	XSTO OUT	
IN1	5	
SGND	6	
IN2	7	
SGND	8	

■ UCU-22...24 ground isolation diagram



Power supply ground

*The maximum common mode voltage between each AI input and AGND is ±10V

**Ground selector (DICOM=DIOGND) settings

Installation checklist

Contents of this chapter

This chapter contains a checklist for the mechanical and electrical installation of the drive.

Checklist

Examine the mechanical and electrical installation of the drive before starting the work. Go through the checklist together with another person.

WARNING!

Obey the safety instructions of the drive. If you ignore them, death, or damage to the equipment can occur. If you are not a certified electrical professional, do not do installation, commissioning or maintenance work.

WARNING!

Stop the drive and do the steps in section 8.1 before you start the work.

[Electrical safety precautions](#)

172 Installation checklist

Make sure that ...

If the drive is connected to a network other than a symmetrically grounded TN-S system: You have done all the required modifications (for example, you may need to disconnect the EMC filter or ground-to-phase varistor) the electrical installation instructions.

There is an adequately sized protective earth (ground) conductor(s) between the drive and the switchboard, the conductor is connected to correct terminal, and the terminal is tightened to the correct torque.

Grounding has also been measured according to the regulations.

The input power cable is connected to the correct terminals, the phase order is correct, and the terminals are tightened to the correct torque.

There is an adequately sized protective earth (ground) conductor between the motor and the drive. The conductor is connected to the correct terminal, and the terminal is tightened to the correct torque.

Grounding has also been measured according to the regulations.

The motor cable is connected to the correct terminals, the phase order is correct, and the terminals are tightened to the correct torque.

The motor cable is routed away from other cables.

No power factor compensation capacitors are connected to the motor cable.

If an external brake resistor is connected to the drive: There is an adequately sized protective earth (ground) conductor between the brake resistor and the drive, and the conductor is connected to the correct terminal, and the terminals are tightened to the correct torque. Grounding has also been measured according to the regulations.

If an external brake resistor is connected to the drive: The brake resistor cable is connected to the correct terminals, and the terminals are tightened to the correct torque.

If an external brake resistor is connected to the drive: The brake resistor cable is routed away from other cables.

The control cables are connected to the correct terminals, and the terminals are tightened to the correct torque.

The voltage setting of the auxiliary voltage transformers (if any) is correct. See the electrical installation instructions.

If a drive bypass connection will be used: The direct-on-line contactor of the motor and the drive output contactor are either mechanically and/or electrically interlocked, that is, they cannot be closed at the same time. A thermal overload device must be used for protection when bypassing the drive. Refer to local codes and regulations.

There are no tools, foreign objects or dust from drilling inside the drive.

The area in front of the drive is clean: the drive cooling fan cannot draw any dust or dirt inside.

The terminal box cover of the motor is in place. Cabinet shrouds are in place and doors are closed.

The motor and the driven equipment are ready for power-up.

Start-up

Contents of this chapter

This chapter contains the start-up and switch-off procedures of the drive.

Start-up procedure

The tasks which are needed in certain cases only are marked with underlining, and option codes are given in brackets. Default device designations (if any) are given in brackets after the name, for example "main switch-disconnector [Q1]". The same device designations are also used in the circuit diagrams.

These instructions cannot and do not cover all possible start-up tasks of a customized drive. Always refer to the delivery-specific circuit diagrams when proceeding with start-up.

WARNING!

Only qualified electrical professionals are permitted to do the work described in this chapter.

Note: For certain options (such as functional safety options +Q950, +Q951, +Q952, +Q957, +Q963, +Q964, +Q978, +Q979), additional start-up instructions are given in their separate manuals.

Action

Safety

174 Start-up

Action

Make sure that the disconnecter of the supply transformer is locked to the open position (i.e., voltage is not connected to the drive, and cannot be connected to the drive accidentally).

Make sure that the main switch-disconnector [Q1.1] is open, or the main breaker [Q1] is racked out.

Some 12-pulse units (option +A004) have two switch-disconnectors or breakers. Make sure that both are open before you continue.

Close the grounding switch [Q9.1] (option +F259). Do not use too much force. Electrical interlocking can prevent closing of the grounding switch.

Note: 12-pulse units (option +A004) have two switches: Q9.1 and Q9.2.

Check the mechanical and electrical installation of the drive. See [Installation checklist \(page 171\)](#).

Check the settings of breakers/switches in the auxiliary circuits. See the circuit diagrams delivered with the drive.

Check the tap settings of transformers T21, T101 (if present) and T111 (if present). See section [Checking the settings of transformers T21, T101 and T111 \(page 117\)](#).

Disconnect any unfinished or uninspected auxiliary voltage (115/230 V AC) cables that lead from the terminal blocks to the outside of the equipment.

Check that both channels of the Safe torque off circuit connected to the STO inputs of both the supply control unit [A51] and the inverter control unit [A41] are closed. Refer to the wiring diagrams delivered with the drive.

Drives with ground fault monitoring for IT (ungrounded) systems (option +Q954): If necessary, adjust the settings of the device. See the circuit diagrams of the delivery and the manual of the device.

Drives with Pt100 relays (option +(n)L506):

- Check the connections against the circuit diagrams of the delivery.
- Set the alarm and trip levels of the Pt100 relays.

Set the alarm and trip levels of the Pt100 relay as low as possible based on the operating temperature and test results of the machine. The trip level can be set, for example, 10 °C higher than what the temperature of the machine is at maximal load in the maximum environmental temperature.

ABB recommends to set the operating temperatures of the relay, typically for example, as follows:

- 120...140 °C when only tripping is in use
- alarm 120...140 °C and trip 130...150 °C when both alarm and tripping are used.

Powering up the auxiliary circuit of the drive

Make sure that it is safe to connect voltage. Make sure that:

- nobody is working on the drive or circuits that have been wired from outside into the drive cabinet
- the cover of the motor terminal box is in place.

Drives with a voltmeter (option +G334): Make sure that the circuit breaker of the measuring circuit (F5.1) is closed.

Close the circuit breakers and/or fuse disconnectors supplying the auxiliary voltage circuits.

Close the cabinet doors.

Close the main breaker of the supply transformer.

Switch on the auxiliary voltage [Q21].

Setting up the supply unit parameters

Check the voltage range setting in parameter 195.01 Supply voltage.

Action

Setting up the inverter unit parameters, and performing the first start

Set up the inverter control program. See the appropriate start-up guide and/or firmware manual. There is a separate start-up guide only for some control programs.

Make sure that parameter 95.09 Switch fuse controller is set to Disabled.

Drives with a brake chopper (option +D150): See chapter [Resistor braking \(page 333\)](#).

Drives with a sine output filter (option +E206): Check that bit 1 of parameter 95.15 Special HW settings is activated.

Drives with an fieldbus adapter module (optional): Set the fieldbus parameters. Activate the appropriate assistant (if present) in the control program, or see the user's manual of the fieldbus adapter module, and the drive firmware manual. Check that the communication works between the drive and the PLC.

Drives with an encoder interface module (optional): Set the encoder parameters. Activate the appropriate assistant (if present) in the control program, or see the user's manual of the encoder interface module, and the drive firmware manual.

Powering up the main circuit of the drive

Switch off the grounding switch [Q9.1] (option +F259).

12-pulse units have two grounding switches, Q9.1 and Q9.2.

Close the main switch-disconnector [Q1.1] or main breaker [Q1].

Note: Do not use excessive force. The main switch-disconnector (or main breaker) can only be closed when:

- the main input terminals [L1, L2, L3] are powered, and
- auxiliary voltage is switched on [Q21], and
- the grounding switch [Q9.1, Q9.2] (option +F259) is open.

Turn the operating switch (S21) to the ON (1) position to activate the run enable signal. Depending on control source settings, this may also close the main contactor (if present). If a main contactor is present and does not close, refer to the circuit diagrams delivered by the drive as well as the appropriate firmware manuals.

On-load checks

Start the motor to perform the ID run.

Check that the cooling fans rotate freely in the right direction, and the air flows upwards.

Check that the motor starts, stops and follows the speed reference in the correct direction when controlled with the control panel.

Check that the motor starts, stops and follows the speed reference in the correct direction when controlled through the customer-specific I/O or fieldbus.

Drives in which the Safe torque off control circuit is in use: Test and validate the operation of the Safe torque off function. See section [Start-up including validation test \(page 318\)](#).

Drives with an emergency stop circuit (options +Q951, +Q952, +Q963, +Q964, +Q978, +Q979): Test and validate the operation of the emergency-stop circuit. See the delivery specific circuit diagrams and wiring, start-up and operating instructions of the option.

Drives with the Prevention of unexpected start-up with safety relay (option +Q957): Test and validate the operation of the Prevention of unexpected start-up circuit. See the delivery specific circuit diagrams and wiring, start-up and operating instructions of the option.

Drives with the Prevention of unexpected start with FSO safety functions module (option +Q950): Test and validate the operation of the Prevention of unexpected start-up circuit. See the delivery specific circuit diagrams and wiring, start-up and operating instructions of the option.

176 Start-up

Switching off the drive

1. Stop the motor.
2. Turn the Run enable switch (S21) to the off (0) position to deactivate the Run enable signal and to switch the main contactor/breaker off.

Fault tracing

Contents of this chapter

This chapter describes the fault tracing possibilities of the drive.

Control unit LEDs (BCU-x2)

LED	Color	Indication
BATT OK	Green	Battery voltage of the real-time clock is OK (high). When the LED is not lit, <ul style="list-style-type: none">• battery voltage is below 2.8 V,• the battery is missing, or• the control unit is not powered.
PWR OK	Green	Internal voltage is sufficient.
FAULT	Red	The control program indicates that the equipment is in a fault state. See the appropriate firmware manual.
WRITE	Yellow	Writing to SD card in progress.

Control unit LEDs (UCU-22...24)

LED		Indication
BAT	Green	Battery voltage of the real-time clock is sufficient (higher than 2.5 V).
	Off	Battery voltage is below 2.5 V, the battery is missing or the control unit is not powered.
PWR	Green	Internal voltage is sufficient.
FAULT	Red	Control program indicates that the equipment is faulty. See the appropriate firmware manual.
WRITE	Yellow	Writing to microSDHC card in progress.
FS COMM	Green	Reserved
FS STATUS	Green	Reserved

Control panel and panel platform/holder LEDs

The ACS-AP-... control panel has a status LED. The control panel mounting platform or holder has two status LEDs. For their indications, see the following table.

Location	LED	Indication
Control panel	Continuous green	The unit is functioning normally.
	Flickering green	Data is transferred between the PC and the unit through the USB connection of the control panel.
	Flashing green	There is an active warning in the unit.
	Continuous red	There is an active fault in the unit.
	Flashing red	There is a fault that requires the stopping and restarting of the drive/converter/inverter.
	Flashing blue (ACS-AP-W only)	The Bluetooth interface is enabled, in discoverable mode, and ready for pairing.
	Flickering blue (ACS-AP-W only)	Data is being transferred through the Bluetooth interface of the control panel.
Control panel mounting platform or holder (with the control panel removed)	Red	There is an active fault in the unit.
	Green	Power supply for the control unit is OK.

Maintenance

Contents of this chapter

This chapter contains maintenance instructions.

Handling fiber optic cables

WARNING!

Obey these instructions. If you ignore them, damage to the equipment may occur.

- Handle the fiber optic cables with care.
- When you disconnect the fiber optic cables, always hold the connector, not the cable.
- Do not touch the ends of the fibers. They are sensitive to dirt.
- Do not bend the fiber optic cables too tightly. The minimum allowed bend radius is 35 mm (1.4 in).

Maintenance intervals

The tables below show the maintenance tasks which can be done by the end user. For ABB Service offering, refer to www.abb.com/driveservices or consult your local Service representative (www.abb.com/searchchannels).

■ Description of symbols

Action	Description
I	Inspection (visual inspection and maintenance action if needed)
P	Performance of on/off-site work (commissioning, tests, measurements or other work)
R	Replacement

■ Recommended maintenance intervals after start-up

Component	Years from start-up								
	1	2	3	4	5	6	7	8	9
Cooling									
Supply and inverter module main cooling fans									R
Supply and inverter modules: circuit board compartment fan									R
Sine filter (option +E206) cool- ing fan									R
Door fan									R
Other cabinet cooling fans (50 Hz)									R
Other cabinet cooling fans (60 Hz)						R			
Batteries									
Control panel battery									R
Control unit battery						R			
Connections and environment									
Air inlet and outlet meshes (IP22/IP42)	I	I	I	I	I	I	I	I	I
Cabinet door filters (IP54)	R	R	R	R	R	R	R	R	R
Tightness of terminals	I	I	I	I	I	I	I	I	I
Ambient conditions (dustiness, moisture, corrosion, temperat- ure)	I	I	I	I	I	I	I	I	I
Cleaning of heatsinks	I	I	I	I	I	I	I	I	I
Quality of supply voltage	P	P	P	P	P	P	P	P	P
Air circuit breaker maintenance (if present)	I	I	I	I	I	I	I	I	I
Spare parts									
Spare part stock	I	I	I	I	I	I	I	I	I
Reforming DC circuit capacitors (spare modules and spare capa- citors)	P	P	P	P	P	P	P	P	P
Functional safety									
Safety function test								I	

See the maintenance information of the safety f

182 Maintenance

Note:

- Maintenance and component replacement intervals are based on the assumption that the equipment is operated within the specified ratings and ambient conditions. ABB recommends annual drive inspections to ensure the highest reliability and optimum performance.
- Long term operation near the specified maximum ratings or ambient conditions may require shorter maintenance intervals for certain components. Consult your local ABB Service representative for additional maintenance recommendations.

Cabinet

■ Cleaning the interior of the cabinet

WARNING!

Obey the safety instructions of the drive. If you ignore them, death, or damage to the equipment can occur. If you are not a qualified electrical professional, do not do installation, commissioning or maintenance work.

WARNING!

Use a vacuum cleaner with antistatic hose and nozzle, and wear a grounded wristband. Using a normal vacuum cleaner creates static discharges that can damage circuit boards.

1. Stop the drive and do the steps in section [Electrical safety precautions](#) before you start the work.
2. Open the cabinet door.
3. Clean the interior of the cabinet. Use a vacuum cleaner and a soft brush.
4. Clean the air inlets of the fans and air outlets of the modules (top).
5. Clean the air inlet gratings (if any) on the door.
6. Close the door.

■ Cleaning the exterior of the drive

WARNING!

Obey the safety instructions of the drive. If you ignore them, death, or damage to the equipment can occur. If you are not a qualified electrical professional, do not do installation, commissioning or maintenance work.

1. Stop the drive and do the steps in section [Electrical safety precautions](#) before you start the work.
2. Clean the exterior of the drive. Use:
 - vacuum cleaner with an antistatic hose and nozzle
 - soft brush
 - dry or damp (not wet) cleaning cloth. Moisten with clean water, or mild detergent (pH 5...9 for metal, pH 5...7 for plastic).

WARNING!