

Please read the Product Safety Guide, located later in this document, before you set up your machine.

WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injuries.

Unpack the machine and check the components

The components included in the box may differ depending on your country. Remove the protective tape and film covering the machine. Open the Top Cover, and then remove the protective tape.

Quick Setup
Guide/Product
Safety Guide

- This product is packaged in a plastic bag. To prevent suffocation, keep plastic bags away from children. The bag is not a toy.
- Use only power supplies listed in your *Online User's Guide*.

NOTE

- We recommend saving the original packaging in case you must ship your machine.
- For more information, see your model's Online User's Guide at support.brother.com/manuals.

For Network Users: Important Notice for Network Security (ADS-1350W/ADS-1800W only)



Your machine's default password is located on the bottom of the machine and marked "Pwd". We recommend immediately changing the default password to use network tools/utilities securely and to protect your machine from unauthorised access.

Unless otherwise specified, illustrations in this guide show the ADS-1800W.

Connect the USB Cable

If using the AC Adapter:
Connect the AC Adapter a

NOTE

- Before loading documents into the Automatic Document Feeder (ADF), fan the paper and align its edges as shown in the illustration on the machine's Top Cover.
- Use the USB Type-C  Cable included in the box to connect to your scanner.
- Make sure to use a computer that has a USB Type-C port that supports 15 W output or higher.
- The AC Adapter is an optional accessory and is available on the Brother website. Search for part number LK-1001 (the AC Adapter (SA-AD-001) and a USB Type-A to USB Type-C  Cable).