





ABB INDUSTRIAL DRIVES

# **ACS880-07 drives (560 to 2800 kW)**

## **Hardware manual**







# **ACS880-07 drives (560 to 2800 kW)**

## **Hardware manual**

### Table of contents

- 1. Safety instructions
- 4. Mechanical installation
- 6. Electrical installation
- 9. Start-up









# Table of contents

## 1 Safety instructions

<a href="#">Contents of this chapter</a>	.....
<a href="#">Use of warnings and notes</a>	.....
<a href="#">General safety in installation, start-up and maintenance</a>	
<a href="#">Electrical safety in installation, start-up and maintenance</a>	
<a href="#">Electrical safety precautions</a>	.....
<a href="#">Additional instructions and notes</a>	.....
<a href="#">Printed circuit boards</a>	.....
<a href="#">Grounding</a>	.....
<a href="#">General safety in operation</a>	.....
<a href="#">Additional instructions for permanent magnet motor drives</a>	
<a href="#">Safety in installation, start-up, maintenance</a>	.....
<a href="#">Safety in operation</a>	.....

## 2 Introduction to the manual

<a href="#">Contents of this chapter</a>	.....
<a href="#">Target audience</a>	.....
<a href="#">Categorization by frame size and option code</a>	.....
<a href="#">Use of component designations</a>	.....
<a href="#">Quick installation, commissioning and operation flowchart</a>	
<a href="#">Terms and abbreviations</a>	.....
<a href="#">Related documents</a>	.....

## 3 Operation principle and hardware description

<a href="#">Contents of this chapter</a>	.....
<a href="#">Operation principle</a>	.....
<a href="#">Overview circuit diagram of the drive</a>	.....
<a href="#">12-pulse connection (option +A004)</a>	.....
<a href="#">Cabinet line-up and layout examples</a>	.....
<a href="#">Frame 1xD8T+2xR8i</a>	.....
<a href="#">Frame 2xD7T+2xR8i (12-pulse connection, option +A004)</a>	.....
<a href="#">Frame 2xD8T+3xR8i</a>	.....
<a href="#">Frame 3xD8T+4xR8i (with main breaker, option +F255)</a>	.....
<a href="#">Auxiliary control cubicle (ACU) layout</a>	.....
<a href="#">Overview of power and control connections (BCU-x2)</a>	
<a href="#">Overview of power and control connections (UCU-22)</a>	
<a href="#">Door devices</a>	.....
<a href="#">Main disconnecting device (Q1.1)</a>	.....
<a href="#">Auxiliary voltage switch [Q21]</a>	.....
<a href="#">Grounding (earthing) switch [Q9], optional</a>	.....
<a href="#">Other devices on the door</a>	.....



## 6 Table of contents

<a href="#">Descriptions of options</a>	5
<a href="#">Degree of protection</a>	5
<a href="#">Definitions</a>	5
<a href="#">IP22 (UL Type 1)</a>	5
<a href="#">IP42 (UL Type 1 Filtered) (option +B054)</a>	5
<a href="#">IP54 (UL Type 12) (option +B055)</a>	5
<a href="#">Marine construction (option +C121)</a>	5
<a href="#">Cooling air inlet through bottom of cabinet (option +C128)</a>	5
<a href="#">UL Listed (option +C129)</a>	5
<a href="#">Channeled air outlet (option +C130)</a>	5
<a href="#">CSA Approved (option +C134)</a>	5
<a href="#">Plinth height (options +C164 and +C179)</a>	5
<a href="#">Seismic design (option +C180)</a>	5
<a href="#">E-Cubicles on left (options +C199)</a>	5
<a href="#">Resistor braking (options +D150 and +D151)</a>	5
<a href="#">EMC filter (option +E202)</a>	5
<a href="#">Sine filter (option +E206)</a>	5
<a href="#">Cabinet heater with external supply (option +G300)</a>	5
<a href="#">Cabinet lighting (option +G301)</a>	5
<a href="#">Terminals for external control voltage (option +G307)</a>	5
<a href="#">Output for motor space heater (option +G313)</a>	5
<a href="#">Supply connection by busbars (option +G317)</a>	5
<a href="#">Run/Fault lights (options +G327)</a>	5
<a href="#">Halogen-free wiring and materials (option +G330)</a>	5
<a href="#">V-meter with selector switch (option +G334)</a>	5
<a href="#">Wire markings</a>	5
<a href="#">Standard wiring</a>	5
<a href="#">Additional wire markings</a>	5
<a href="#">Common mode filter temperature monitoring (option +G453)</a>	5
<a href="#">Bottom cable entry/exit (options +H350 and +H352)</a>	5
<a href="#">Top cable entry/exit (options +H351 and +H353)</a>	5
<a href="#">Cable conduit entry (option +H358)</a>	5
<a href="#">Common motor terminal cubicle (option +H359)</a>	5
<a href="#">Common output terminals (option +H366)</a>	5
<a href="#">Connectivity for wired remote monitoring (option +K496)</a>	5
<a href="#">Connectivity for wireless remote monitoring (option +K497)</a>	5
<a href="#">Additional terminal block X504 (option +L504)</a>	5
<a href="#">Thermal protection with PTC relays (options +L505, +2L505, +L513, +2L513, +L536, +L537)</a>	5
<a href="#">+L505, +2L505, +L513, +2L513</a>	5
<a href="#">+L536, +L537</a>	5
<a href="#">Thermal protection with Pt100 relays (options +nL506, +nL514)</a>	5
<a href="#">SIM610 or auxiliary motor fan (options +M600)</a>	5
<a href="#">What the option contains</a>	5
<a href="#">Description</a>	5
<a href="#">Type designation label</a>	6
<a href="#">Type designation key</a>	6
<a href="#">Option codes</a>	



<a href="#">Necessary tools</a>	.....
<a href="#">Examining the delivery</a>	.....
<a href="#">Moving and unpacking the drive</a>	.....
<a href="#">Moving the drive in its packaging</a>	.....
<a href="#">Lifting the crate with a forklift</a>	.....
<a href="#">Lifting the crate with a crane</a>	.....
<a href="#">Moving the crate with a forklift</a>	.....
<a href="#">Removing the transport package</a>	.....
<a href="#">Moving the unpacked drive cabinet</a>	.....
<a href="#">Lifting the cabinet with a crane</a>	.....
<a href="#">Moving the cabinet on rollers</a>	.....
<a href="#">Moving the cabinet on its back</a>	.....
<a href="#">Moving the cabinet to its final position</a>	.....
<a href="#">Attaching the cabinet to the floor and wall or roof</a>	.....
<a href="#">General rules</a>	.....
<a href="#">Attaching the cabinet (non-marine units)</a>	.....
<a href="#">Alternative 1.-Clamping</a>	.....
<a href="#">Alternative 2.-Using the holes inside the cabinet</a>	.....
<a href="#">Alternative 3.-Cabinets with plinth options +C164 and +C179</a>	.....
<a href="#">Attaching the cabinet (marine units)</a>	.....
<a href="#">Joining cabinet sections together</a>	.....
<a href="#">Miscellaneous</a>	.....
<a href="#">Cable duct in the floor below the cabinet</a>	.....
<a href="#">Arc welding</a>	.....
<a href="#">Air inlet through the bottom of the cabinet (option +C128)</a>	.....
<a href="#">Air outlet duct on the cabinet roof (option +C130)</a>	.....
<a href="#">Calculating the required static pressure difference</a>	.....
<a href="#">Lifting jugs and bars</a>	.....
<a href="#">Certificate of conformity</a>	.....
<a href="#">Declarations of conformity</a>	.....

## 5 Guidelines for planning the electrical installation

<a href="#">Contents of this chapter</a>	.....
<a href="#">Limitation of liability</a>	.....
<a href="#">North America</a>	.....
<a href="#">Selecting the supply transformer</a>	.....
<a href="#">Basic guidelines</a>	.....
<a href="#">Additional notes</a>	.....
<a href="#">A drive with a 12-pulse diode supply unit</a>	.....
<a href="#">Selecting the supply disconnecting device</a>	.....
<a href="#">Selecting the main contactor or breaker</a>	.....
<a href="#">Examining the compatibility of the motor and drive</a>	.....
<a href="#">Protecting the motor insulation and bearings</a>	.....
<a href="#">Requirements tables</a>	.....

<a href="#">Requirements for ABB motors, P</a>	< 100 kW (134 hp)	.....
<a href="#">Requirements for ABB motors, P</a>	> 100 kW (134 hp)	.....
<a href="#">Requirements for non-ABB motors, P</a>	< 100 kW (134 hp)	.....
<a href="#">Requirements for non-ABB motors, P</a>	> 100 kW (134 hp)	.....



## 8 Table of contents

Additional requirements for ABB motors of types other than M3_, HX_, AM_ and AX .....	9
Additional requirements for braking applications .....	9
Additional requirements for ABB high-output and IP23 motors .....	9
Additional requirements for non-ABB high-output and IP23 motors .....	9
Additional data for calculating the rise time and the peak line-to-line voltage .....	9
Additional note for sine filters .....	9
Selecting the power cables .....	10
Power cable selection procedure and applicability check .....	10
General guidelines .....	10
Typical power cable sizes .....	10
Power cable types .....	10
Preferred power cable types .....	10
Alternate power cable types .....	10
Not allowed power cable types .....	10
Power cable shield .....	10
Grounding requirements .....	10
Additional grounding requirements - IEC .....	10
Additional grounding requirements - UL (NEC) .....	10
Selecting the control cables .....	10
Shielding .....	10
Signals in separate cables .....	10
Signals that can be run in the same cable .....	10
Relay cable .....	10
Control panel to drive cable .....	10
PC tool cable .....	10
Routing the cables .....	10
General guidelines - IEC .....	10
Continuous motor cable shield/conduit and metal enclosure for equipment on the motor cable .....	10
Separate control cable ducts .....	10
Protecting the drive, input power cable, motor and motor cable in short circuit situations and against thermal overload .....	10
Protecting the input cabling and the drive upon a short-circuit .....	10
Protecting the motor and motor cable in short-circuits .....	10
Protecting the drive and the power cables against thermal overload .....	10
Protecting the motor against thermal overload .....	10
Protecting the motor against overload without thermal model or temperature sensors .....	10
Protecting the drive against ground faults .....	10
Residual current device compatibility .....	10
Implementing the emergency stop function .....	10
Implementing the Safe torque off function .....	10
Implementing the Prevention of unexpected start-up function .....	10
Implementing an ATEX-certified motor thermal protection .....	10
Implementing the functions provided by the FSO safety functions module .....	11
Implementing the power loss ride-through function .....	11
Implementing a bypass connection .....	11





[Protecting the contacts of relay outputs](#) . . . . .

[Implementing a motor temperature sensor connection](#)

[Connecting a motor temperature sensor to the drive through an option module](#) . . . . .

## **[6 Electrical installation](#)**

[Contents of this chapter](#) . . . . .

[Warnings](#) . . . . .

[Measuring the insulation](#) . . . . .

[Measuring the insulation resistance of the drive](#)

[Measuring the insulation resistance of the motor and motor cable](#)

[Measuring the insulation resistance of the input power cable](#)

[Compatibility check : IT \(ungrounded\) earthing system](#)

[Attaching the device stickers to the cabinet door](#) . . . . .

[Checking the settings of transformers T21, T101 and T111](#)

[T.500 V \(units\) tap settings \(400 . . . . .](#)

[T21 and T101 tap settings \(690 V units\) . . . . .](#)

[T111 tap settings . . . . .](#)

[Connecting the control cables](#) . . . . .

[Control cable connection procedure](#) . . . . .

[Grounding the outer shields of the control cables 360° at the cabinet entry](#)

[Routing the control cables inside the cabinet](#) . . . . .

[Connecting control cabling](#) . . . . .

[Connecting the motor cables \(units without common motor terminal cubicle or sine output filter\)](#) . . . . .

[Motor connection diagram \(without option +H366\)](#)

[Motor connection diagram \(with option +H366\) . . . . .](#)

[Procedure](#) . . . . .

[Removing an inverter module](#) . . . . .

[Removing the fan carriage of an inverter module](#)

[Connecting the motor cables](#) . . . . .

[Installing the fan carriage of an inverter module](#)

[Installing an inverter module](#) . . . . .

[Connecting the motor cables \(units with common motor terminal cubicle or sine output filter\)](#) . . . . .

[Output busbars](#) . . . . .

[Connection diagram](#) . . . . .

[Procedure](#) . . . . .

[Connecting an external brake resistor assembly](#) . . . . .

[Connecting the input power cables](#) . . . . .

[Connection diagram, 6-pulse units](#) . . . . .

[Connection diagram, 12-pulse units](#) . . . . .

[Layout of the input cable connection terminals and cable entries](#)

[Connection procedure](#) . . . . .

[Use of fasteners in cable lug connections](#) . . . . .

[Connecting a PC](#) . . . . .

[Panel bus \(control of several units from one control panel\)](#)

[Installing option modules](#)



## 10 Table of contents

### 7 Control units of the drive

<a href="#">Contents of this chapter</a> .....	14
<a href="#">General</a> .....	14
<a href="#">BCU layout</a> .....	14
<a href="#">Default I/O diagram of the supply control unit (BCU-x2)</a> .....	14
<a href="#">Default I/O diagram of the inverter control unit (BCU)</a> .....	14
<a href="#">U24 layout</a> .....	15
<a href="#">U24 unit I/O diagram of the supply control unit (UCU-22)</a> .....	15
<a href="#">U24 unit I/O diagram of the inverter control unit (UCU-22)</a> .....	15
<a href="#">Additional information on the connections</a> .....	16
<a href="#">Power supply for the control unit (XPOW)</a> .....	16
<a href="#">DIL input</a> .....	16
<a href="#">The XD2D connector</a> .....	16
<a href="#">Safe torque off (XSTO, XSTO OUT)</a> .....	16
<a href="#">FSO safety functions module connection (X12, with BCU only)</a> .....	16
<a href="#">SDHC memory card slot</a> .....	16
<a href="#">MicroSDHC memory card slot</a> .....	16
<a href="#">Connector data</a> .....	16
<a href="#">BCU ground isolation diagram</a> .....	16
<a href="#">U24 ground isolation diagram</a> .....	16

### 8 Installation checklist

<a href="#">Contents of this chapter</a> .....	17
<a href="#">Checklist</a> .....	17

### 9 Start-up

<a href="#">Contents of this chapter</a> .....	17
<a href="#">Start-up procedure</a> .....	17
<a href="#">Switching off the drive</a> .....	17

### 10 Fault tracing

<a href="#">Contents of this chapter</a> .....	17
<a href="#">Control unit LEDs (BCU-x2)</a> .....	17
<a href="#">U24 control unit LEDs (UCU-22)</a> .....	17
<a href="#">Control panel and panel platform/holder LEDs</a> .....	17
<a href="#">Warning and fault messages</a> .....	17

### 11 Maintenance

<a href="#">Contents of this chapter</a> .....	17
<a href="#">Handling fiber optic cables</a> .....	17
<a href="#">Maintenance intervals</a> .....	18
<a href="#">Description of symbols</a> .....	18
<a href="#">Recommended maintenance intervals after start-up</a> .....	18
<a href="#">Cabinet</a> .....	18
<a href="#">Cleaning the interior of the cabinet</a> .....	18
<a href="#">Cleaning the exterior of the drive</a> .....	18



Fans	
Replacing a supply module (D7T) cooling fan	
Replacing a supply module (D8T) or inverter module (R8i) cooling fan	
Replacing the circuit board compartment fan	
Replacing the cooling fan in the auxiliary control cubicle	
Replacing the cooling fan in the incoming cubicle	
Replacing the roof fan (IP54/UL type 12)	
Replacing the common motor terminal cubicle fan	
Fan attached to the cabinet door	
Roof fan (with options +C128 and +H353)	
Floor fan (with options +C128 and +H353)	
Replacing the brake chopper and resistor cubicle fans (options +D150 and +D151)	
Supply and inverter modules	
Replacing a frame D7T supply module	
Replacing a frame D8T supply module	
Removing an inverter module	
Installing an inverter module	
Cleaning the heatsink	
Activating the reduced run of the supply unit	
Starting reduced run operation	
Resuming normal operation	
Activating the reduced run function of the inverter unit	
Returning the module	
Capacitors	
Reforming the capacitors	
Fuses	
Checking and replacing the DC fuses of a D7T supply module	
Checking and replacing the DC fuses of a D8T supply module	
Control panel	
Control units	
BCU control unit types	
Replacing the memory unit (BCU)	
Replacing the BCU control unit battery	
UCU control unit types	
Replacing the memory unit (UCU-22)	
Replacing the UCU control unit battery	
Replacing the microSDHC memory card (UCU-22)	
Functional safety components	

## 12 Technical data

Contents of this chapter	
Ratings	
Definitions	
Derating	
Surrounding air temperature derating	
Altitude derating	
Switching frequency derating	



## 12 Table of contents

<a href="#">DC fuses</a>	23
<a href="#">Supply module internal DC fuses</a>	23
<a href="#">Fuses on C/VAR varistor board</a>	23
<a href="#">Brake chopper DC fuses</a>	23
<a href="#">Dimensions and weights</a>	23
<a href="#">Free space requirements</a>	23
<a href="#">Losses, cooling data and noise</a>	23
<a href="#">Sine output filter data</a>	23
<a href="#">Typical power cable sizes</a>	23
<a href="#">Terminal and cable entry data for the power cables</a>	23
<a href="#">Terminal data for the motor cables</a>	23
<a href="#">Terminal data for the supply and inverter control units</a>	23
<a href="#">Terminal data for block X504</a>	23
<a href="#">Electrical power network specification</a>	23
<a href="#">Motor connection data</a>	23
<a href="#">Efficiency</a>	23
<a href="#">Energy efficiency data (ecodesign)</a>	23
<a href="#">Protection classes</a>	23
<a href="#">Ambient conditions</a>	23
<a href="#">Transportation</a>	24
<a href="#">Storage conditions</a>	24
<a href="#">Colors</a>	24
<a href="#">Materials</a>	24
<a href="#">Drive</a>	24
<a href="#">Packaging of drive</a>	24
<a href="#">Packaging of options</a>	24
<a href="#">Manuals</a>	24
<a href="#">Disposal</a>	24
<a href="#">Applicable standards</a>	24
<a href="#">Markings</a>	24
<a href="#">EMC compliance (IEC/EN 61800-3)</a>	24
<a href="#">Definitions</a>	24
<a href="#">Category C2</a>	24
<a href="#">Category C3</a>	24
<a href="#">Category C4</a>	24
<a href="#">UL and CSA checklist</a>	24
<a href="#">Tightening torques</a>	24
<a href="#">Electrical connections</a>	24
<a href="#">Mechanical connections</a>	24
<a href="#">Insulation supports</a>	24
<a href="#">Cable lugs</a>	24
<a href="#">Disclaimers</a>	24
<a href="#">Generic disclaimer</a>	24
<a href="#">Cyber security disclaimer</a>	24

## 13 Dimensions

<a href="#">Cabinet line-up dimensions</a>	25
<a href="#">Dimension tables</a>	





Frame 1×D8T + 2×R8i, IP54 (+B055) .....	
<a href="#">F1/2ne. 1×D8T + 2×R8i with common motor terminal cubicle (+H359)</a>	
<a href="#">F2/2ne. 1×D8T + 2×R8i with common motor terminal cubicle (+H359)</a>	
<a href="#">F1/2ne. 1×D8T + 2×R8i with brake choppers and resistors (+D150 +D151)</a>	
<a href="#">F2/2ne. 1×D8T + 2×R8i with brake choppers and resistors (+D150 +D151)</a>	
<a href="#">F1/2ne. 1×D8T + 2×R8i with sine output filter (+E206)</a>	
<a href="#">F2/2ne. 1×D8T + 2×R8i with sine output filter (+E206)</a>	
<a href="#">Frame 2×D8T + 2×R8i, 12-pulse (+A004) with grounding switch (+F259)</a>	
<a href="#">F1/2ne. 2×D8T + 3×R8i .....</a>	
<a href="#">F2/2ne. 2×D8T + 3×R8i .....</a>	
<a href="#">F1/2ne. 2×D8T + 3×R8i with common motor terminal cubicle (+H359)</a>	
<a href="#">F2/2ne. 2×D8T + 3×R8i with common motor terminal cubicle (+H359)</a>	
<a href="#">F1/2ne. 2×D8T + 3×R8i with top entry / top exit (+H351/+H353)</a>	
<a href="#">F2/2ne. 2×D8T + 3×R8i with top entry/top exit .</a>	
<a href="#">F1/2ne. 3×D8T + 4×R8i .....</a>	
<a href="#">F2/2ne. 3×D8T + 4×R8i .....</a>	
<a href="#">F1/2ne. 3×D8T + 4×R8i with common motor terminal cubicle (+H359)</a>	
<a href="#">F2/2ne. 3×D8T + 4×R8i with common motor terminal cubicle (+H359)</a>	
<a href="#">F1/2ne. 3×D8T + 4×R8i with top entry / top exit (+H351/+H353)</a>	
<a href="#">F2/2ne. 3×D8T + 4×R8i with top entry / top exit (+H351/+H353)</a>	
<a href="#">F1/2ne. 4×D8T + 5×R8i (6-pulse) with top entry/exit, UL Listed (+C129)</a>	
<a href="#">F2/2ne. 4×D8T + 5×R8i (6-pulse) with top entry/exit, UL Listed (+C129)</a>	
<a href="#">Dimensions of empty cubicles (options +C199, +C200, +C201)</a>	
<a href="#">IP22/IP42 .....</a>	
<a href="#">IP54 .....</a>	
<a href="#">Location and size of input terminals .....</a>	
<a href="#">400 mm, bottom cable entry .....</a>	
<a href="#">400 mm, top cable entry .....</a>	
<a href="#">600 mm, without main breaker, bottom cable entry (including 12-pulse units with grounding switch) .....</a>	
<a href="#">600 mm, without main breaker, top cable entry (including 12-pulse units with grounding switch) .....</a>	
<a href="#">600 mm, 12-pulse units without grounding switch, bottom cable entry</a>	
<a href="#">600 mm, 12-pulse units without grounding switch, top cable entry</a>	
<a href="#">600 mm, with main breaker, bottom cable entry</a>	
<a href="#">600 mm, with main breaker, top cable entry .....</a>	
<a href="#">1000 mm (UL/CSA), top cable entry .....</a>	
<a href="#">1000 mm (UL/CSA), bottom cable entry .....</a>	
<a href="#">Location and size of output terminals .....</a>	
<a href="#">Units without common motor terminal cubicle .....</a>	
<a href="#">Inverter module cubicle with two R8i modules, bottom cable exit</a>	
<a href="#">Inverter module cubicle with two R8i modules, top cable exit</a>	
<a href="#">Inverter module cubicle with three R8i modules, bottom cable exit</a>	
<a href="#">Inverter module cubicle with three R8i modules, top cable exit</a>	
<a href="#">Brake chopper cubicle .....</a>	
<a href="#">Sine filter cubicle, 1000 mm, bottom cable exit</a>	
<a href="#">Sine filter cubicle, 1000 mm, top cable exit .....</a>	
<a href="#">Units with common motor terminal cubicle (+H359)</a>	



## 14 Table of contents

<a href="#">Cubicle width 600 mm, bottom cable exit</a>	30
<a href="#">Cubicle width 600 mm, top cable exit</a>	30
<b>14 The Safe torque off function</b>	
<a href="#">Contents of this chapter</a>	30
<a href="#">Description</a>	30
<b>Compliance with the European Machinery Directive and the UK Supply of Machinery (Safety) Regulations</b>	30
<a href="#">Wiring</a>	30
<a href="#">Activation switch</a>	30
<a href="#">Cable types and lengths</a>	30
<a href="#">Grounding of protective shields</a>	30
<a href="#">Dual-channel connection with internal power supply (BCU-x2)</a>	31
<a href="#">Dual-channel connection with internal power supply (UCU-22)</a>	31
<a href="#">Single-channel connection of activation switch (BCU-x2)</a>	31
<a href="#">Single-channel connection of activation switch (UCU-22)</a>	31
<a href="#">Multiple drives</a>	31
<a href="#">Internal power supply (example, drives with ZCU-xx and BCU-x2)</a>	31
<a href="#">Internal power supply (example, drives with UCU-22)</a>	31
<a href="#">External power supply (example, drives with ZCU-xx and BCU-x2)</a>	31
<a href="#">External power supply (example, drives with UCU-22)</a>	31
<a href="#">Operation principle</a>	31
<a href="#">Start-up including validation test</a>	31
<a href="#">Competence</a>	31
<a href="#">Validation test reports</a>	31
<a href="#">Validation test procedure</a>	31
<a href="#">Use</a>	32
<a href="#">Maintenance</a>	32
<a href="#">Competence</a>	32
<a href="#">Perfect proof test procedure</a>	32
<a href="#">Simplified proof test procedure</a>	32
<a href="#">Fault tracing</a>	32
<a href="#">Safety data</a>	32
<a href="#">Terms and abbreviations</a>	32
<a href="#">TUV certificate</a>	32
<a href="#">Declarations of conformity</a>	32

## 15 Resistor braking

<a href="#">Contents of this chapter</a>	33
<a href="#">Operation principle</a>	33
<a href="#">Factory-installed brake choppers and resistors</a>	33
<a href="#">Technical data</a>	33
<a href="#">Ratings of chopper/resistor combinations</a>	33
<a href="#">Definitions</a>	33
<a href="#">SAFUR resistor data</a>	33
<a href="#">Terminals and cable lead-through data of factory-installed chopper/resistor cubicles</a>	33