

Getting Started Guide: Cisco Aironet 1140 Series Autonomous Access Point

Updated: February 11, 2010

Table Of Contents

Cisco Aironet 1140 Series Autonomous Access Point

About this Guide

Safety Instructions

Overview

- Verifying Shipped Components

- Key Ports and Components

- Performing a Site Survey

Obtaining and Assigning an IP Address

- Connecting to the Access Point Locally

- Assigning the IP Address to the BVI

- Assigning an IP Address Using the CLI

Mounting the Access Point

Configuring Basic Settings

- Default Settings on the Express Setup Page

- Enabling the Radio Interfaces

- Configuring Security Settings

 - Configuring Basic Security Settings

 - Understanding Express Security Settings

 - Using VLANs

 - Express Security Types

 - Configuring Security for 802.11n

 - Express Security Limitations

 - Using the Express Security Page

Troubleshooting

- Checking the Access Point LED

- Configuring System Power Settings

- Finding More Troubleshooting Help

Access Point Specifications