

Nero User's Manual

Jean-Paul Chaput
System Administrator
Pierre & Marie Curie University, LIP6
ASIM Department

Nero User's Manual
by Jean-Paul Chaput

Published September 2002

Table of Contents

I. *Alliance - nero* User's Manual v
 nero7

I. *Alliance* - nero User's Manual

nero

Name

nero — Negotiating Router

Synopsis

```
nero [-h] [-v] [-V] [-c] [-2] [-3] [-4] [-5] [-6] [-L] [-G]
[--help] [--verbose] [--very-verbose] [--core-dump] [--local] [--global]
[--place placement] {netlist} {layout}
```

Description

nero is a simple router suited for small academic designs. Currently it can process designs of size up to 4K gates.

Global routing

A design is considered as *big* if it contains nets which half perimeter is greater than 800 lambdas. Global routing is used on big designs.

In nero, "global routing" means that the longest nets are completely routed in a first step with only routing layers numbers 3 & 4. Then the smaller nets are routed with all available layers. This implies that when global routing is used, the number of routing layers is forced to at least 4. In each step, the nets are routed from the shortest to the longest with the same routing algorithm.

Invocation

nero mandatory arguments :

- *netlist* : the name of the design, without any extension. Please note that unless a **-p** placement option is given, the file holding the placement is expected to have the same name as the netlist file (short of the extension).
- *layout* : the name of the resulting routed layout. Be careful of not giving the same name as the netlist, in this case the initial placement will be silently overwritten.

nero optionnals arguments :

- **-h, --help** : print help.
- **-v, --verbose** : be verbose.
- **-V, --very-verbose** : be unbearably verbose.
- **-c, --core-dump** : do not prevent the generation of core dumps in case of a crash. Mostly used during the development stage.
- **-2, -3, -4, -5, -6** : set the numbers of layers used for routing. The default for small designs is 2 and 4 for big ones. When global routing took place, the router will use at least 4 routing layers.
- **-L, --local** : turn off the global routing stage, whatever the size of the design. Be warned that this will enormously slow down the routing process.

- **-G, --global** : turn on the global routing regardless of the size of the design.
- **-p placement, --place placement** : specify a name for the placement file different from the netlist name.

Example

Route the netlist `amd2901_core.vst`, using the placement file `amd2901_core_p.ap` and store the result in `amd2901_core_r`.

```
$ export MBK_IN_LO=vst
$ export MBK_IN_PH=ap
$ export MBK_OUT_PH=ap
$ nero -V --place amd2901_core_p amd2901_core amd2901_core_r
```

See Also

`MBK_IN_LO(1)`, `MBK_OUT_LO(1)`, `MBK_IN_PH(1)`, `MBK_OUT_PH(1)`, `ocp(1)`, `ocr(1)`, `druc(1)`, `cougar(1)`