

## Checking and Adjusting Tire Pressures


Follow these steps when tires are cold and Model S has been stationary for over three hours:



1. Refer to the Tire and Loading Information label located on the driver's center door pillar for the target tire pressure.
2. Remove the valve cap.
3. Firmly press an accurate tire pressure gauge onto the valve to measure pressure.
4. If required, add or remove air to reach the recommended pressure.

Note  
You can release air by pressing the metal stem in the center of the valve.



- 
5. Re-check pressure using the accurate tire gauge.
  6. Repeat steps 3 and 4 as necessary until the tire pressure is correct.
  7. Reinstall the valve cap to prevent dirt from entering. Periodically check the valve for damage and leaks.

#### Do It Yourself

General Information

Restarting and Powercycling

Connecting and Pairing

Wheels, Tires, and Brakes

    Burnishing the Brakes

**Checking and Adjusting Tire Pressures**

Wipers and Washers

Climate Components

Front and Rear Trunk

Calibrate Cameras

Low Voltage Battery

Charging