

Contents

Preface — vii

Chapter 1 Introduction — 1

What is UEFI? — 1

What Do We Mean by *Shell*? — 4

A Short History of the UEFI Shell — 5

Brief Overview of the UEFI Shell — 5

UEFI Shell APIs — 6

Command Line Interface Features — 6

Why a Shell at all? — 7

Chapter 2 Under the UEFI Shell — 9

Shell and UEFI — 9

Evolution and Revolution — 13

Chapter 3 What Is the UEFI Shell? — 15

What Is Contained in the UEFI Shell? — 16

What Kind of Shell Do You Have? — 16

What!? No Shell? No Problem! — 17

Programmatic Shell Environment — 19

Using UEFI Shell Commands — 20

Interactive Shell Environment — 22

Scripting — 22

Program Launch — 24

File-System Abstractions — 29

Shell Script Resolves into a UEFI Firmware Action — 31

Chapter 4 Why We Need an Execution Environment before the OS — 33

Evolution of a Machine — 33

The Platform Initialization Flow — 34

UEFI Transitions — 36

States of a Platform — 38

Readiness of UEFI — 41

Migration Using the UEFI Shell — 44

Going Forward — 45

Chapter 5 Manufacturing — 47

Throughput — 47

Manufacturing Test Tools — 49

| | |
|--|----|
| Hardware Access with Manufacturing Tools | 50 |
| Converting Manufacturing Tools | 53 |
| Conclusion | 54 |

Chapter 6 Bare Metal Provisioning — 55

| | |
|----------------------------------|----|
| Provisioning with the UEFI Shell | 55 |
| UEFI Networking Stack | 56 |
| Securing the Network | 58 |
| Speeding Up the Network | 62 |
| Example of Putting It Together | 62 |
| Summary | 68 |

Chapter 7 Configuration of Provisioned Material — 69

| | |
|--|----|
| Initialization Timeline | 69 |
| Configuration Infrastructure Overview | 71 |
| Using the Configuration Infrastructure | 72 |
| Driver Model Interactions | 73 |
| Provisioning the Platform | 75 |
| Configuring through the UEFI Shell | 76 |
| Basic Configuration | 76 |
| Advanced Configuration Abilities | 79 |

Chapter 8 The Use of UEFI for Diagnostics — 85

| | |
|--|----|
| Types of Diagnostics | 85 |
| SMBIOS Table Organization | 87 |
| SMBIOS Structure Table Entry Point | 88 |
| Table Organization Graph | 88 |
| Structure Standards | 89 |
| Structure Evolution and Usage Guidelines | 90 |
| Text Strings | 90 |
| Required Structures and Data | 91 |
| Features | 91 |
| User Interface Design | 92 |
| Design Guide | 92 |
| Usage | 93 |
| Examples | 93 |
| Architecture Design | 94 |
| Data Structure | 95 |
| SMBIOS_STRUCTURE_TABLE | 95 |
| SMBIOS_HEADER | 97 |
| SMBIOS_STRUCTURE_POINTER | 98 |
| STRUCTURE_STATISTICS | 99 |

| | |
|---|------------|
| Source Code for the Utility — | 100 |
| Summary — | 105 |
| Chapter 9 UEFI Shell Scripting — | 107 |
| Hello, World! — | 108 |
| Echo — | 108 |
| Echo All Parameters — | 109 |
| Echo All Parameters (Improved Version) — | 110 |
| Concatenate Text Files — | 112 |
| List Only Selected “ls” Information — | 113 |
| Install Script — | 115 |
| How to Make a Shell Script Appear as a Boot Option — | 119 |
| Chapter 10 UEFI Shell Programming — | 121 |
| A Simple UEFI Shell Application: HelloWorld — | 121 |
| The Source File: HelloWorld.c — | 121 |
| The Component Information (.inf) File — | 123 |
| A Simple Standard Application: HelloWorld2 — | 124 |
| The Source File: HelloWorld2.c — | 124 |
| The Component Information (.inf) File: HelloWorld2.inf — | 125 |
| Read Keyboard Input in UEFI Shell Scripts: GetKey — | 126 |
| The Source File: GetKey.c — | 127 |
| The Component Information (.inf) File: GetKey.inf — | 137 |
| The Build Description (.dsc) File — | 139 |
| Calculate Math Expressions: Math — | 139 |
| The Source File: Math.c — | 140 |
| The Component Information (.inf) File: Math.inf — | 154 |
| Convert ASCII to Unicode and Back: UniCodeDecode — | 154 |
| The Source File: UniCodeDecode.c — | 155 |
| The Component Information (.inf) File — | 163 |
| Chapter 11 Managing UEFI Drivers Using the Shell — | 165 |
| Testing Specific Protocols — | 166 |
| Loading and Unloading UEFI Drivers — | 167 |
| Load — | 168 |
| LoadPciRom — | 168 |
| Unload — | 169 |
| Connecting UEFI Drivers — | 169 |
| Connect — | 169 |
| Disconnect — | 170 |
| Reconnect — | 170 |
| Driver and Device Information — | 171 |

| | |
|---|-----|
| Drivers | 171 |
| Devices | 172 |
| DevTree | 172 |
| Dh -d | 173 |
| OpenInfo | 173 |
| Testing the Driver Configuration and Driver Diagnostics Protocols | 174 |
| DrvCfg | 174 |
| DrvDiag | 174 |
| Debugging Code Statements | 175 |
| POST Codes | 177 |
| Post Card Debug | 178 |
| Text-Mode VGA Frame Buffer | 179 |
| Other Options | 179 |

Appendix A Security Considerations — 181

| | |
|---|-----|
| UEFI Shell Binary Integrity | 181 |
| Overview | 181 |
| Signed Executable Overview | 182 |
| Digital Signature | 183 |
| Signed Executable Processing | 185 |
| Signed Executable Generation Application (SignTool) | 185 |
| UEFI Load Image | 186 |
| SignTool | 186 |
| Build Environment | 186 |
| Example usage | 187 |

Appendix B Command Reference — 189

| | |
|-------------------------------------|-----|
| Command Profiles and Support Levels | 189 |
| Command List | 189 |
| Standardizing Command Output | 192 |
| Command Details | 193 |
| alias | 193 |
| attrib | 194 |
| bcfg | 194 |
| cd | 196 |
| cls | 197 |
| comp | 197 |
| connect | 198 |
| cp/copy | 199 |
| date | 199 |
| dblk | 200 |
| del | 200 |

| | |
|---------------|-----|
| devices | 200 |
| devtree | 201 |
| dh | 201 |
| dir/ls | 202 |
| disconnect | 202 |
| dmem | 203 |
| dmpstore | 204 |
| drivers | 204 |
| drvcfg | 205 |
| drvdiag | 206 |
| echo | 206 |
| edit | 207 |
| eficompress | 207 |
| efidecompress | 207 |
| exit | 207 |
| for | 208 |
| getmtc | 209 |
| goto | 209 |
| help | 209 |
| hexedit | 210 |
| if | 210 |
| ifconfig | 214 |
| ifconfig6 | 214 |
| load | 215 |
| loadpcirom | 216 |
| ls | 216 |
| map | 217 |
| md | 218 |
| mem | 218 |
| memmap | 218 |
| mkdir | 219 |
| mm | 219 |
| mode | 220 |
| mv | 220 |
| openinfo | 220 |
| parse | 221 |
| pause | 221 |
| pci | 221 |
| ping | 222 |
| ping6 | 222 |
| reconnect | 223 |
| reset | 223 |

| | |
|------------|-----|
| rm | 224 |
| sermode | 224 |
| set | 225 |
| setsize | 226 |
| setvar | 226 |
| shift | 227 |
| smbiosview | 227 |
| stall | 228 |
| time | 228 |
| time | 229 |
| touch | 229 |
| type | 230 |
| unload | 230 |
| ver | 230 |
| vol | 230 |

Appendix C Programming Reference — 233

| | |
|------------------------------|-----|
| Script-based Programming | 233 |
| Parameter Passing | 233 |
| Redirection and Piping | 234 |
| Return Codes | 235 |
| Environment Variables | 236 |
| Non-Script-based Programming | 237 |
| Shell Protocol | 238 |
| Shell Parameters Protocol | 240 |

Appendix D UEFI Shell Library — 241

| | |
|----------------------------------|-----|
| Functions | 241 |
| File I/O Functions | 241 |
| Miscellaneous Functions | 242 |
| Command Line Parsing | 243 |
| Text I/O | 244 |
| String Functions | 244 |
| ShellCloseFile() | 245 |
| ShellCloseFileMetaArg() | 246 |
| ShellCommandLineCheckDuplicate() | 246 |
| ShellCommandLineFreeVarList() | 247 |
| ShellCommandLineGetCount() | 247 |
| ShellCommandLineGetFlag() | 248 |
| ShellCommandLineGetValue() | 248 |
| ShellCommandLineGetRawValue() | 249 |
| ShellCommandLineParseEx() | 250 |

| | |
|------------------------------------|-----|
| ShellCopySearchAndReplace() | 251 |
| ShellConvertStringToUint64() | 252 |
| ShellCreateDirectory() | 253 |
| ShellDeleteFile() | 254 |
| ShellDeleteFileByName() | 254 |
| ShellExecute() | 255 |
| ShellFileExists() | 257 |
| ShellFileHandleReturnLine() | 257 |
| ShellFileHandleReadLine() | 258 |
| ShellFindFilePath() | 259 |
| ShellFindFilePathEx() | 260 |
| ShellFindFirstFile() | 260 |
| ShellFindNextFile() | 261 |
| ShellFlushFile() | 262 |
| SHELL_FREE_NON_NULL() | 263 |
| ShellGetCurrentDir() | 263 |
| ShellGetEnvironmentVariable() | 264 |
| ShellGetExecutionBreakFlag() | 265 |
| ShellGetFileInfo() | 265 |
| ShellGetFilePosition() | 266 |
| ShellGetFileSize() | 266 |
| ShellHexStrToUintn() | 267 |
| ShellInitialize() | 268 |
| ShellIsDecimalDigitCharacter() | 268 |
| ShellIsDirectory() | 269 |
| ShellIsFile() | 269 |
| ShellIsFileInPath() | 270 |
| ShellIsHexadecimalDigitCharacter() | 270 |
| ShellIsHexOrDecimalNumber() | 271 |
| ShellOpenFileByDevicePath() | 271 |
| ShellOpenFileByName() | 273 |
| ShellOpenFileMetaArg() | 274 |
| ShellPrintEx() | 275 |
| ShellPrintHelp() | 276 |
| ShellPrintHiiEx() | 277 |
| ShellPromptForResponse() | 278 |
| ShellPromptForResponseHii() | 279 |
| ShellReadFile() | 281 |
| ShellSetFileInfo() | 282 |
| ShellSetFilePosition() | 283 |
| ShellSetEnvironmentVariable() | 284 |
| ShellSetPageBreakMode() | 285 |

| | |
|-------------------|-------|
| ShellStrToUintn() | — 285 |
| ShellWriteFile() | — 286 |
| StrnCtGrow() | — 287 |
| Data Structures | — 288 |
| Format Strings | — 288 |
| Shell Parameters | — 289 |

| | |
|--------------|--------------|
| Index | — 291 |
|--------------|--------------|