




DELTA CONNECTION



NOTE: 1. WIRE IN EITHER DELTA OR STAR CONNECTIONS. NOT BOTH
3. CHECK ROTATION OF UNIT IS AS PER LABEL ON FAN (OR WARRANTY IS VOID)
4. CHANGE ROTATION OF DIRECTION BY INTERCHANGING 2 PHASES
5. PLEASE ENSURE THAT THERMAL OVERLOAD IS CONNECTED (OR WARRANTY IS VOID)

STAR CONNECTION



REV.	DESCRIPTION	DATE	BY	<div><div>106 FAIRBANK ROAD CLAYTON SOUTH, VICTORIA 3169 ph: +61 3 9551 4878 email: mail@cfmairsystems.com.au web: www.cfmairsystems.com.au</div></div> <div>THE INFORMATION CONTAINED HEREIN IS CONFIDENTIAL TO CFM FANS AND SHALL NOT BE REPRODUCED, COPIED OR DISCLOSED IN WHOLE OR IN PART, OR USED FOR MANUFACTURE OR FOR ANY OTHER PURPOSE WITHOUT THE WRITTEN PERMISSION OF CFM FANS. THIS PRINT IS TO BE RETURNED UPON DEMAND DESTROY OLD REVISIONS</div> <div>UNLESS OTHERWISE STATED DIMENSIONS ARE OUTSIDE DIMS, IN MILLIMETRES AND TO TOLERANCES LINEAR: ±1 ANGLE: ±10° (MIN) HOLES: WITHIN 0.5 OF TRUE POSITION</div>	MAT'L / FINISH: N/A	MODEL:
A	ISSUED FOR CONSTRUCTION	04.10.2020	CFM		DRAWN: CFM Airsystems	DIAGRAM # 33
					DATE: October 2020	
					CHECKED: M.KOTSIKAS	DESCRIPTION: ELECTRICAL DIAGRAM No.33
					SCALE: NTS	
					SHEET: A4	REV A