


- NOTE: 1. USE EARTH WIRE FROM LOW SPEED 4 WIRE CORE FOR CONNECTION AT HIGH SPEED  
 2. FAN CAN BE WIRED AS 2 SPEED. DO NOT USE STAR / DELTA SWITCH  
 3. CHECK ROTATION OF UNIT IS AS PER LABEL ON FAN (OR WARRANTY IS VOID)  
 4. FITTED WITH AUTOMATIC RESET OVERLOADS

REV.	DESCRIPTION	DATE	BY	 <p>106 FAIRBANK ROAD CLAYTON SOUTH, VICTORIA 3169 ph: +61 3 9551 4878 email: mail@cfmairsystems.com.au web: www.cfmairsystems.com.au</p> <p>THE INFORMATION CONTAINED HEREIN IS CONFIDENTIAL TO CFM FANS AND SHALL NOT BE REPRODUCED, COPIED OR DISCLOSED IN WHOLE OR IN PART, OR USED FOR MANUFACTURE OR FOR ANY OTHER PURPOSE WITHOUT THE WRITTEN PERMISSION OF CFM FANS. THIS PRINT IS TO BE RETURNED UPON DEMAND DESTROY OLD REVISIONS</p> <p>UNLESS OTHERWISE STATED DIMENSIONS ARE OUTSIDE DIMS, IN MILLIMETRES AND TO TOLERANCES            LINEAR: ±1      ANGLE: ±10° (MIN)      HOLES: WITHIN 0.5 OF TRUE POSITION</p>	MAT'L / FINISH: N/A	MODEL:
A	ISSUED FOR CONSTRUCTION	04.10.2020	CFM		DRAWN: CFM Airsystems	DIAGRAM # 5
					DATE: October 2020	
					CHECKED: M.KOTSIKAS	DESCRIPTION: ELECTRICAL DIAGRAM No.5
					SCALE: NTS	
					SHEET: A4	REV A