


- NOTE: 1. Y – BRIDGE FOR STAR CONNECTION (LOW SPEED)
2. WIRE IN EITHER DELTA OR STAR. NOT BOTH
3. CHECK ROTATION OF UNIT IS AS PER LABEL ON FAN (OR WARRANTY IS VOID)
4. CHANGE ROTATION OF DIRECTION BY INTERCHANGING 2 PHASES
5. PLEASE ENSURE THAT THERMAL OVERLOAD IS CONNECTED (OR WARRANTY IS VOID)

REV.	DESCRIPTION	DATE	BY	<div><div>106 FAIRBANK ROAD CLAYTON SOUTH, VICTORIA 3169 ph: +61 3 9551 4878 email: mail@cfmairsystems.com.au web: www.cfmairsystems.com.au</div></div> <div>THE INFORMATION CONTAINED HEREIN IS CONFIDENTIAL TO CFM FANS AND SHALL NOT BE REPRODUCED, COPIED OR DISCLOSED IN WHOLE OR IN PART, OR USED FOR MANUFACTURE OR FOR ANY OTHER PURPOSE WITHOUT THE WRITTEN PERMISSION OF CFM FANS. THIS PRINT IS TO BE RETURNED UPON DEMAND DESTROY OLD REVISIONS</div> <div>UNLESS OTHERWISE STATED DIMENSIONS ARE OUTSIDE DIMS, IN MILLIMETRES AND TO TOLERANCES LINEAR: ±1 ANGLE: ±10° (MIN) HOLES: WITHIN 0.5 OF TRUE POSITION</div>	MAT'L / FINISH: N/A		MODEL:	
A	ISSUED FOR CONSTRUCTION	04.10.2020	CFM		DRAWN: CFM Airsystems		DIAGRAM # 19	
					DATE: October 2020			
					CHECKED: M.KOTSIKAS			DESCRIPTION: ELECTRICAL DIAGRAM No.19
					SCALE: NTS			
					SHEET:	A4		