


ECU Power Source Circuit

CIRCUIT DESCRIPTION

The ECU power source supplies power to the actuator and sensors, etc. When terminal GND and the case of the cruise control ECU are grounded.

WIRING DIAGRAM




I07610

INSPECTION PROCEDURE

1 Check ECU-IG fuse.

LH Side J/B

**PREPARATION:**

Remove the ECU-IG fuse from the instrument panel junction block.

CHECK:

Check continuity of ECU-IG fuse.

OK:



Continuity

NG

Check for short in all the harness and components connected to ECU-B fuse.

OK

2 Check voltage between terminals B and GND of cruise control ECU connector.

**PREPARATION:**

(a) Remove the ECU with connector still connected.

(b) Turn ignition switch ON.

CHECK:

Measure voltage between terminals B and GND of ECU connector.

OK:


10 - 14 V

OK

Proceed to next circuit inspection shown in problem symptom table (See page DI-682).

NG

3 Check resistance between terminal GND of cruise control ECU connector and body ground.

**CHECK:**

Measure resistance between terminal GND of ECU connector and body ground.

OK:

Resistance: Below 1 Ω

NG

Repair or replace harness or connector.

OK

Check and repair harness and connector between cruise control ECU and battery (See page IN-35).