

The diagram is divided into two main sections: **Power Source** and **Turn Signal and Hazard Warning Light**.

**Power Source Section:**

- BATTERY:** Connected to the system.
- F17 FUSIBLE LINK BLOCK:** Contains a 100A MAIN fuse and a 140A ALT fuse.
- Fuses:** 20A AM1 NO. 2, 15A HAZ-TRN, and 80A AM1 NO. 1.
- Relays:** 1E, 1C, 10, 1N, 1G, 1J, 1E, 1J.
- Wiring:** Various wires (B-R, G-W, G-B, W-B) connect the battery to the fuses and relays.

**Turn Signal and Hazard Warning Light Section:**

- I26 IGNITION SW:** Connected to the battery and the turn signal flasher.
- J15 JUNCTION CONNECTOR:** Connects the ignition switch to the turn signal flasher.
- T16 TURN SIGNAL FLASHER:** The central component for the turn signals.
- Wiring:** Various wires (G-W, G-B, W-B, G-Y) connect the flasher to the turn signal lights and the battery.
- Turn Signal Lights:** F7 FRONT SIDE TURN SIGNAL LIGHT LH, F9 FRONT TURN SIGNAL LIGHT LH, R15 REAR TURN SIGNAL LIGHT LH [REAR COMB. LIGHT LH], F8 FRONT SIDE TURN SIGNAL LIGHT RH.
- Trailer Socket:** T18 TRAILER SOCKET.
- Other Components:** J18 JUNCTION CONNECTOR, J37 JUNCTION CONNECTOR, J5 JUNCTION CONNECTOR, J42 JUNCTION CONNECTOR, BO1, BO2, BF3.

