


<b>DTC</b>	<b>C1789 / 89</b>	<b>L4 Position Switch Circuit</b>
------------	-------------------	-----------------------------------

## CIRCUIT DESCRIPTION

This circuit is sending the signal to the ECU by detecting that the transfer shift lever is in "L4" position.

DTC No.	DTC Detecting Condition	Trouble Area
C1789 / 89	L4 position switch signal does not change.	<ul style="list-style-type: none"> <li>• L4 position switch</li> <li>• L4 position switch circuit</li> <li>• Suspension control ECU</li> </ul>

## WIRING DIAGRAM



**INSPECTION PROCEDURE****1 Check output signal of L4 position switch.****IN CASE OF USING HAND-HELD TESTER:****PREPARATION:**

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch ON and push the hand-held tester main switch ON.
- (c) Select the DATALIST mode on the hand-held tester.

**CHECK:**

Check the L4 position switch condition displayed on the hand-held tester when shifting the transfer shift lever in "L4" and "H4" positions.


**OK:**

**When the transfer shift lever is shifted in "L4" position:**

**"ON" is displayed for L4 position switch condition.**

**When the transfer shift lever is shifted in "H4" position:**

**"OFF" is displayed for L4 position switch condition.**

**IN CASE OF NOT USING HAND-HELD TESTER:****PREPARATION:**

Remove the suspension control ECU with connectors still connected.


**CHECK:**

- (a) Turn the ignition switch ON.
- (b) Measure voltage between terminal L4SW of suspension control ECU connector and body ground when transfer shift lever is shifted in "L4" and "H4" position.

**OK:**

Transfer shift lever position	Voltage
L4	Below 1.5 V
H4	9 – 14 V

**OK****No problem.****NG**

**2 Check L4 position switch.****PREPARATION:**

- (a) Disconnect the L4 position switch connector.  
(b) Remove the L4 position switch (See page TR-9).

**CHECK:**

Measure resistance between terminals 1 and 2 of L4 position switch connector when the L4 position switch pushed and released.

**OK:**

Switch condition	Resistance
Pushed	0 Ω (Continuity)
Released	∞ Ω (Open)

**NG****Replace L4 position switch.****OK****3 Check for open and short circuit in harness and connector between L4 position switch and suspension control ECU (See page IN-35).****NG****Repair or replace harness or connector.****OK****Check and replace suspension control ECU.**