

Power Source

Moon Roof

Legend:

- * 1 : Europe
- * 2 : Except Europe
- * 3 : 2UZ-FE, 1HD-FTE
- * 4 : Except *3

Power Source Details:

- Battery (Diesel) and Battery (Gasoline) connected to the main power line.
- F38 Fusible Link Block containing 120A J/B NO. 2 and 140A ALT.
- 25A SUN ROOF fuse (2L) and 7.5A AM1 fuse (2E).
- 10A ECU-IG1 fuse (2L) and IG1 NO. 2 Relay (2E).
- Wiring paths for B, B-R, B-W, L-B, and B-G.
- Set Bolt of Cowl Side J/B LH.

Moon Roof Details:

- M 1 Moon Roof Control ECU with pins IG, +B, BUS(*3), and PWS(*4).
- M 2 Moon Roof Control SW with UP, DOWN, OPEN, and CLOSE positions.
- Wiring paths for UP, DOWN, OPEN, CLOSE, E, E1, E2, and IE2.
- Motor (M) and switches (P1, P2) connected to the ECU.
- Set Bolt of Cowl Side J/B LH.

- * 1 : Europe
- * 2 : Except Europe
- * 3 : 2UZ-FE, 1HD-FTE
- * 4 : Except *3