

SUB FUEL PUMP

ON-VEHICLE INSPECTION

FIGHN-01

CHECK SUB FUEL PUMP OPERATION AND FUEL PRESSURE (See page FI-16)

NOTICE:

Push the fuel tank changeover switch ON.