

DTC	P1335/13	Crankshaft Position Sensor Circuit Malfunction (during engine running)
-----	----------	------------------------------------------------------------------------

CIRCUIT DESCRIPTION

Refer to DTC P0335/12, 13 (Crankshaft Position Sensor Circuit Malfunction) on [page DI-50](#).

DTC No.	DTC Detecting Condition	Trouble Area
P1335/13	No crankshaft position sensor signal to engine ECU with engine speed 1,000 rpm or more	<ul style="list-style-type: none"><li>• Open or short in crankshaft position sensor circuit</li><li>• Crankshaft position sensor</li><li>• Starter</li><li>• Engine ECU</li></ul>

WIRING DIAGRAM

Refer to DTC P0335/12, 13 (Crankshaft Position Sensor Circuit Malfunction) on [page DI-50](#) for the WIRING DIAGRAM.

INSPECTION PROCEDURE

Refer to DTC P0335/12, 13 (Crankshaft Position Sensor Circuit Malfunction) on [page DI-50](#) for the INSPECTION PROCEDURE.