



## FUEL TEMPERATURE SENSOR INSPECTION

ED00N-02

### 1. REMOVE FUEL TEMPERATURE SENSOR

- (a) Disconnect the sensor connector.
- (b) Using a 19 mm deep socket wrench, remove the sensor and gasket.

### 2. INSPECT FUEL TEMPERATURE SENSOR

(See page ED-5)

### 3. REINSTALL FUEL TEMPERATURE SENSOR

- (a) Using a 19 mm deep socket wrench, install a new gasket and the sensor.

**Torque: 21.6 N·m (220 kgf·cm, 16.5 ft·lbf)**

- (b) Connect the sensor connector.