


# F ELECTRICAL WIRING DIAGRAM (System Circuits)



### Radio and Player (7 Speaker)

The diagram illustrates the wiring for a 7-speaker car stereo system. The components and their connections are as follows:

- CD 6 AUTOMATIC CHANGER:** Pins 5 (+B), 12 (ACC), 4 (MUTE), 8 (GND), 10 (TX+), 9 (TX-), 3 (S. GND), 2 (CDL+), 7 (CDL-), 1 (CDR+), 6 (CDR-). Connections include L-Y, GR, W, W-B, P, L, L, G, R, and W (Shielded).
- RADIO AND PLAYER:** Pins 4 (+B), 3 (ACC), 1 (AMP+), 5 (MUTE), 12 (S. GND), 13 (BEEP), 6 (FL+), 7 (FR+), 14 (RL+), 15 (RR+), 11 (GND). Connections include L-Y, GR, B-R, O, B, G, P, Y, W, R (Shielded), and ANT+.
- STEREO COMPONENT AMPLIFIER:** Pins 4 (RL+), 11 (RL-), 3 (RR+), 10 (RR-), 6 (WL+), 15 (WL-), 5 (WR+), 14 (WR-), 12 (GND), 13 (GND). Connections include B, Y, R, W, L-W, L-Y, L-B, L-R, and BR.
- Speakers:**
  - R24 REAR DOOR SPEAKER LH:** Connected to BB1, BB2, and BB2.
  - R25 REAR DOOR SPEAKER RH:** Connected to BE1 and BE1.
  - W13 WOOFER (Speaker):** Connected to ID1 and ID1.
- Other Components:** IS1 (IS1), IS2 (IS2), ID1 (ID1), ID2 (ID2), BB1 (BB1), BB2 (BB2), BE1 (BE1), BE2 (BE2), ID1 (ID1), ID2 (ID2), BB1 (BB1), BB2 (BB2), BE1 (BE1), BE2 (BE2).

The diagram also shows the connection to the Auto Antenna Control Relay (391-3) and the BL (BL) terminal.