

## DTC C1516 / 16 VGRS Actuator Neutral Position Incomplete

### CIRCUIT DESCRIPTION

This code is set when the VGRS system calibration procedure does not complete normally.

DTC No.	DTC Detecting Condition	Trouble Area
C1516/16	The VGRS actuator angle adjustment did not complete normally.	<ul style="list-style-type: none"> <li>• VGRS actuator</li> <li>• VGRS ECU</li> </ul>

### INSPECTION PROCEDURE

1 Clear DTC (See page DI-91).

NEXT

2 Perform VGRS system calibration (See page DI-100).

NEXT

3 Is DTC C1516/16 output?

NO

VGRS system calibration is completed.

YES

4 Is DTC C1532/32 output?

YES

Replace VGRS ECU.

NO

Proceed to step 5.

**5****Is DTC C1516/16 output after 3 or more attempts?****YES****Replace VGRS actuator.****NO****Go to step 1**