

17. Panel switch does not function. (Navigation screen only)

INSPECTION PROCEDURE

1	Display check mode (Panel switch check screen)
---	--

NG

Replace the multi display.

OK

2	Check "AVC-LAN communication circuit". (See page DI-275)
---	--

NG

Replace or repair AVC-LAN circuit.

OK

Replace the navigation ECU.