

24. Driving direction is opposite to moving direction of vehicle position mark.

INSPECTION PROCEDURE

1 Navigation check mode (vehicle signal check mode REV)

OK

Replace the navigation ECU.

NG

2 Check the reverse signal circuit of navigation ECU (see page DI-273).

OK

Replace the navigation ECU.

NG

Replace or repair wire harness.