

## 5. No navigation displayed, "Audio OFF" on audio screen and no audio sound.

### INSPECTION PROCEDURE

1 Service check mode.

NG

Troubleshoot for each diagnosis.

OK

2 Check the radio receiver assembly.

#### PREPARATION:

Disconnect the radio receiver assembly connector.

#### CHECK:

Check voltage terminals +B.

#### OK:

+B: 10 – 14 V

#### CHECK:

Check voltage terminal ACC when turn ignition switch ACC or ON position.

#### OK:

ACC: 10 – 14 V

#### CHECK:

Check continuity terminal GND.

#### OK:

GND: Continuity

NG

Replace or repair wire harness.

OK

3 Check "AVC-LAN communication circuit" (See page DI-1215).

NG

Replace the AVC-LAN circuit or radio receiver assembly.

OK

**Replace the multi display.**