

The diagram is divided into two main sections: **Power Source** (left) and **Remote Control Mirror (w/o Driving Position Memory)** (right).

Power Source Section:

- BATTERY** is connected to a **140A ALT FUSIBLE LINK BLOCK** (F17).
- The circuit continues through a **20A AM1 NO. 2** fuse and an **80A AM1 NO. 1** fuse.
- The **IGNITION SW** (I26) is shown with terminals **ACC** and **IG1**.
- The **10A MIRR** fuse is connected to the mirror circuit.
- Junction Connectors:** J15, J28, J32, and J36 are used to connect various components.

Remote Control Mirror Section:

- The **REMOTE CONTROL MIRROR SW** (R9, R10) is connected to the power source.
- The **REMOTE CONTROL MIRROR LH** (R48) is connected to the mirror circuit.
- The **W-B** (Wash/Burn) and **MR** (Mirror Right) and **MF** (Mirror Left) functions are shown.
- The **IF** (Intermittent Flash) terminal is connected to the mirror circuit.

