

PROBLEM SYMPTOMS TABLE

Symptom	Suspect Area	See page
Theft deterrent system is not set.	1. Security indicator circuit 2. Key unlock warning switch circuit 3. Door courtesy switch circuit 4. Door unlock detection switch circuit 5. Engine hood courtesy switch circuit 6. Power source circuit 7. Theft deterrent ECU	DI-842 DI-847 DI-1008 DI-1081 DI-849 DI-839 -
Security indicator does not light up or blink.	1. Security indicator circuit 2. Theft deterrent ECU	DI-842 -
Theft deterrent system cannot be unset even if ignition switch is ON.	1. Key unlock warning switch circuit 2. Power source circuit 3. Theft deterrent ECU	DI-847 DI-839 -
During warning condition, horn does not operate.	1. Horn circuit 2. Theft deterrent ECU	DI-845 -