

G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
A 1	A/C Ambient Temp. Sensor	90980-11070	A37	Airbag Squib (Front Passenger Airbag Assembly) (Except 2UZ-FE Australia)	90980-11883
A 2	A/C Condenser Fan Motor	90980-11237	A38	Airbag Squib (Steering Wheel Pad)	90980-10850
A 3	A/C Condenser Fan Relay	90980-10940	A39	Ashtray Illumination	90980-10825
A 4	A/C Dual Pressure SW	90980-11149	A40	Auto Antenna Control Relay	90980-10819
A 5	A/C Magnetic Clutch	90980-11271	A41	A/C Amplifier	90980-11497
A 6	A/C Magnetic Clutch and Lock Sensor	90980-11016	A42	A/C Amplifier	90980-11475
A 7	A/C Magnetic Valve	90980-11075	A43	A/C Amplifier	90980-11502
A 8	A/C Triple Pressure SW (A/C Dual and Single Pressure SW)	90980-10943	A44	A/C Amplifier	90980-10801
A 9	A/T Oil Temp. Sensor (2UZ-FE)	90980-11025	A45	ABS Speed Sensor Rear LH (Independent Suspension)	90980-11073
	A/T Oil Temp. Sensor (Except 2UZ-FE)	90980-11243		ABS Speed Sensor Rear LH (Rigid Axle Suspension)	90980-11075
A10	ABS Actuator	90980-11009	A46	ABS Speed Sensor Rear RH (Independent Suspension)	90980-11073
A11	ABS Actuator	90980-11413		ABS Speed Sensor Rear RH (Rigid Axle Suspension)	90980-11075
A12	ABS Actuator	90980-10895	A47	Accumulator Solenoid	90980-11019
A13	ABS Actuator	90980-11151	B 1	Back-Up Light SW	90980-11051
A14	ABS Actuator	90980-10983	B 2	Brake Fluid Level Warning SW	90980-11207
A15	ABS Speed Sensor Front LH	90980-10941	B 3	Blower Motor Controller (LHD)	90980-10910
A16	ABS Speed Sensor Front RH	90980-11002		Blower Motor Controller (RHD)	90980-11667
A17	Accel Position Sensor (2UZ-FE)	90980-11150	B 4	Blower HI Relay	90980-10713
	Accel Position Sensor (1HD-T,1HZ)	90980-11016	B 5	Blower LO Relay	90980-10171
	Accel Position Sensor (1HD-FTE)	90980-11232	B 6	Blower ME Relay	
A18	AHC Pump Motor	90980-10928	B 7	Back Door Courtesy SW (Liftgate Type)	90980-10039
A19	Air Cleaner Warning Sensor	90980-11025		Back Door Courtesy SW (Swing Type)	90980-10444
A20	Air Flow Meter	90980-11317	B 8	Back Door Key Lock and Unlock SW (Liftgate Type)	90980-11490
A21	Airbag Sensor Front LH	90980-11856		Back Door Key Lock and Unlock SW (Swing Type)	90980-11170
A22	Airbag Sensor Front RH				
A23	Alternator	90980-09212	B 9	Back Door Lock Motor and Back Door Unlock Detection SW	90980-11150
A24	Alternator	90980-11349	B10	Buckle SW LH	90980-11211
A25	Auto Antenna Motor	90980-11194	B11	Buckle SW RH	
A26	A/C Solar Sensor	90980-11919	C 1	Camshaft Position Sensor	90980-10947
A27	A/C Thermistor (2UZ-FE Australia)	90980-11918	C 2	Center Diff. Lock Control Motor	90980-11024
	A/C Thermistor (Except 2UZ-FE Australia)	90980-10825	C 3	Check Connector	90980-11195
A28	ABS Deceleration Sensor	90980-10845	C 4	Crankshaft Position Sensor (2UZ-FE,1HD-FTE)	90980-11162
A29	ABS ECU	90980-11424		Crankshaft Position Sensor (1FZ-FE)	90980-11816
A30	ABS ECU	90980-11391	C 5	Cruise Control Actuator	90980-11150
A31	ABS ECU	90980-11390	C 6	CD Automatic Changer	90980-10803
A32	Accelerator Pedel SW	90980-10825	C 7	Center Airbag Sensor Assembly	90980-11872
A33	AHC Main Relay	90980-10221	C 8	Center Diff. Lock Control Relay	90980-10801
A34	Air Inlet Control Servo Motor	90980-11165	C 9	Center ECU	90980-11390
A35	Air Mix Control Servo Motor (LHD)	90980-10797	C10	Center ECU	90980-11391
	Air Mix Control Servo Motor (RHD)	90980-11529			
A36	Air Vent Mode Control Servo Motor (LHD)	90980-11165			
	Air Vent Mode Control Servo Motor (RHD)	90980-11321			
A37	Airbag Squib (Front Passenger Airbag Assembly) (RHD 2UZ-FE Australia)	90980-11884			

Note : Not all of the above part numbers of the connector are established for the supply. In case of ordering a connector or terminal with wire, please confirm in advance if there is supply for it using "Parts Catalog News" (published by Parts Engineering Administration Dept.).

Nota : Toutes les références du connecteur ne sont pas définies pour la fourniture. Pour passer une commande d'un connecteur ou d'une borne avec fil, prière de vérifier préalablement si cette pièce est bien disponible en se reportant à "Parts Catalog News" (publié par le Département de la Gestion de l'Ingénierie).

Code	Part Name	Part Number	Code	Part Name	Part Number
C11	Center ECU	90980-11408	D25	Door Lock Motor and Door Unlock Detection SW Front LH	90980-11150
C12	Center ECU	90980-11392	D26	Door Lock Motor and Door Unlock Detection SW Front RH	
C13	Cigarette Lighter	90980-10760	D27	Door Lock Motor and Door Unlock Detection SW Rear LH	
C14	Cigarette Lighter Illumination	90980-11148	D28	Door Lock Motor and Door Unlock Detection SW Rear RH	
C15	Combination Meter	82824-60060	D29	Driving Position Memory SW	90980-10601
C16	Combination Meter	82824-60050	D30	Detection SW (Front Diff. Lock)	90980-11250
C17	Combination Meter	82824-60060	E 1	ECT Solenoid (2UZ-FE,1HD-FTE)	90980-10891
C18	Combination Meter	82824-60050		ECT Solenoid (1FZ-FE,1HD-T,1HZ)	90980-10854
C19	Combination SW (RHD Except Europe)	90980-11671	E 2	EFI Water Temp. Sensor (2UZ-FE)	90980-10737
	Combination SW (Europe)	90980-11672		EFI Water Temp. Sensor (1FZ-FE,1HD-FTE)	
C20	Combination SW	90980-11581	E 3	Engine Hood Courtesy SW (RHD,Except LHD 1HD-FTE)	90980-10554
C21	Combination SW	90980-11616		Engine Hood Courtesy SW (LHD 1HD-FTE)	90980-11003
C22	Combination SW	90980-11594	E 4	ECT ECU	90980-11424
C23	Cooler Box	90980-11535	E 5	ECT ECU	90980-11392
C24	Cruise Control Clutch SW	90980-10906	E 6	ECT Pattern Select SW	90980-10933
C25	Cruise Control ECU	90980-11391	E 7	Engine and ECT ECU	90980-11421
C26	Control Valve Assembly	90980-11599	E 8	Engine and ECT ECU	90980-11476
D 1	Detection SW (Center Diff. Lock)	90980-11250	E 9	Engine and ECT ECU	90980-11586
D 2	Detection SW (Transfer L Position)		E10	Engine and ECT ECU	90980-11637
D 3	Detection SW (Transfer Neutral Position)	90980-11025	E11	Engine and ECT ECU	90980-11638
D 4	Diesel Engine Revolution Sensor	90980-11250	E12	Engine and ECT ECU	90980-11391
D 5	Damping Mode Select SW and Height Control SW	90980-11533	E13	Engine and ECT ECU	
D 6	Daytime Running Light Relay	90980-10807	E14	Engine and ECT ECU	90980-11392
D 7	Diode (Front Fog)	90980-10637	E15	EDU	90980-11024
D 8	DLC3	90080-98012	E16	Engine ECU	90980-11391
D 9	Door Lock Control SW	90980-10996	E17	Engine ECU	90980-11390
D10	Damping Force Control Actuator Front LH	90980-11960	E18	Engine ECU	90980-11408
D11	Damping Force Control Actuator Front RH		E19	Engine ECU	90980-11392
D12	Damping Force Control Actuator Rear LH		F 1	First Position SW	90980-10923
D13	Damping Force Control Actuator Rear RH		F 2	Fluid Pressure Sensor	90980-10845
D14	Detection SW (Rear Diff. Lock) (Independent Suspension)	90980-11156	F 3	Front Clearance Light LH	90980-11156
	Detection SW (Rear Diff. Lock) (Rigid Axle Suspension)	90980-11256	F 4	Front Clearance Light RH	
D15	Door Courtesy Light Front LH	90980-11148	F 5	Front Fog Light LH	90980-11660
D16	Door Courtesy Light Front RH		F 6	Front Fog Light RH	
D17	Door Courtesy Light Rear LH		F 7	Front Side Turn Signal Light LH	90980-11162
D18	Door Courtesy Light Rear RH		F 8	Front Side Turn Signal Light RH	
D19	Door Courtesy SW Front LH	90980-10871	F 9	Front Turn Signal Light LH	90980-11019
D20	Door Courtesy SW Front RH		F10	Front Turn Signal Light RH	
D21	Door Courtesy SW Rear LH		F11	Front Wiper Motor	90980-11599
D22	Door Courtesy SW Rear RH				
D23	Door Key Lock and Unlock SW LH	90980-11170			
D24	Door Key Lock and Unlock SW RH				

Nota : No todos los números de las partes del conector indicados arriba están dispuestos para el suministro. Al pedir un conector o terminal con cable, asegúrese, de antemano, de que esté suministrado refiriéndose a "Parts Catalog News" (publicado por el Departamento Administrativo de Ingeniería de las Partes).

Anmerkung : Nicht alle der obenerwähnten Teile-Nummern der Stecker werden für die Lieferung etabliert. Im Falle der Bestellung von Stecker oder Anschlußklemme mit Draht bestätigen Sie bitte unter Verwendung der "Teile-Prospekt-Nachrichten" (herausgegeben durch die Teile-Engineering-Verwaltungsabteilung) im voraus, ob es entsprechende Lieferung gibt.

G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
F12	Fuel Cut Valve Controller	90980-11349	H18	Horn RH	90980-10619
F13	Fuel Heater SW	90980-10928	H19	Headlight Beam Level Control SW (LHD Europe)	90980-10996
F14	Fuel Pump Resistor	90980-11156		Headlight Beam Level Control SW (Except LHD Europe)	90980-10797
F15	Fuel Sediment SW (1HZ,1HD-T,1HD-FTE)	90980-11003	H20	Height Control Sensor Rear	90980-11143
F16	Fuel Temp. Sensor (1HD-FTE)	90980-10737	H21	High Mounted Stop Light (Liftgate Type)	90980-11211
F17	Fusible Link Block	82620-60010		High Mounted Stop Light (Swing Type)	90980-10825
F18	Fuel Pump Inertia SW (2UZ-FE Europe)	90980-10825	I 1	Ignition Coil and Igniter No.1 (2UZ-FE)	90980-11885
F19	Front Blower Motor	90980-10903		Ignition Coil and Igniter No.1 (1FZ-FE)	90980-11158
F20	Front Blower Resistor (LHD)	90980-10910	I 2	Ignition Coil and Igniter No.2 (2UZ-FE)	90980-11885
	Front Blower Resistor (RHD)	90980-11136		Ignition Coil and Igniter No.2 (1FZ-FE)	90980-11158
F21	Front/Rear Diff. Lock Control SW or Rear Diff. Lock Control SW	90980-10631	I 3	Ignition Coil and Igniter No.3 (2UZ-FE)	90980-11885
F22	Fuel Tank Changeover SW	90980-10933		Ignition Coil and Igniter No.3 (1FZ-FE)	90980-11158
F23	Front Door Speaker LH	90980-10935	I 4	Ignition Coil and Igniter No.4 (2UZ-FE)	90980-11885
F24	Front Door Speaker RH		I 5	Ignition Coil and Igniter No.5 (2UZ-FE)	
F25	Front Interior Light		I 6	Ignition Coil and Igniter No.6 (2UZ-FE)	
F26	Front Personal Light		I 7	Ignition Coil and Igniter No.7 (2UZ-FE)	
F27	Front/Rear Diff Lock Control ECU	90980-10848	I 8	Ignition Coil and Igniter No.8 (2UZ-FE)	
F28	Fuel Pump and Sender	90980-11077	I 9	Injection Pump	90980-11028
F29	Fuel Pump Control ECU	90980-10862	I10	Injector No.1	90980-11153
F30	Fuel Pump Select Relay	90980-10173	I11	Injector No.2	
F31	Fuel Solenoid Valve 1	90980-10901	I12	Injector No.3	
F32	Fuel Solenoid Valve 2		I13	Injector No.4	
F33	Front Diff. Lock Motor	90980-11290	I14	Injector No.5	
G 1	Glow Plug	99141-13004	I15	Injector No.6	
G 2	Glow Plug Relay	90980-11569	I16	Injector No.7	
G 3	Glove Box Light	90980-11098	I17	Injector No.8	
H 1	Headlight Beam Level Control Actuator LH	90980-11016	I18	Intake Air Temp. Sensor (1FZ-FE)	90980-11163
H 2	Headlight Beam Level Control Actuator RH			Intake Air Temp. Sensor (1HD-FTE)	90980-11025
H 3	Headlight Cleaner Control Relay	90980-10939	I19	Intake Heater	99141-14006
H 4	Headlight Cleaner Motor	90980-11410	I20	Intake Heater Relay	90980-11248
H 5	Headlight Control ECU LH	90980-11255	I21	Intake Heater Relay	99141-14006
H 6	Headlight Control ECU RH		I22	Intake Heater Relay	99141-14006
H 7	Headlight LH (High)	98980-11659	I23	ISC Valve	90980-11145
H 8	Headlight RH (High)	90980-11659	I24	Idle-Up SW	90980-10933
H 9	Headlight LH (Low)	90980-11660	I25	Ignition Key Cylinder Light	90980-10906
H10	Headlight RH (Low)		I26	Ignition SW	90980-11615
H11	Heated Oxygen Sensor (Bank 1 Sensor 1)	90980-10869	I27	Instrument ECU	90980-11927
H12	Heated Oxygen Sensor (Bank 1 Sensor 2)	90980-11026	I28	Instrument ECU	90980-11914
H13	Heated Oxygen Sensor (Bank 2 Sensor 1)	90980-10869	I29	Instrument ECU	90980-11925
H14	Heated Oxygen Sensor (Bank 2 Sensor 2)	90980-11026	J 1	Junction Connector	-
H15	Height Control Sensor Front LH	90980-11015	J 2	Junction Connector	
H16	Height Control Sensor Front RH		J 3	Junction Connector	
H17	Horn LH	90980-10619	J 4	Junction Connector	

Note : Not all of the above part numbers of the connector are established for the supply. In case of ordering a connector or terminal with wire, please confirm in advance if there is supply for it using "Parts Catalog News" (published by Parts Engineering Administration Dept.).

Nota : Toutes les références du connecteur ne sont pas définies pour la fourniture. Pour passer une commande d'un connecteur ou d'une borne avec fil, prière de vérifier préalablement si cette pièce est bien disponible en se reportant à "Parts Catalog News" (publié par le Département de la Gestion de l'Ingénierie).

Code	Part Name	Part Number	Code	Part Name	Part Number
J 5	Junction Connector	-	J49	Junction Connector	-
J 6	Junction Connector		J50	Junction Connector	
J 7	Junction Connector		J51	Junction Connector	
J 8	Junction Connector		J52	Junction Connector	
J 9	Junction Connector		J53	Junction Connector	
J10	Junction Connector		K 1	Knock Sensor 1	90980-11166
J11	Junction Connector		K 2	Knock Sensor 2	
J12	Junction Connector		L 1	License Plate Light	90980-11159
J13	Junction Connector		L 2	License Plate Light LH	90980-10679
J14	Junction Connector		L 3	License Plate Light RH	90980-11148
J15	Junction Connector		L 4	Lumbar Support Control SW (Driver's Seat)	90980-10601
J16	Junction Connector		M 1	Moon Roof Control ECU	90980-10997
J17	Junction Connector		M 2	Moon Roof Control SW	90980-10789
J18	Junction Connector		N 1	Neutral Start SW, A/T Indicator Light SW and Back-Up Light SW	90980-11332
J19	Junction Connector		N 2	Noise Filter (Ignition)	90980-10843
J20	Junction Connector		O 1	O/D Direct Clutch Speed Sensor	90980-11156
J21	Junction Connector		O 2	O/D Main SW	90980-11606
J22	Junction Connector		O 3	Oil Level Sensor	90980-10532
J23	Junction Connector		O 4	Oil Pressure Sender (2UZ-FE,1FZ-FE)	90980-11363
J24	Junction Connector			Oil Pressure Sender (1HD-FTE,1HZ,1HD-T)	90980-18703
J25	Junction Connector		P 1	Pick-Up Sensor	90980-11157
J26	Junction Connector		P 2	Power Steering Oil Pressure SW	90980-11428
J27	Junction Connector		P 3	Power Outlet (Front)	90980-10760
J28	Junction Connector		P 4	Power Quarter Window SW LH	90980-10797
J29	Junction Connector		P 5	Power Quarter Window SW RH	90980-10996
J30	Junction Connector		P 6	Pre-Heating Timer	90980-10803
J31	Junction Connector	P 7	Parking Brake SW	90980-10871	
J32	Junction Connector	P 8	Power Outlet (Luggage Compartment)	90980-10860	
J33	Junction Connector	P 9	Power Vent Window Motor LH		
J34	Junction Connector	P10	Power Vent Window Motor RH		
J35	Junction Connector	P11	Power Window Control SW Front LH	90980-10789	
J36	Junction Connector	P12	Power Window Control SW Front RH		
J37	Junction Connector	P13	Power Window Control SW Rear LH		
J38	Junction Connector	P14	Power Window Control SW Rear RH		
J39	Junction Connector	P15	Power Window Master SW	90980-11791	
J40	Junction Connector	P16	Power Window Master SW	90980-11165	
J41	Junction Connector	P17	Power Window Motor Front LH (w/ Jam Protection)	90980-11599	
J42	Junction Connector		Power Window Motor Front LH (w/o Jam Protection)	90980-11003	
J43	Junction Connector	P18	Power Window Motor Front RH (w/ Jam Protection)	90980-11599	
J44	Junction Connector		Power Window Motor Front RH (w/o Jam Protection)	90980-11003	
J45	Junction Connector				
J46	Junction Connector				
J47	Junction Connector				
J48	Junction Connector				

Nota : No todos los números de las partes del conector indicados arriba están dispuestos para el suministro. Al pedir un conector o terminal con cable, asegúrese, de antemano, de que esté suministrado refiriéndose a "Parts Catalog News" (publicado por el Departamento Administrativo de Ingeniería de las Partes).

Anmerkung : Nicht alle der obenerwähnten Teile-Nummern der Stecker werden für die Lieferung etabliert. Im Falle der Bestellung von Stecker oder Anschlußklemme mit Draht bestätigen Sie bitte unter Verwendung der "Teile-Prospekt-Nachrichten" (herausgegeben durch die Teile-Engineering-Verwaltungsabteilung) im voraus, ob es entsprechende Lieferung gibt.

G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
P19	Power Window Motor Rear LH	90980-11003	R12	Room Temp. Sensor (Front) (Except 2UZ-FE Australia)	90980-10825
P20	Power Window Motor Rear RH	90980-11003	R13	Rear A/C Control SW	90980-11503
P21	Pretensioner LH	90980-11862	R14	Rear Air Mix Control Servo Motor	90980-11319
P22	Pretensioner RH		R15	Rear Combination Light LH	90980-11587
P23	Power Seat Control SW (Driver's Seat)	90980-10803	R16	Rear Combination Light LH (Europe)	90980-10825
P24	Power Seat Control SW (Front Passenger's Seat)			Rear Combination Light LH (Except Europe)	90980-10908
P25	Power Seat ECU	90980-11502	R17	Rear Combination Light RH	90980-11587
P26	Power Seat ECU	90980-11527		Rear Combination Light RH (Europe)	90980-10825
P27	Power Seat Motor (Driver's Seat Front Vertical Control)	90980-10825	R18	Rear Combination Light RH (Except Europe)	90980-10908
P28	Power Seat Motor (Driver's Seat Lumbar Support Control)		R19	Rear Cooler Blower Motor	90980-10214
P29	Power Seat Motor (Driver's Seat Rear Vertical Control)		R20	Rear Cooler Magnetic Valve	90980-10860
P30	Power Seat Motor (Driver's Seat Reclining Control)		R21	Rear Cooler Power Transistor	90980-10171
P31	Power Seat Motor (Driver's Seat Slide Control)		R22	Rear Cooler Relay	90980-10175
P32	Power Seat Motor (Front Passenger's Seat Front Vertical Control)		R23	Rear Diff. Lock Motor	90980-11194
P33	Power Seat Motor (Front Passenger's Seat Rear Vertical Control)		R24	Rear Door Speaker LH	90980-10935
P34	Power Seat Motor (Front Passenger's Seat Reclining Control)		R25	Rear Door Speaker RH	
P35	Power Seat Motor (Front Passenger's Seat Slide Control)		R26	Rear Evaporator Temp. Sensor	90980-10825
P36	Power Seat Position Sensor (Driver's Seat Front Vertical Control)	90980-10908	R27	Rear Heater Blower Motor	90980-10860
P37	Power Seat Position Sensor (Driver's Seat Rear Vertical Control)		R28	Rear Heater Blower Resistor	90980-10918
P38	Power Seat Position Sensor (Driver's Seat Reclining Control)		R29	Rear Heater Control SW	90980-10797
P39	Power Seat Position Sensor (Driver's Seat Slide Control)		R30	Rear Heater Power Transistor	90980-10171
R 1	Radio and Player	90980-11264	R31	Rear Heater Relay	
R 2	Radio and Player	90980-10997	R32	Rear Inlet Air Temp. Sensor	90980-11369
R 3	Radio and Player	90980-10803	R33	Rear Interior Light	90980-10935
R 4	Radio and Player	90980-10996	R34	Rear Parsonal Light	90980-10365
R 5	Radio and Player	90980-10803	R35	Rear Window Defogger	90980-11097
R 6	Rear Diff. Lock Control ECU	90980-10801	R36	Rear Window Defogger	
R 7	Rear Fog Light SW	90980-11165	R37	Rear Window Defogger LH	90980-10792
R 8	Relay Box	90980-10903	R38	Rear Window Defogger LH	
R 9	Remote Control Mirror SW	90980-11657	R39	Rear Window Defogger RH	
R10	Remote Control Mirror SW	90980-11319	R40	Rear Window Defogger RH	90980-10795
R11	Rheostat	90980-10908	R41	Rear Wiper Motor	
R12	Room Temp. Sensor (Front) (2UZ-FE Australia)	90980-11918	R42	Rear Wiper Motor LH	
			R43	Rear Wiper Motor RH	90980-10173
			R44	Rear Wiper Relay	
			R45	Rear Wiper Relay LH	90980-10797
			R46	Rear Wiper Relay RH	
			R47	Remote Control Mirror ECU	90980-11877
			R48	Remote Control Mirror LH	90980-11573
			R49	Remote Control Mirror RH	
			R50	Room Temp. Sensor (Rear)	90980-11918
			S 1	Speed Sensor (Combination Meter)	90980-11143
			S 2	Speed Sensor (ECT)	90980-11156

Note : Not all of the above part numbers of the connector are established for the supply. In case of ordering a connector or terminal with wire, please confirm in advance if there is supply for it using "Parts Catalog News" (published by Parts Engineering Administration Dept.).

Nota : Toutes les références du connecteur ne sont pas définies pour la fourniture. Pour passer une commande d'un connecteur ou d'une borne avec fil, prière de vérifier préalablement si cette pièce est bien disponible en se reportant à "Parts Catalog News" (publié par le Département de la Gestion de l'Ingénierie).

Code	Part Name	Part Number	Code	Part Name	Part Number
S 3	Spill Valve	90980-11154	V 3	Variable Resistor	90980-10902
S 4	Starter	90980-09585	V 4	Viscous Heater Magnetic Clutch	90980-11271
S 5	Starter (Independent Suspension)	90980-11400	V 5	Viscous Heater Relay	90980-10940
	Starter (Rigid Axle Suspension)	90980-11184	V 6	VRV (EGR)	90980-11162
S 6	Stop Light SW	90980-11118	V 7	VSV (A/C Idle-UP)	90980-11156
S 7	Suspension Control ECU	90980-11424	V 8	VSV (EGR Cut)	90980-11149
S 8	Suspension Control ECU	90980-11391	V 9	VSV (EVAP)	90980-11156
S 9	Suspension Control ECU	90980-11390	V10	VSV (Fully Closed)	
S10	Seat Heater SW (Driver's Seat)	90980-10996	V11	VSV (Turbo Pressure Sensor)	
S11	Seat Heater SW (Front Passenger's Seat)	90980-10797	V12	Viscous Heater Amplifier	90980-10801
S12	Stereo Component Amplifier	90980-10848	W 1	Water Temp. Cut Relay	90980-11304
S13	Stereo Component Amplifier	90980-10807	W 2	Washer Motor (2UZ-FE, 1FZ-FE, 1HD-T, 1HZ)	90980-11622
S14	Sub Fuel Pump	90980-11038		Washer Motor (1HD-FTE)	90980-11294
S15	Sub Fuel Pump Forcing Driving Relay	90980-10221	W 3	Water Temp. Sender	90980-11428
S16	Sub Fuel Sender	90980-11016	W 4	Water Temp. Sensor (Glow Plug)	90980-10737
S17	Seat Belt Warning Occupant Detection Sensor	90980-10860	W 5	Water Temp. SW (A/C)	90980-10184
			W 6	Water Temp. SW (ECT)	90980-11243
S18	Seat Heater (Driver's Seat)	90980-10987	W 7	Winch Main Relay	90980-10887
S19	Seat Heater (Front Passenger's Seat)		W 8	Winch Main Relay	-
T 1	Temp. Sensor (AHC)	90980-10737	W 9	Winch Main Relay	
T 2	Theft Deterrent Horn	90980-10619	W10	Winch Motor and Magnetic SW	90980-10887
T 3	Throttle Control Motor	90980-10942	W11	Winch Motor and Magnetic SW	90980-09507
T 4	Throttle Position Sensor (2UZ-FE)	90980-11037	W12	Wireless Door Lock ECU	90980-11264
	Throttle Position Sensor (1FZ-FE)	90980-11261	W13	Woofer (Speaker)	90980-10795
T 5	Timing Control Valve	90980-11285			
T 6	Turbo Pressure Sensor	90980-10845			
T 7	Turbo Pressure SW	90980-11003			
T 8	Telescopic Motor	90980-10799			
T 9	Theft Deterrent ECU	90980-10765			
T10	Theft Deterrent ECU	90980-10973			
T11	Tilt and Telescopic ECU	90980-10799			
T12	Tilt and Telescopic ECU	90980-10848			
T13	Tilt Motor	90980-10799			
T14	Transponder Key Amplifier (2UZ-FE)	90980-10933			
	Transponder Key Amplifier (1FZ-FE, 1HD-FTE, 1HD-T, 1HZ)	90980-10789			
T15	Transponder Key Computer	90980-11556			
T16	Turn Signal Flasher	90980-10799			
T17	Tire Carrier Courtesy SW	90980-10433			
T18	Trailer Socket	90980-10988			
T19	Tweeter LH	90980-11300			
T20	Tweeter RH				
U 1	Unlock Warning SW	90980-10860			
V 1	Vacuum Sensor	90980-10845			
V 2	Vacuum SW	90980-11252			

Nota : No todos los números de las partes del conector indicados arriba están dispuestos para el suministro. Al pedir un conector o terminal con cable, asegúrese, de antemano, de que esté suministrado refiriéndose a "Parts Catalog News" (publicado por el Departamento Administrativo de Ingeniería de las Partes).

Anmerkung : Nicht alle der obenerwähnten Teile-Nummern der Stecker werden für die Lieferung etabliert. Im Falle der Bestellung von Stecker oder Anschlußklemme mit Draht bestätigen Sie bitte unter Verwendung der "Teile-Prospekt-Nachrichten" (herausgegeben durch die Teile-Engineering-Verwaltungsabteilung) im voraus, ob es entsprechende Lieferung gibt.