

## CIRCUIT DESCRIPTION

The lift amount of EGR valve is controlled by the vacuum which is regulated by the E-VRV operated by the engine ECU.

If even one of the following conditions is fulfilled, the VSV is turned ON by a signal from the ECU. This results in atmospheric air acting on the EGR valve, closing the EGR valve and shutting off the exhaust gas (EGR cut-off).

- Before the engine is warmed up
- During deceleration (Diesel throttle valve closed)
- Light engine load (amount of intake air very small)
- Engine speed over 3,000 rpm

The diagram illustrates the EGR system wiring. Power from the battery (B) passes through a fusible link block (MAIN and ALT) and a battery disconnect switch (EE) to the Engine Room J/B. The J/B contains an ECD Relay and an ECD solenoid. The relay controls the ECD solenoid and the EGR valve (E-VRV). The EGR valve is connected to the EGR solenoid (VSV for EGR) and the EGR control solenoid (EGRC). The EGR solenoid is connected to the EGR valve (E-VRV) and the EGR control solenoid (EGRC). The EGR control solenoid is connected to the EGR valve (E-VRV) and the EGR control solenoid (EGRC). The EGR valve (E-VRV) is connected to the EGR solenoid (VSV for EGR) and the EGR control solenoid (EGRC). The EGR control solenoid (EGRC) is connected to the EGR valve (E-VRV) and the EGR control solenoid (EGRC). The EGR valve (E-VRV) is connected to the EGR solenoid (VSV for EGR) and the EGR control solenoid (EGRC). The EGR control solenoid (EGRC) is connected to the EGR valve (E-VRV) and the EGR control solenoid (EGRC).

## INSPECTION PROCEDURE

### When using hand-held tester


**1** Check the connection of vacuum hose.

**NG**

Repair or replace.

**OK**

**2** Check the vacuum between EGR valve and VSV for EGR at 1,500 rpm.



#### PREPARATION:

- (a) Using a 3-way connector, connect a vacuum gauge to the hose between the VSV and EGR valve.
- (b) Warm up the engine to above 80°C (176°F).

#### CHECK:

Check the vacuum at 1,500 rpm.

#### RESULT:

Type	Vacuum
I	0 kPa (0 mmHg, 0 in. Hg)
II	0 kPa (0 mmHg, in. Hg) ~ 28 kPa (210 mmHg, 8.3 in. Hg)
III	Above 28 kPa (210 mmHg, 8.3 in. Hg)

**Type I**


Go to step 7.

**Type III**

Go to step 10

**Type II**

### 3 Check the VSV circuit for EGR.



#### PREPARATION:

- Disconnect the vacuum hose from the VSV for EGR.
- Connect the hand-held tester to the DLC3.
- Turn the ignition switch ON and push the hand-held tester main switch ON.
- Select the ACTIVE TEST mode on the hand-held tester.

#### CHECK:

Check operation of VSV for EGR, when it is operated by the hand-held tester.

#### OK:

**VSV is ON:**

Air from pipe E flows out through air filter.

**VSV is OFF:**

Air does not flow from pipe E to air filter.

OK

Check the connection, damage and blockage of vacuum hose.

NG


### 4 Check VSV for EGR (See page EC-9)

NG

Replace VSV for EGR.

OK

# 5 Check voltage between terminal EGR of engine ECU and body ground.



## PREPARATION:


- (a) Remove the glove compartment door.
- (b) Turn the ignition switch ON.

## CHECK:

Measure voltage between terminal EGR of engine ECU and body ground.

## OK:

Voltage: 9 – 14 V



## Reference: INSPECTION USING OSCILLOSCOPE

During EGR system ON (engine speed 1,500 rpm), check waveform between terminals EGR and E1 of engine ECU.

## HINT:

The correct waveform is as shown.

NG

Check and replace engine ECU  
(See page IN-19).

OK


# 6 Check for open and short in harness and connector between VSV for EGR and engine ECU (See page IN-19).

NG

Repair or replace harness or connector.

OK

## 7 Check operation of E-VRV.



### PREPARATION:

- Disconnect the vacuum hoses from the E-VRV.
- Connect the hand-held tester to the DLC3.
- Turn the ignition switch ON and the push hand-held tester main switch ON.
- Select the ACTIVE TEST mode on the hand-held tester.

### CHECK:

Check operation of E-VRV, when it is operated by the hand-held tester.

### OK:

**E-VRV ON:**

Air from pipe E is flowing out through pipe F.

**E-VRV OFF:**

Air from pipe E is flowing out through air filter.

OK

Go to step 10.

NG

## 8 Check E-VRV for EGR (See page EC-9).

NG

Replace E-VRV.

OK

## 9 Check for open and short in harness and connector between E-VRV and engine ECU, E-VRV and ECD main relay (Marking ECD) (See page IN-19).

NG

Repair or replace harness or connector.

OK

10 Check EGR valve (See page EC-9).

NG

Replace the EGR valve.

OK

Check and replace engine ECU (See page IN-19).

### When not using hand-held tester

1 Check the connection of vacuum hose.

NG

Repair or replace.

OK

2 Check the vacuum between EGR valve and VSV for EGR at 1,500 rpm (See page DI-85, Step 2).

Type I

Go to step 6.

Type III

Go to step 9.

Type II

3 Check VSV for EGR (See page EC-9).

NG

Replace VSV for EGR.

OK

- 4 Check voltage between terminal EGR of engine ECU and body ground (See page DI-85, Step 5).

NG

Check and replace engine ECU  
(See page IN-19).

OK


- 5 Check for open and short in harness and connector between VSV for EGR and engine ECU (See page IN-19).

NG

Repair or replace harness or connector.

OK

- 6 Check operation of E-VRV.

**PREPARATION:**

- Remove the glove compartment door.
- Disconnect the "E17" connector of engine ECU.
- Turn the ignition switch ON.

**CHECK:**

Check E-VRV operation.

- Connect between terminal EGR of engine ECU connector and body ground (ON).
- Disconnect between terminal EGR of engine ECU connector and body ground (OFF).

**OK:****E-VRV ON:**

Air from pipe E is flowing out through pipe F.

**E-VRV OFF:**

Air from pipe E is flowing out through air filter.

OK

Go to step 9.

NG

7 Check E-VRV (See page EC-9).

NG

Replace E-VRV.

OK

8 Check for open and short in harness and connector between E-VRV and engine ECU, E-VRV and ECD main relay (Marking: ECD) (See page IN-19).

NG

Repair or replace harness or connector.

OK

9 Check EGR valve (See page EC-9).

NG

Replace EGR valve.

OK

Check and replace engine ECU (See page IN-19).