


Security Indicator Light Circuit

CIRCUIT DESCRIPTION


WIRING DIAGRAM



I26278

INSPECTION PROCEDURE

- 1 Check voltage between terminals IND of transponder key ECU connector and body ground.

**PREPARATION:**

Turn ignition switch ON and do diagnosis mode.

CHECK:

Measure voltage between terminals IND of transponder key ECU connector and body ground when security indicator light light up and does not light up.

OK:


Indicator light	Voltage
Light up	3 - 6 V
Does not light up	Below 1 V

NG

Proceed to next circuit inspection shown in problem symptom table (See page DI-893).

OK

- 2 Check multi-information display.

**PREPARATION:**

Turn ignition switch ON and do diagnosis mode.

CHECK:

Measure voltage between terminals IND of transponder key ECU connector and body ground when security indicator light light up and does not light up.

OK:

Indicator light	Voltage
Light up	8 - 10 V
Does not light up	Below 1 V

NG

Repair or Replace wire harness or connector.

OK

Check and replace multi-information display.