

The diagram illustrates the electrical system for the Power Window (Europe). It is divided into four main sections: 1. Power Source, 2. Power Window (Europe), 3. Power Window Motor Front LH, and 4. Power Window Motor Front RH. The Power Source section includes a 40A POWER fuse, a 2G fuse, a 100A J/B NO 2 fuse, a 140A ALT fuse, and a BATTERY. The Power Window (Europe) section shows the master switch (P15) and control switches (P12, P13, P14) with their respective wiring and relays. The Power Window Motor Front LH (P17) and Power Window Motor Front RH (P18) sections show the motor wiring and ground connections. The Power Window Motor Rear LH (P19) and Power Window Motor Rear RH (P20) sections show the motor wiring and ground connections. The diagram uses standard electrical symbols for fuses, relays, switches, and motors, and includes color codes (R, L, Y, B, G, W) for the wiring.