

Position of Parts in Engine Compartment

Code	English	Deutsch
H 3	Headlight Cleaner Control Relay	Scheinwerferwaschersteuerrelais
H 4	Headlight Cleaner Motor	Scheinwerferwaschermotor
H 7	Headlight LH (High)	Scheinwerfer, links (Fern)
H 8	Headlight RH (High)	Scheinwerfer, rechts (Fern)
H 9	Headlight LH (Low)	Scheinwerfer, links (Abblend)
H 10	Headlight RH (Low)	Scheinwerfer, rechts (Abblend)
H 17	Horn LH	Hupe, links
H 18	Horn RH	Hupe, rechts
I 1	Ignition Coil and Igniter No.1	Zündspule und Schaltgerät Nr.1
I 2	Ignition Coil and Igniter No.2	Zündspule und Schaltgerät Nr.2
I 3	Ignition Coil and Igniter No.3	Zündspule und Schaltgerät Nr.3
I 10	Injector No.1	Einspritzventil Nr.1
I 11	Injector No.2	Einspritzventil Nr.2
I 12	Injector No.3	Einspritzventil Nr.3
I 13	Injector No.4	Einspritzventil Nr.4
I 14	Injector No.5	Einspritzventil Nr.5
I 15	Injector No.6	Einspritzventil Nr.6
I 18	Intake Air Temp. Sensor	Ansauglufttemperatursensor
I 23	ISC Valve	ISC-Ventil
K 1	Knock Sensor 1	Klopfsensor 1
K 2	Knock Sensor 2	Klopfsensor 2
N 1	Neutral Start SW, A/T Indicator Light SW and Back-Up Light SW	Neutralstartschalter, A/T-Fahrstufenanzeige und Rückfahrscheinwerferschalter
N 2	Noise Filter (Ignition)	Störschutzfilter (Zündung)
O 3	Oil Level Sensor	Ölstandsensor
S 1	Speed Sensor (Combination Meter)	Geschwindigkeitssensor (Kombiinstrument)
S 2	Speed Sensor (ECT)	Geschwindigkeitssensor (ECT)
S 4	Starter	Anlasser
S 5	Starter	Anlasser
T 2	Theft Deterrent Horn	Diebstahlschutzhupe
T 4	Throttle Position Sensor	Drosselklappenpositionssensor
V 1	Vacuum Sensor	Unterdrucksensor
V 3	Variable Resistor	Regelwiderstand
W 2	Washer Motor	Waschermotor
W 3	Water Temp. Sender	Kühlmitteltemperaturgeber
W 7	Winch Main Relay	Windenhauptrelais
W 8	Winch Main Relay	Windenhauptrelais
W 9	Winch Main Relay	Windenhauptrelais
W 10	Winch Motor and Magnetic SW	Windenmotor und Magnetschalter
W 11	Winch Motor and Magnetic SW	Windenmotor und Magnetschalter