



- H 1 Headlight Beam Level Control Actuator LH
- H 2 Headlight Beam Level Control Actuator RH
- H 3 Headlight Cleaner Control Relay
- H 4 Headlight Cleaner Motor
- H 7 Headlight LH (High)
- H 8 Headlight RH (High)
- H 9 Headlight LH (Low)
- H 10 Headlight RH (Low)
- H 15 Height Control Sensor Front LH
- H 16 Height Control Sensor Front RH
- H 17 Horn LH
- H 18 Horn RH
  
- I 9 Injection Pump
- I 18 Intake Air Temp. Sensor
- I 19 Intake Heater
- I 20 Intake Heater Relay
- I 21 Intake Heater Relay
- I 22 Intake Heater Relay
  
- M 3 Master Cylinder Pressure Sensor
  
- N 1 A/T Indicator Light SW , Neutral Start SW
- N 6 Noise Filter (ABS)
  
- O 3 Oil Level Sensor
- O 4 Oil Pressure Sender
  
- P 2 Power Steering Oil Pressure SW
  
- S 1 Speed Sensor (Combination Meter)
- S 2 Speed Sensor (ECT)
- S 3 Spill Valve
- S 4 Starter
- S 5 Starter
- S 20 Swirl Control Valve
  
- T 1 Temp. Sensor (AHC)
- T 2 Theft Deterrent Horn
- T 3 Throttle Control Motor
- T 5 Timing Control Valve
- T 6 Turbo Pressure Sensor
- T 25 Turbine Speed Sensor
  
- V 2 Vacuum SW
- V 4 Viscous Heater Magnetic Clutch
- V 6 VRV (EGR)
- V 8 VSV (EGR Cut)
- V 11 VSV (Turbo Pressure Sensor)
- V 14 VRV (EGR No.2)
  
- W 2 Washer Motor
- W 7 Winch Main Relay
- W 8 Winch Main Relay
- W 9 Winch Main Relay
- W 10 Winch Motor and Magnetic SW
- W 11 Winch Motor and Magnetic SW
  
- Z 10 Option Connector (Wireless Door Lock Buzzer)



