


DTC	C1257 / 57	Power Supply Drive Circuit
------------	-------------------	-----------------------------------

CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1257 / 57	When malfunction inside ECU is detected.	<ul style="list-style-type: none"> Battery Power source circuit Skid control ECU

WIRING DIAGRAM



INSPECTION PROCEDURE**1 Check battery voltage.****OK:**


Voltage: 10 – 14 V

NG**Check and repair the charging system.****OK****2 Check voltage of the ECU IG power source.****In case of using the hand-held tester.****PREPARATION:**

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch ON and push the hand-held tester main switch ON.
- (c) Select the DATALIST mode on the hand-held tester.

CHECK:

Check the voltage condition output from the ECU displayed on the hand-held tester.

OK:**"Normal" is displayed.****In case of not using the hand-held tester:****PREPARATION:**

Remove skid control ECU with connectors still connected.

CHECK:


- (a) Turn the ignition switch ON.
- (b) Measure voltage between terminals IG1 and GND of skid control ECU connector.

OK:

Voltage: 10 – 14 V

OK**Turn ignition switch OFF, check and replace skid control ECU.****NG**

3 Check continuity between terminal GND of skid control ECU connector and body ground.



CHECK:

Measure resistance between terminal GND of skid control ECU connector and body ground.

OK:

Resistance: 1 Ω or less


NG

Repair or replace harness or connector.

OK

4 Check ECU-IG fuse.

Cowl Side J/B L.H.:



PREPARATION:

Remove ECU-IG fuse from the cowl side J/B L.H.

CHECK:

Check continuity of ECU-IG fuse.

OK:

Continuity

NG

Check for short circuit in all the harness and components connected to ECU-IG fuse (See attached wiring diagram).

OK

Check for open circuit in harness and connector between skid control ECU and battery (See page IN-38).