


Reverse Signal Circuit

CIRCUIT DESCRIPTION


The navigation ECU receives the reverse signal from the park/neutral position switch and information about the GPS antenna, and then adjusts the vehicle position.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 Check voltage between terminals REV and of navigation ECU and body ground.



(a) Measure the voltage according to the value(s) in the table below.

Standard:


Tester connection (Terminal No.)	Condition	Specified condition
REV – Body ground	IG SW ON, Shift lever R position	10 to 14 V

OK

Proceed to next circuit inspection shown in problem symptoms table. (See page DI-209)

NG

2 Check for open or short circuit in harness and connector between navigation ECU and park/neutral position switch (A/T) or back-up light switch (M/T) assembly.



(a) Disconnect the connector from the navigation ECU.

(b) Measure the resistance according to the value(s) in the table below.

Standard:**A/T (2UZ-FE, 1HD-FTE):**

Tester connection	Condition	Specified condition
REV – N1-2	Always	Below 1 Ω
REV – Body ground	Always	10 kΩ or higher

A/T (1FZ-FE):

Tester connection	Condition	Specified condition
REV – N1-4	Always	Below 1 Ω
REV – Body ground	Always	10 kΩ or higher

M/T:

Tester connection	Condition	Specified condition
REV – B1-1	Always	Below 1 Ω
REV – Body ground	Always	10 kΩ or higher

OK

Replace park/neutral position switch assembly.

NG

Repair or replace harness or connector.