


## Ignition Switch Circuit

## CIRCUIT DESCRIPTION

This circuit sends an ignition switch ON or OFF signal to the ECU.

## WIRING DIAGRAM



INSPECTION PROCEDURE

1

Check ECU-IG1 and AM1 fuse.


NG

Check for short in all the harness and components connected to ECU-IG1 and AM1 fuse, and repair them.

OK

2

Check voltage between terminal IG of sliding roof gear assembly with ECU connector and body ground.



**PREPARATION:**  
Remove Power Seat Control ECU with connectors still connected.

**CHECK:**  
Measure voltage between terminal IG of Power Seat Control ECU connector and body ground when Ignition switch is ON and OFF.

<b>OK:</b>	
Ignition switch	Voltage
ON	10 ~ 14 V
OFF	0 V

OK

Proceed to next circuit inspection shown in problem symptom table (See page DI-967).

NG

Repair or replace harness or connector between sliding roof gear assembly with ECU and battery.