

<b>DTC</b>	<b>P0325/52</b>	<b>Knock Sensor 1 Circuit Malfunction</b>
------------	-----------------	---


<b>DTC</b>	<b>P0330/55</b>	<b>Knock Sensor 2 Circuit Malfunction</b>
------------	-----------------	---

## CIRCUIT DESCRIPTION

Knock sensors are fitted to the cylinder block to detect engine knocking. This sensor contains a piezoelectric element which generates a voltage when it becomes deformed, which occurs when the cylinder block vibrates due to knocking. If engine knocking occurs, ignition timing is retarded to suppress it.

DTC No.	DTC Detecting Condition	Trouble Area
P0325/52	No knock sensor 1 signal to engine ECU with engine speed between 1,800 rpm and 5,200 rpm	<ul style="list-style-type: none"> <li>• Open or short in knock sensor 1 circuit</li> <li>• Knock sensor 1 (looseness)</li> <li>• Engine ECU</li> </ul>
P0330/55	No knock sensor 2 signal to engine ECU with engine speed between 1,800 rpm and 5,200 rpm	<ul style="list-style-type: none"> <li>• Open or short in knock sensor 2 circuit</li> <li>• Knock sensor 2 (looseness)</li> <li>• Engine ECU</li> </ul>

## WIRING DIAGRAM




P22425

## INSPECTION PROCEDURE

### HINT:

- Read freeze frame data using hand-held tester. Because freeze frame records the engine conditions when the malfunction is detected, when troubleshooting it is useful for determining whether the vehicle was running or stopped, the engine warmed up or not, the air-fuel ratio lean or rich, etc. at the time of the malfunction.
- DTC P0325/52 is for the knock sensor circuit on the front side.
- DTC P0330/55 is for the knock sensor circuit on the rear side.

### 1 Check continuity between terminal KNK1, KNK2 of engine ECU connector and body ground.



#### PREPARATION:

- Remove the glove compartment door.
- Disconnect the E12 connector of engine ECU.

#### CHECK:

Measure resistance between terminal KNK1, KNK2 of engine ECU connector and body ground.

#### OK:



**Resistance: 1 MΩ or higher**

#### Reference: INSPECTION USING OSCILLOSCOPE

- With the engine racing (4,000 rpm) measure between terminal KNK1, KNK2 of engine ECU and body ground.

#### HINT:

The correct waveform is as shown.



A00068

OK

Go to step 3.

NG

2 Check knock sensor.

NG

Replace knock sensor.

OK

3 Check for open and short in harness and connector between engine ECU and knock sensor (See page N-19).

NG

Repair or replace harness or connector.

OK

4 Does malfunction disappear when a good knock sensor is installed?

YES

Replace knock sensor.

NO

Check and replace engine ECU  
(See page N-19)