


## INSTALLATION

### 1. INSTALL INJECTION PUMP


#### NOTICE:

**Do not put the injection pump at an angle more than 45° from the horizontal.**

- (a) Install a new O-ring to the pump.
- (b) Apply a light coat of engine oil on the O-ring.
- (c) 1HD-T:  
Place the No. 1 Cylinder block insulator.




- (d) Align the set key on the drive shaft and groove of the injection pump drive gear.



- (e) Align the period lines (or matchmarks) of the injection pump and timing belt case.
- (f) Install the 2 nuts holding the injection pump to the timing gear case.

**Torque: 18 N·m (185 kgf·cm, 13 ft·lbf)**



- (g) Install the injection pump stay with the bolt.


**Torque: 69 N·m (700 kgf·cm, 51 ft·lbf)**

#### NOTICE:

**Before tightening to the standard torque, check whether the pump stay is up against the injection pump.**

If there is a gap, loosen the bolts joining the pump stay to the cylinder block and set the pump stay against the injection pump.

- (h) Install a new O-ring to the injection pump drive gear.




- (i) Install the injection pump drive gear set nut.
- (j) Hold the crankshaft pulley, and torque the nut.

**Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)**

#### NOTICE:

**Do not turn the crankshaft pulley. The valve heads will hit against the piston top.**

- (k) Check the thrust clearance of the injection pump drive shaft. (See page EM-11)



## 2. CONNECT HOSES

- (a) Connect the fuel return hose.
- (b) 1HD-T:  
Connect the boost compensator hose.
- (c) 1HD-T (w/ BACS)  
Connect the BACS hose.

## 3. A/T:

### CONNECT THROTTLE POSITION SENSOR CONNECTOR TO ACCELERATOR LINK

## 4. w/ACSD:

### CONNECT WATER BYPASS HOSES TO THERMO WAX

## 5. INSTALL NO.2 CAMSHAFT TIMING PULLEY

(See page EM-31)

## 6. INSTALL TIMING BELT (See page EM-31)

## 7. CHECK INJECTION TIMING (See page EM-11)

## 8. INSTALL INJECTION PIPES (See page FU-13)

Torque:

1HZ: 14.7 N·m (150 kgf·cm, 11 ft·lbf)

1HD-T: 24.5 N·m (250 kgf·cm, 18 ft·lbf)

## 9. 1HD-T:

INSTALL OIL FILTER (See page LU-2)

## 10. FILL WITH ENGINE COOLANT (See page CO-2)

## 11. START ENGINE AND CHECK FOR FUEL LEAKAGE