


DTC	C1257 / 57	Power Supply Drive Circuit
-----	------------	----------------------------

## CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1257 / 57	After the ignition switch has been turned ON, open or short circuit in circuit of power supply drive system inside ECU.	<ul style="list-style-type: none"> <li>• Battery</li> <li>• Power source circuit</li> <li>• ABS ECU</li> </ul>

## WIRING DIAGRAM



F05555

## INSPECTION PROCEDURE

1	Check battery voltage.
---	------------------------

**OK:**

Voltage: 10 – 14 V

**NG**

Check and repair the charging system.

**OK**

2	Check voltage of the ECU IG power source.
---	---


**IN CASE OF USING HAND-HELD TESTER:****PREPARATION:**

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch ON and push the hand-held tester main switch ON.
- (c) Select the DATALIST mode on the hand-held tester.

**CHECK:**

Check the voltage condition output from the ECU displayed on the hand-held tester.

**OK:****"Normal" is displayed.**

**IN CASE OF NOT USING HAND-HELD TESTER:****PREPARATION:**


Remove ABS ECU with connectors still connected.

**CHECK:**

- (a) Turn the ignition switch ON.
- (b) Measure voltage between terminals IG1 and GND of ABS ECU connector.

**OK:**

**Voltage: 10 – 14 V**

**CHECK:**

- (a) Turn the ignition switch ON.
- (b) Measure voltage between terminals IG2 and GND of ABS ECU connector.

**OK:**

**Voltage: 10 – 14 V**


**OK**

**Ignition switch OFF, check and replace ABS ECU.**

**NG**

**3**

**Check continuity between terminal GND of ABS ECU connector and body ground.**

**CHECK:**

Measure resistance between terminal GND of ABS ECU connector and body ground.

**OK:**

**Resistance: 1  $\Omega$  or less**


**NG**

**Repair or replace harness or connector.**

**OK**

#### 4 Check ECU-IG fuse.

Driver's  
Side J/B



F04448

#### **PREPARATION:**

Remove ECU-IG fuse from the driver's side J/B.

#### **CHECK:**

Check continuity of ECU-IG fuse.

#### **OK:**

**Continuity**

**NG**

Check for short circuit in all the harness and components connected to ECU-IG fuse (See attached wiring diagram).

**OK**

Check for open circuit in harness and connector between ABS ECU and battery (See page IN-24).