



INSTALLATION

1. CHECK TORQUE CONVERTER CLUTCH INSTALLATION

Using calipers and a straight edge, measure the distance from the installed surface of the transmission housing to the installed surface of the torque converter clutch.

Correct distance: More than 43.4 mm (1.710 in.)

2. TRANSMISSION INSTALLATION

Installation is in the reverse order of removal. (See page AT-12)

HINT:

- Transmission control rod and park/neutral position switch (See page DI-33).
- ATF level (See page DI-33).
- Conduct the road test of the vehicle (See page DI-33).