

3. No navigation screen displayed when "MAP", "Menu", or "DEST" switch pressed. (Screen cannot be switched.)

INSPECTION PROCEDURE

1	Service check mode (Check the navigation ECU)
---	---

NG	Troubleshoot for each diagnosis.
OK	Replace multi-display.

Ncon

2	Check the navigation ECU power source circuit (see page DI-256).
---	--

NG	Replace or repair wire harness or connector.
----	--

OK

3	Check multi-display power source circuit (see page DI-259).
---	---

NG	Replace or repair wire harness or connector.
----	--

OK

4	Check the display signal circuit (see page DI-270).
---	---

NG	Replace or repair wire harness or connector.
----	--

OK

Replace multi display.