


SLIP Indicator Light Circuit

CIRCUIT DESCRIPTION


The SLIP indicator blinks during VSC operation.

WIRING DIAGRAM

LHD:



RHD:



INSPECTION PROCEDURE


1 Does the warning lights other than SLIP indicator lights up?

YES

Go to step 3.

NO

2 Check IG1 No. 1 relay.



BE1840
R15257
R15258

F00044

PREPARATION:

Remove IG1 No. 1 relay from engine room J/B.

CHECK:

Check continuity between each pair of terminal of IG1 No. 1 relay.

OK:

Terminals 3 and 4	Continuity
Terminals 1 and 2	Open

CHECK:

- (a) Apply battery voltage between terminals 3 and 4.
- (b) Check continuity between terminals.

OK:

Terminals 1 and 2	Continuity
-------------------	------------

NG

Replace IG1 No. 1 relay.

OK

Check for open circuit in harness and connector between IG1 No. 1 relay and combination meter (See page N-35).

3 Check SLIP indicator light.

Open circuit in the combination meter (See page BE-1).

NG**Repair SLIP indicator light bulb or combination meter assembly.****OK****4 Check for short circuit in harness and connector between SLIP indicator light and ABS & BA & TRC & VSC ECU (See page IN-35).****NG****Repair or replace harness or connector.****OK****Check and repair ABS & BA & TRC & VSC ECU.**