

22. No voice navigation.

INSPECTION PROCEDURE

- 1 Set the volume to the max in the menu screen.

OK

Normal (Voice navigation is not available. No destination is set, or the vehicle is running off the route.)

NG

- 2 Check for open or short in harness and connector between navigation ECU and driver side door speaker (see page DI-265).

NG

Replace or repair wire harness.

OK

- 3 Check the sound. (Check if the radio sound can be heard from the driver side door speaker.)

OK

Replace the navigation ECU.

NG

Replace the speaker.