

REMOVAL

1. DISCHARGE REFRIGERANT FROM REFRIGERATION SYSTEM

HINT:

At the time of installation, please refer to the following item.


Evacuate air from refrigeration system.

Charge system with refrigerant and inspect for leakage of refrigerant.

Specified amount:

w/o Cool Box: 1,050 ± 50 g (37.03 ± 1.76 oz.)

w/ Cool Box: 1,150 ± 50 g (40.56 ± 1.76 oz.)



106687

2. DISCONNECT LIQUID AND SUCTION TUBES

Remove the bolt and slide the plate, then disconnect the both tubes.

Torque: 10 N·m (100 kgf·cm, 7 ft·lbf)

NOTICE:

Cap the open fittings immediately to keep moisture or dirt out of the system.


HINT:

At the time of installation, please refer to the following item.

Lubricate 2 new O-rings with compressor oil and install them to the tubes.

3. REMOVE THESE PARTS:


- (a) Rear door scuff plate RH
 - (b) Rear floor mat support plate
 - (c) Roof headlining rear trim
 - (d) Quarter trim panel RH
 - (e) Roof side inner upper garnish
- (See page BO-137)




107931

4. REMOVE NO. 1 COOLER AIR DUCT

- (a) Remove the 3 roof headlining set clips.



- (b) Remove the 5 clips and duct.



5. REMOVE REAR COOLING UNIT

- (a) Disconnect the connectors.
(b) Remove the 3 bolts and cooling unit.