

WATER TEMPERATURE CUT SWITCH (1HZ, 1HD-T) INSPECTION


AC1UG-01

1. REMOVE WATER TEMPERATURE CUT SWITCH


- (a) Drain engine coolant.

HINT:

It is not necessary to drain out all coolant.



- (b) Disconnect the connector.
(c) Remove the switch.



2. INSPECT WATER TEMPERATURE CUT SWITCH

Check the continuity between terminals when engine coolant temperature is changed as shown in the chart.

If continuity is not as specified, replace the switch.

3. INSTALL WATER TEMPERATURE CUT SWITCH

- (a) Install the switch.

Torque: 34 N·m (350 kgf·cm, 25 ft·lbf)

- (b) Connect the connector.
(c) Fill with engine coolant.