

5. Self-Diagnosis Function

- If the airbag sensor assembly detects a malfunction in the SRS airbag system, the airbag sensor assembly stores the malfunction data in memory, in addition to illuminating the SRS warning light. The DTC (Diagnostic Trouble Code) can be accessed by connecting a hand-held tester to the DLC3 terminal or the SST (09843-18040) to the Tc and CG terminals of the DLC3 and reading the blinking of the SRS warning light. For details, see the Avalon Repair Manual Supplement (Pub. No. RM952E).
- The following DTC are added.

DTC No.	Detection Item	DTC No.	Detection Item
B1180/17	Short in D squib (2nd step) circuit	B0127/27	Seat belt buckle switch (LH) short circuit malfunction
B1181/18	Open in D squib (2nd step) circuit	B1187/55	Short in P squib (2nd step) circuit (to ground)
B1182/19	Short in D squib (2nd step) circuit (to ground)	B1188/56	Short in P squib (2nd step) circuit (to B+)
B1183/22	Short in D squib (2nd step) circuit (to B+)	B1185/57	Short in P squib (2nd step) circuit
B1153/25	Seat position sensor assembly malfunction	B1186/58	Open in P squib (2nd step) circuit
B0126/27	Seat belt buckle switch (LH) open circuit malfunction	—	—