


DTC	19	Rear Room Temperature Sensor Circuit
------------	-----------	---

CIRCUIT DESCRIPTION

This sensor detects the temperature inside the cabin (rear side) and sends the appropriate signals to the rear A/C amplifier.


DTC No.	Detection Item	Trouble Area
19	Open or short in rear room temperature sensor circuit	<ul style="list-style-type: none"> •Rear room temp. sensor •Harness or connector between rear room temp. sensor and rear A/C amplifier •Rear A/C amplifier

WIRING DIAGRAM



INSPECTION PROCEDURE

1 Check voltage between terminals TR and SGND of A/C amplifier.

**PREPARATION:**

Remove rear A/C amplifier with connectors still connected.

CHECK:

- Turn ignition switch to ON.
- Measure voltage between terminals TR and SGND of rear A/C amplifier connector at each temperature.

OK:**Voltage**

at 25°C (77°F) 1.8 – 2.2 V

at 40°C (104°F) 1.2 – 1.6 V

HINT:

As the temperature increases, the voltage decreases.


NG

Go to step 2.

OK

Proceed to next circuit inspection shown on problem symptoms table (See page DI-1238). However, if DTC 19 is displayed, check and replace A/C amplifier.

2 Check rear room temperature sensor.

**PREPARATION:**

Disconnect rear room temperature sensor connector.

CHECK:

Measure resistance between terminals 1 and 2 of room temperature sensor connector at each temperature.

OK:**Resistance :**

at 25°C (77°F) : 1.65 – 1.75 kΩ

at 50°C (122°F) : 0.55 – 0.65 kΩ

HINT:

As the temperature increases, the resistance decreases.

NG

Replace rear room temperature sensor.

OK

3

Check harness and connector between rear A/C amplifier and rear room temperature sensor (See page IN-38).

NG

Repair or replace harness or connector.

OK

Check and replace A/C amplifier.