


2. Layout of Main Components



258RV67

3. Diagnosis

- If the CAN has communication error at ECU or sensor, DTCs (Diagnostic Trouble Codes) are output simultaneously to indicate the malfunction location.
- The DTCs for CAN communication concerning the brake control system can be read by connecting the SST 09843-18040 to Tc and CG terminals of DLC3 connector, and observing the blinking of the ABS and VSC warning light (2-digit code) or by connecting a hand-held tester (5-digit code). For details, see the RAV4 Repair Manual Supplement (Pub. No. 1078E).

► DTC Combination Chart ◀

DTC Code Output (from VSC ECU)	Mode
U0073/94, U0123/62 U0124/95, U0126/63	Skid Control ECU communication stop mode
U0123/62, U0124/95	Yaw rate and deceleration sensor communication stop mode
U0126/63	Steering angle sensor communication stop mode

► DTC Chart ◀

DTC	Detection Item
U0073/94	Malfunction in CAN communication
U0123/62	Malfunction in CAN communication with yaw rate sensor
U0124/95	Malfunction in CAN communication with deceleration sensor
U0126/63	Malfunction in CAN communication with Steering angle sensor