

INSTALLATION

Installation is in the reverse order of removal (See page TR-6).

HINT:

After installation, do the road test.