

CIRCUIT INSPECTION


DTC	B2785/99	IG Switch ON Malfunction
------------	-----------------	---------------------------------

DTC	B2786/99	IG Switch OFF Malfunction
------------	-----------------	----------------------------------

CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
B2785/99	<ul style="list-style-type: none"> • Short circuit in IG switch circuit • IG switch adheres to ON position 	<ul style="list-style-type: none"> • IG switch • EFI Main Relay • Wire harness
B2786/99	<ul style="list-style-type: none"> • Open circuit in IG switch circuit • IG switch adheres to OFF position 	

WIRING DIAGRAM




I07554

INSPECTION PROCEDURE

1

Check voltage between terminals +B and E1 of Engine and ECT ECU connectors.



PREPARATION:

- (a) Remove the glove compartment.
- (b) Turn ignition switch ON.

CHECK:

Measure voltage between terminals +B and E1 of Engine and ECT ECU connectors.

OK:

Voltage: 9 – 14 V

OK

Proceed to next circuit inspection shown in problem symptoms table (See page DI-753).

NG

2

Check for open in harness and connector between terminal E1 of Engine and ECT ECU and body ground (See page IN-35).

NG

Repair or replace harness or connector.

OK

3

Check EFI main relay (Marking: EFI).


NG

Replace EFI main relay.

OK

4 Check EFI fuse.**NG****Check for short in all the harness and components connected to EFI fuse.****OK****5 Check for open in harness and connector between EFI main relay (Marking: EFI) and battery, EFI main relay (Marking: EFI) and Engine and ECT ECU (See page IN-35).****NG****Repair or replace harness or connector.****OK****6 Check IGN fuse.**

Driver Side J/B



107273

PREPARATION:

Remove the IGN fuse from the driver side J/B.

CHECK:

Check continuity of IGN fuse.

OK:**Continuity****NG****Check for short in all the harness and components connected to IGN fuse.****OK**

7 Check ignition switch (See page BE-20).

NG

Replace ignition switch.

OK

8 Check for open circuit in harness and connector between IG switch and EFI main relay, EFI main relay and body ground (See page N-35).

NG

Repair or replace wire harness and connector.

OK

Replace Engine and ECT ECU.