

## INSPECTION

### 1. INSPECT HEADLIGHT BEAM LEVEL CONTROL SWITCH CURRENT


#### NOTICE:

**If a resistor is not placed, switch may be damaged.**

Measure the current between terminals 4 and 5.

Switch position	Resistance (mA)
0	Approx. 8.0
1	Approx. 7.2
2	approx. 6.4
3	Approx. 5.6
4	Approx. 4.8
5	Approx. 4.0


If current value is not as specified, replace the switch.



### 2. INSPECT HEADLIGHT BEAM LEVEL CONTROL SWITCH ILLUMINATION

Connect the positive (+) lead from the battery to terminal 3 and negative (-) lead to terminal 6, and check that the illumination light lights up.

If operation is not as specified, replace the switch.



### 3. INSPECT HEADLIGHT BEAM LEVEL CONTROL ACTUATOR CIRCUIT

#### NOTICE:

**If a resistor is not placed, switch may be damaged.**

Disconnect the connector and inspect connector on wire harness side, as shown in the chart.

Switch position	Resistance (mA)
0	Approx. 8.0
1	Approx. 7.2
2	approx. 6.4
3	Approx. 5.6
4	Approx. 4.8
5	Approx. 4.0

If circuit is as specified, replace the actuator.